

ShanWan Q41

ShanWan Wireless Controller User Manual

Model: Q41

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your ShanWan Wireless Controller (Model Q41). Please read this manual thoroughly before using the product to ensure proper functionality and to maximize your gaming experience. This controller is compatible with PS4, PS3, PC, Mac, iOS, and Android devices. It is not compatible with PS5 games.

PRODUCT OVERVIEW

Controller Components



Image: Front and back view of the ShanWan Wireless Controller in white and black. The front shows the joysticks, D-pad, action buttons, and central touchpad. The back reveals the M1 and M2 programmable buttons and product labeling.

The ShanWan Wireless Controller features a standard gamepad layout with dual analog sticks, a D-pad, action buttons (Triangle, Circle, Cross, Square), shoulder buttons (L1, R1, L2, R2), a central touchpad, and a Home button. Additionally, it includes programmable M1 and M2 back buttons for enhanced customization.

Key Features



Image: A black ShanWan Wireless Controller with eight icons illustrating its main features: Wireless Connection, Share function, 3.5mm Audio Jack, Double Vibration, Touchpad, Programmable function, 6-axis Gyro, and Mobile Holder.

- **Extensive Compatibility:** Supports PS4, PS3, PC, Mac, iOS, and Android devices.
- **Dual Vibration Motors:** Provides haptic feedback for an immersive gaming experience.
- **6-Axis Gyro Sensor:** Detects controller tilt for responsive in-game actions.
- **Programmable Back Buttons (M1 & M2):** Allows assignment of complex in-game macros.
- **Integrated Touchpad:** Offers additional control options.
- **3.5mm Audio Jack:** For connecting headphones or headsets.
- **Ergonomic Design:** Contoured shape and non-slip frosted back for comfortable, extended use.
- **Long-lasting Battery:** Built-in 600mAh rechargeable battery provides 8-10 hours of playtime.
- **Mobile Phone Bracket:** Included for convenient mobile gaming.

SETUP INSTRUCTIONS

Charging the Controller



Image: A close-up of the ShanWan Wireless Controller's central area, illustrating battery specifications: 600mAh rechargeable battery, 10 hours playing time, 2 hours charging time, and 30 days standby time.

1. Connect the provided USB charging cable to the controller's charging port.
2. Connect the other end of the USB cable to a power source (e.g., PS4 console, PC, or USB wall adapter).
3. The controller's indicator light will show charging status. A full charge typically takes 1-2 hours.
4. Once fully charged, the controller provides approximately 8-10 hours of continuous gameplay.

Pairing with Devices

The controller supports wireless connection up to 8 meters.

For PS4/PS3 Console:

1. Ensure the console is powered on.
2. Connect the controller to the console using the USB cable.
3. Press the Home button on the controller. The controller will pair with the console.
4. Once paired, you can disconnect the USB cable for wireless use.

For PC/Mac:

1. Connect the controller to your PC/Mac using the USB cable. The system should automatically detect and install the necessary drivers.

2. For wireless connection, ensure your PC/Mac has Bluetooth enabled. Put the controller into pairing mode (specific button combination may vary, typically holding Share + Home button until light flashes). Select the controller from your device's Bluetooth settings.

For iOS/Android Devices:

1. Ensure Bluetooth is enabled on your mobile device.
2. Put the controller into pairing mode (typically holding Share + Home button until the light bar flashes rapidly).
3. On your mobile device, search for Bluetooth devices and select "ShanWan Controller" or similar.
4. Once connected, the indicator light will stabilize.
5. Utilize the included phone bracket to attach your mobile device to the controller.

OPERATING INSTRUCTIONS

Basic Controls

- **Analog Sticks:** Used for movement and camera control.
- **D-Pad:** For directional input, often in menus or specific game actions.
- **Action Buttons (Triangle, Circle, Cross, Square):** Perform in-game actions.
- **Shoulder Buttons (L1, R1, L2, R2):** Used for various in-game functions like aiming, shooting, or item usage.
- **Home Button:** Accesses the system menu or returns to the home screen.
- **Share Button:** For sharing gameplay content (functionality depends on the platform).
- **Options Button:** Accesses in-game menus or pause functions.
- **Touchpad:** Functions as a clickable button and a touch-sensitive surface for specific game interactions.

Programmable Back Buttons (M1/M2)



Image: The back of the ShanWan Wireless Controller, highlighting the M1 and M2 programmable buttons. An overlay illustrates various buttons (L1, R1, L2, R2, Triangle, Circle, Cross, Square, Home, L3, R3) that can be mapped to M1 and M2.

The M1 and M2 buttons on the back of the controller can be programmed to replicate other button inputs, allowing for custom layouts and macros.

1. **Entering Programming Mode:** Press and hold the "SET" button (usually a small button near M1/M2, or a combination like Share + Options) until the indicator light changes (e.g., starts flashing).
2. **Assigning a Button:** Press the M1 or M2 button you wish to program, then press the button you want to assign to it (e.g., R3, L2, Triangle).
3. **Exiting Programming Mode:** Press the "SET" button again to save the setting and exit programming mode. The indicator light should return to its normal state.

Refer to the specific instructions provided with your controller packaging for exact button combinations for programming mode, as these can sometimes vary slightly.

Using Gamepad Space & ShanWan Controller Apps



Image: A split image demonstrating the use of two applications. On the left, a person is holding the ShanWan controller with a smartphone attached, displaying the "Gamepad Space" app interface for controller customization. On the right, a person holds a smartphone showing the "ShanWan Controller" app icon, indicating it's an application market for mobile games compatible with the controller.

- **Gamepad Space:** This application allows you to customize the key mapping and trigger functions of your controller, providing a personalized gaming experience. Download it from your device's app store.
- **ShanWan Controller:** This is an application market designed for mobile phone handles. You can download games directly to your phone through this app that are optimized for use with the ShanWan controller, supporting popular titles like Call of Duty Mobile. Download it from your device's app store.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the controller. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. If storing for an extended period, charge the battery to about 50% every few months.
- **Avoid Impact:** Do not drop or subject the controller to strong impacts, as this can damage internal components.

TROUBLESHOOTING

Controller does not turn on:

Ensure the controller is charged. Connect it to a power source using the USB cable and allow it to charge for at least 30 minutes before attempting to turn it on again.

Controller does not connect wirelessly:

- Ensure the controller is in pairing mode (indicator light flashing).

- Verify Bluetooth is enabled on your device (console, PC, mobile).
- Move the controller closer to the device. The maximum wireless range is 8 meters.
- Try restarting both the controller and the device you are trying to connect to.
- If connecting to a console, try connecting via USB cable first to establish the initial pairing.

Buttons are unresponsive or sticky:

Clean the controller as described in the Maintenance section. If the issue persists, contact customer support.

Vibration function is not working:

Check in-game settings to ensure vibration is enabled. Some games or platforms may have options to disable haptic feedback.

Programmable buttons (M1/M2) are not working as expected:

Re-enter programming mode and re-assign the desired functions to ensure they were set correctly. Refer to the "Programmable Back Buttons" section.







SPECIFICATIONS

Model:	Q41
Compatibility:	PS4, PS3, PC, Mac, iOS, Android (Not compatible with PS5 games)
Battery Capacity:	600mAh rechargeable lithium-ion battery
Charging Time:	Approximately 1-2 hours
Playing Time:	Approximately 8-10 hours
Wireless Range:	Up to 8 meters
Product Dimensions:	6.29 x 2.75 x 2.35 inches
Item Weight:	13.1 ounces
Manufacturer:	ShanWan
First Available:	June 14, 2023

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact ShanWan customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

Related Documents - Q41

	<p>ShanWan Q11A Retractable Gamepad User Manual</p> <p>User manual for the ShanWan Q11A retractable gamepad, detailing its features, connectivity options (Bluetooth, USB), compatibility with various platforms (Android, iOS, PC, PS3/PS4, Switch), operation instructions, and specifications.</p>
	<p>ShanWan Q36 Pro Wireless Gaming Controller User Manual</p> <p>Comprehensive user guide for the ShanWan Q36 Pro Wireless Gaming Controller, covering setup, connectivity for Android, iOS, Windows, and Nintendo Switch, PS4 compatibility, firmware updates, and technical specifications.</p>
	<p>ShanWan Q38 Wireless Gaming Controller User Manual and Features</p> <p>Comprehensive guide to the ShanWan Q38 wireless gaming controller, covering setup, modes (Android/iOS/Windows, Switch, PS4), firmware upgrades, additional functions, and specifications.</p>
	<p>ShanWan Q36 Wireless Game Controller: User Guide and Connection Modes</p> <p>Comprehensive guide to the ShanWan Q36 wireless game controller. Learn how to connect to Android, iOS, Windows, Nintendo Switch (Pro and Joycon modes), and PS4. Includes setup, firmware updates, and technical specifications.</p>
	<p>ShanWan Q36 Wireless Gamepad User Guide</p> <p>A comprehensive guide to the ShanWan Q36 Wireless Gamepad, covering setup, connectivity for Android, iOS, and Windows, and charging functions. Learn how to pair your device and optimize your gaming experience.</p>
	<p>ShanWan Q36 Game Controller User Guide and Connectivity Modes</p> <p>Comprehensive guide to the ShanWan Q36 game controller, covering X-Input, HID, and ShootingPlus modes for Android, iOS, and Windows. Includes setup, charging, and electrical specifications.</p>