

Manuals.plus /
› ASHATA /
› M9 Plus HDMI Display Dongle Adapter User Manual

ASHATA ASHATAu6kcri7sn0

M9 Plus HDMI Display Dongle Adapter User Manual

Model: ASHATAu6kcri7sn0 | Brand: ASHATA

INTRODUCTION

The ASHATA M9 Plus HDMI Display Dongle Adapter is a versatile device designed to wirelessly mirror or stream content from your mobile devices (Android, iOS) and PCs to a larger display such as an HDTV or monitor. It supports 1080P resolution and various mirroring protocols including Miracast, DLNA, and AirPlay, making it ideal for presentations, entertainment, and educational purposes.

This manual provides detailed instructions on how to set up, operate, and troubleshoot your M9 Plus HDMI Display Dongle Adapter to ensure optimal performance.

PRODUCT OVERVIEW



Image: The M9 Plus HDMI Display Dongle Adapter, a compact black device with an HDMI connector on one end.



Image: The M9 Plus HDMI Display Dongle Adapter shown alongside its USB power cable, which includes a Wi-Fi receiver module.

SETUP INSTRUCTIONS

1. **Connect to TV/Monitor:** Insert the HDMI connector of the M9 Plus dongle into an available HDMI port on your HDTV or monitor.
2. **Power On:** Connect the USB power cable to the dongle's micro USB port. Plug the USB-A end of the cable into a USB power adapter (5V/1A recommended, not included) or a USB port on your TV that provides sufficient power. The dongle will power on and display its main screen on your TV.
3. **Select HDMI Input:** Use your TV remote to select the correct HDMI input source that the dongle is connected to.
4. **Initial Setup (Wi-Fi Connection):**
 - On the TV screen, you will see the dongle's Wi-Fi name (SSID) and password.
 - On your mobile device (phone/tablet), go to Wi-Fi settings and connect to the dongle's Wi-Fi network.

- Open a web browser on your mobile device and enter the IP address displayed on the TV screen (e.g., 192.168.49.1) to access the dongle's settings page.
- From the settings page, select "Internet" or "Wi-Fi Setup" to connect the dongle to your home Wi-Fi network. This allows the dongle to access the internet for firmware updates and content streaming.

OPERATING INSTRUCTIONS

Screen Mirroring (General)

The M9 Plus supports various screen mirroring protocols. Ensure your device is connected to the same Wi-Fi network as the dongle (or directly to the dongle's Wi-Fi if not connected to home Wi-Fi).

For iOS Devices (AirPlay)

1. Ensure your iOS device is connected to the same Wi-Fi network as the M9 Plus dongle.
2. Swipe down from the top-right corner (or up from the bottom for older devices) to open Control Center.
3. Tap "Screen Mirroring" or "AirPlay Mirroring".
4. Select the M9 Plus dongle from the list of available devices. Your iOS device screen will now be mirrored to the TV.

For Android Devices (Miracast/Smart View/Wireless Display)

1. Ensure your Android device is connected to the same Wi-Fi network as the M9 Plus dongle.
2. Navigate to your device's settings. The exact path may vary by device, but commonly found under:
 - Settings > Connected devices > Connection preferences > Cast
 - Settings > Display > Cast
 - Settings > Smart View / Screen Mirroring / Wireless Display / Multi-screen
3. Enable the casting feature and select the M9 Plus dongle from the list. Your Android device screen will now be mirrored to the TV.

For PC (Windows/macOS)

For Windows PCs, use the "Connect" feature (Windows Key + K) and select the dongle. For macOS, use AirPlay mirroring if supported, or third-party software if needed.



Image: The M9 Plus dongle connected to a display, demonstrating its use for screen mirroring in a meeting or classroom setting.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the dongle. Do not use liquid cleaners or aerosols.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Firmware Updates:** The dongle supports automatic firmware upgrades. Ensure it is connected to the internet via your home Wi-Fi for these updates to occur, which will keep it compatible with the latest device versions.

TROUBLESHOOTING

No display on TV:

- Ensure the dongle is properly inserted into the HDMI port.
- Verify the TV is set to the correct HDMI input source.
- Check if the USB power cable is securely connected and receiving sufficient power (try a different USB port or power adapter).

Cannot connect mobile device to dongle's Wi-Fi:

- Ensure the dongle is powered on and displaying its Wi-Fi SSID and password on the TV.
- Double-check the Wi-Fi password.
- Restart both the dongle (by unplugging and re-plugging power) and your mobile device.

Screen mirroring is laggy or disconnects frequently:

- Ensure your mobile device and the dongle are close to each other and within range of your Wi-Fi router (if connected to home Wi-Fi).
- Reduce interference by moving away from other wireless devices.
- Check your home Wi-Fi network's stability and speed.
- Ensure the dongle's firmware is up to date.

Dongle does not automatically upgrade:

- Ensure the dongle is connected to a stable internet connection via your home Wi-Fi network.
- Access the dongle's settings page via a web browser on your mobile device and look for a manual update option if available.

SPECIFICATIONS

Feature	Detail
Model Name	ASHATAu6kcri7sn0
Brand	ASHATA
Connectivity Technology	HDMI, Wi-Fi (2.4G)
Connector Type	HDMI
Resolution	1080p
Supported Protocols	Miracast, DLNA, AirPlay
Supported OS	iOS 9.0+, Android 5.0+
Color	Black
Item Weight	2.29 ounces
Package Dimensions	5.35 x 4.02 x 1.3 inches

WARRANTY AND SUPPORT

For product support, technical assistance, or warranty inquiries, please contact ASHATA customer service through their official channels or the retailer from whom the product was purchased. Please refer to your purchase documentation for specific warranty terms and conditions.

Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C821S3C7>

More documents and user manuals: <https://manuals.plus/>