

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Midea](#) /
- › [Midea MDF18A1AWW Built-in Dishwasher User Manual](#)

## Midea MDF18A1AWW

# Midea MDF18A1AWW Built-in Dishwasher User Manual

Model: MDF18A1AWW

## 1. PRODUCT OVERVIEW

The Midea MDF18A1AWW is a slimline built-in dishwasher designed for efficiency and convenience in smaller kitchens or apartments. It offers a capacity of 8 place settings and features a digital control panel with an LED display for easy operation. This model is Energy Star 7.0 certified, ensuring energy-efficient performance.





Figure 1: Front view of the Midea MDF18A1AWW Built-in Dishwasher.

## 2. INSTALLATION AND SETUP

Proper installation is crucial for the optimal performance and longevity of your Midea dishwasher. This built-in model is designed to fit seamlessly into your kitchen cabinetry.

### 2.1 Dimensions and Capacity

- **Dimensions (D x W x H):** 22.6 x 17.6 x 32.4 inches (with adjustable legs)
- **Capacity:** 8 Place Settings
- **Maximum Plate Height:** Up to 11 inches



Figure 2: Interior view illustrating the 8 place setting capacity and key dimensions.

## 2.2 Required Accessories (Not Provided)

The following accessories are typically required for installation and are not included with the dishwasher:

- Power Supply Cord Kit
- Water Supply Line
- 90° Elbow (for water line connection)
- UL Listed Wire Nuts
- Strain Relief

## 2.3 Provided Accessories

The dishwasher package includes:

- Mounting Clamps
- Flat Head Wood Screws
- Screws
- Hose Clamp

- Adjustment Caps
- Installation Manual
- User Manual
- Kick Plate



Figure 3: Overview of installation parts and included accessories.

### 3. OPERATING INSTRUCTIONS

Your Midea dishwasher offers a variety of programs and functions to ensure optimal cleaning for different types of dishware.

#### 3.1 Control Panel

The digital control panel with an LED display is located on the top edge of the dishwasher door, providing easy access and clear visibility of selected programs and remaining cycle time.

# 1-Hour Quick Wash



Figure 4: Digital control panel with LED display for program selection and status.

## 3.2 Washing Programs

Select the appropriate program based on the soil level and type of dishes:

- **Heavy:** For heavily soiled dishes, pots, and pans.
- **Normal:** Standard program for daily soiled dishes.
- **ECO:** Energy-efficient program for normally soiled dishes.
- **Delicate:** Gentle wash for fragile items like glassware.
- **Quick:** A 1-hour cycle for lightly soiled dishes that need to be cleaned quickly.
- **Rinse:** For rinsing dishes that will be washed later.






Figure 5: The 1-Hour Quick Wash program provides fast cleaning for lightly soiled items.

### 3.3 Functions and Options

Enhance your wash cycle with these additional functions:

- **Heated Dry:** Ensures dishes come out dry and ready to use. This function is available for most cycles except Rapid and Self-clean.
- **Hi-Temp:** Maintains water temperature at 136°F (58°C) max for thorough cleaning and sanitization, suitable for heavily soiled items and baby bottles.
- **Sanitize:** Provides an extra sanitizing rinse to ensure dishes are hygienically clean.

# Stainless Steel Tub

More durable with better drying performance



Figure 6: Illustration of the Heated Dry function, ensuring dishes are extra dry.

## 3.4 Loading the Dishwasher

The dishwasher features versatile racks and a removable cutlery basket for flexible loading. Ensure dishes are loaded to allow water spray to reach all surfaces.




Figure 7: Example of proper dish loading in the dishwasher racks.



Figure 8: The removable cutlery basket for organizing forks, spoons, and knives.

**Note: ONLY use detergent specifically designed for dishwashers. Regular liquid dish soap will cause operational problems.**

## 4. MAINTENANCE

---

Regular maintenance helps ensure your dishwasher continues to operate efficiently.

### 4.1 Cleaning the Interior

The Midea MDF18A1AWW features a durable stainless steel tub, which contributes to better drying performance and longevity. Periodically inspect and clean the filter system at the bottom of the dishwasher to remove any food particles. Refer to the detailed installation manual for specific instructions on filter removal and cleaning.

### 4.2 Exterior Care

Wipe the exterior surfaces with a soft, damp cloth. For stainless steel finishes, use a specialized stainless steel cleaner to maintain its appearance.

## 5. TROUBLESHOOTING

---

This section provides general guidance for common issues. For detailed troubleshooting steps, please refer to the comprehensive user manual included with your product.



- **Dishes not clean:** Ensure proper loading, check detergent dispenser, verify water temperature, and clean filters.
- **Dishwasher not draining:** Check for clogs in the drain hose or filter.
- **Unusual noises:** Inspect for foreign objects in the pump area or spray arms.
- **Error codes:** Consult the user manual for specific error code interpretations and solutions.

## 6. SPECIFICATIONS

Feature	Specification
Brand	Midea
Model Name	MDF18A1AWW
Form Factor	Built-In
Finish Type	Stainless Steel
Color	White
Product Dimensions	22.6"D x 17.6"W x 32.4"H
Item Weight	54.6 Pounds
Capacity	8 Place Settings
Voltage	120 Volts
Annual Energy Consumption	234 Kilowatt Hours Per Year
Energy Star Rating	Energy Star 7.0 Certified
Noise Level	52 Decibels
Controls Type	Push Button
Special Feature	Digital Display

## 7. OFFICIAL PRODUCT INFORMATION

Learn more about Midea's commitment to innovation and manufacturing excellence in the dishwasher industry.

Your browser does not support the video tag.

Video 1: "The History of Midea's Dishwasher Development" - This video highlights Midea's journey in dishwasher manufacturing, emphasizing innovation and intelligent production processes.

## 8. WARRANTY AND SUPPORT






Midea offers protection plans for your dishwasher. For specific warranty details and customer support, please refer to the documentation included with your product or visit the official Midea website.

- **Protection Plans:** Available options include 3-Year Protection Plan and Complete Protect (monthly plan).

- **Customer Support:** Refer to your product documentation for contact information or visit the [Midea Store on Amazon](#) for more information.

© 2025 Midea. All rights reserved.

Related Documents - MDF18A1AWW

	<p><a href="#">Midea Dishwasher Instruction Manual - TORRINO</a></p> <p>Comprehensive instruction manual for the Midea TORRINO dishwasher, covering safety information, product overview, usage, maintenance, installation, and troubleshooting.</p>
	<p><a href="#">Midea Dishwasher User Manual - MDF18A1AWW, MDF18A1ABB, MDF18A1AST Models</a></p> <p>Comprehensive user manual for Midea dishwashers (models MDF18A1AWW, MDF18A1ABB, MDF18A1AST), covering safety, operation, maintenance, and troubleshooting. Find detailed instructions and specifications.</p>
	<p><a href="#">Midea Dishwasher User Manual MDF18A1AWW, MDF18A1ABB, MDF18A1AST</a></p> <p>User manual for the Midea Dishwasher (models MDF18A1AWW, MDF18A1ABB, MDF18A1AST), covering safety, operation, parts, setup, controls, loading, care, and troubleshooting.</p>
	<p><a href="#">Midea Dishwasher User Manual: MDF18A1AWW, MDF18A1ABB, MDF18A1AST</a></p> <p>Comprehensive user manual for Midea dishwashers, model series MDF18A1AWW, MDF18A1ABB, and MDF18A1AST. Includes setup, operation, maintenance, safety precautions, and troubleshooting.</p>
	<p><a href="#">Midea Dishwasher Instruction Manual - TORRINO</a></p> <p>Comprehensive instruction manual for the Midea TORRINO dishwasher, covering safety information, product overview, usage instructions, installation, and troubleshooting.</p>



Comprehensive instruction manual for Midea dishwashers, models MDWCSS and MDWCW. Covers operation, loading, maintenance, troubleshooting, and technical specifications for optimal use.