

[Manuals.plus](#) /

› [MoNiBloom](#) /

› MoNiBloom 3 Wheels Pet Stroller Instruction Manual

MoNiBloom A78-PS-001-NB

MoNiBloom 3 Wheels Pet Stroller Instruction Manual

Brand: MoNiBloom | Model: A78-PS-001-NB

1. SAFETY INFORMATION

Please read all instructions carefully before assembling and using the pet stroller. Failure to follow these instructions may result in injury to your pet or damage to the product.

- **Maximum Weight Capacity:** Do not exceed the maximum weight recommendation of 33 pounds (14.97 kg).
- **Pet Supervision:** Never leave your pet unattended in the stroller.
- **Secure Your Pet:** Always use the internal safety leashes to secure your pet to prevent them from jumping out.
- **Brake Usage:** Always engage the rear wheel brakes when the stroller is stationary, especially on inclines.
- **Proper Assembly:** Ensure all parts are correctly assembled and locked into place before use.
- **Terrain:** While designed for smooth rides, exercise caution on rough or uneven terrain.
- **Weather Protection:** Utilize the canopy and mesh covers to protect your pet from direct sunlight or light rain.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Stroller Frame (Pre-assembled)
- Main Pet Compartment
- Front Wheel Assembly (1 unit)
- Rear Wheels (2 units)
- Cup Holder Tray
- Storage Basket (Pre-attached)
- Removable Soft Pad

- Safety Leashes (2 units, pre-attached)

3. SETUP AND ASSEMBLY

Follow these steps to assemble your MoNiBloom Pet Stroller:

1. **Unfold the Stroller Frame:**

Place the folded stroller frame on a flat surface. Press the single button on the handle and pull the handle upwards until the frame locks into its open position. Ensure all locking mechanisms are securely engaged.



JUST A SINGLE BUTTON PRESS TO FOLD
WHILE OTHERS STRUGGLE WITH CUMBERSOME TWO-HAND MECHANISMS.

Image: The stroller's one-button folding mechanism, demonstrating how to unfold the frame by pressing the button on the handle.

2. **Attach the Wheels:**

Insert the single front wheel assembly into the designated slot at the front of the stroller until it clicks securely into place. Attach the two rear wheels to their respective axles at the back of the stroller, ensuring they are firmly seated.



Image: A close-up view of the rear wheels with their foot-activated lock and the 360-degree swivel front wheels, illustrating their attachment points.

3. Install the Cup Holder Tray:

Align the cup holder tray with the attachment points on the stroller handle and push down until it snaps into place.

CUP HOLDER TRAY FOR YOUR BEVERAGE NEEDS



Image: The cup holder tray attached to the stroller handle, showing its convenient placement for beverages and small items.

4. Prepare the Pet Compartment:

Place the removable soft pad inside the main pet compartment for added comfort. Ensure the internal safety leashes are accessible.



**SPACIOUS AND
COMFORTABLE**

Image: The spacious interior of the pet compartment, highlighting the removable soft pad for pet comfort.

4. OPERATING INSTRUCTIONS

Placing Your Pet Inside:

The stroller offers multiple entry points for your pet's convenience:

- **Front Entry:** Unzip the front mesh window for easy access.
- **Top Entry:** Open the top canopy and mesh cover to place your pet directly into the compartment.
- **Rear Entry:** Unzip the rear mesh panel for an alternative entry.

Once your pet is inside, always attach their harness or collar to the internal safety leashes to prevent them from jumping out.

WITH MULTIPLE OPENINGS

FOR FEEDING AND PLAY, LETS YOUR PET ENJOY THE RIDE!



Image: The pet stroller featuring various mesh openings, allowing for multiple entry points and excellent ventilation for your pet.

Using the Canopy and Mesh Windows:

The adjustable canopy provides shade and protection. The mesh windows ensure proper ventilation and visibility for your pet.

- Adjust the canopy by pushing or pulling it to the desired position.
- The mesh windows can be zipped open or closed as needed for airflow or security.

ADJUSTABLE CANOPY



Image: The adjustable canopy of the pet stroller, demonstrating its flexibility and the integrated mesh window for visibility and ventilation.

Using the Storage Features:

- **Cup Holder Tray:** Use the tray on the handle to hold beverages, keys, or small personal items.
- **Storage Basket:** The spacious basket located underneath the pet compartment is ideal for carrying pet essentials, toys, or personal belongings.



A SPACIOUS BOTTOM STORAGE FOR PET ESSENTIALS

Image: The large storage basket located at the bottom of the stroller, providing ample space for pet supplies or personal items.

Maneuvering and Braking:

- The 360° swiveling front wheel allows for easy navigation and smooth turns.
- To engage the brakes, press down on the foot-activated locks located on each rear wheel. To release, lift the locks upwards.

5. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your pet stroller:

- **Cleaning Fabric:** The Oxford cloth material is water-resistant. Wipe down fabric surfaces with a damp cloth and mild soap. Do not use harsh chemicals.
- **Cleaning Mesh:** Gently wipe mesh areas with a damp cloth.
- **Frame Cleaning:** Clean the alloy steel frame with a damp cloth. Dry thoroughly to prevent rust.

- **Wheel Maintenance:** Periodically check wheels for debris and clean as necessary. Lubricate axles if wheels become stiff.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use.



600D OXFORD CLOTH DURABLE AND WATER RESISTANT

Image: A close-up view of the 600D Oxford cloth, highlighting its durable and water-resistant properties for easy cleaning.

6. TROUBLESHOOTING

If you encounter any issues with your pet stroller, refer to the following common solutions:

- **Stroller Does Not Unfold/Fold Smoothly:**
 - Ensure the folding mechanism button is fully pressed.
 - Check for any obstructions in the frame hinges.
- **Wheels Are Stiff or Squeaky:**

- Clean any dirt or debris from the wheel axles.
- Apply a small amount of silicone-based lubricant to the wheel axles.

- **Brakes Not Engaging/Disengaging:**

- Check for any obstructions around the brake mechanism.
- Ensure the brake levers are fully pushed down or lifted up.

- **Pet Not Comfortable:**

- Ensure the removable soft pad is correctly placed.
- Allow your pet time to adjust to the stroller in a familiar environment.

For issues not covered here, please contact MoNiBloom customer support.

7. SPECIFICATIONS

Brand	MoNiBloom
Model Number	A78-PS-001-NB
Color	Navy Blue
Material	Polyester (600D Oxford Cloth), breathable mesh
Frame Material	Alloy Steel
Maximum Weight Recommendation	33 Pounds (14.97 kg)
Item Weight	11.02 Pounds (5 kg)
Item Dimensions (L x W x H)	29"L x 13"W x 40"H (73.66 cm x 33.02 cm x 101.6 cm)
Folded Size (D x W x H)	19"D x 32"W x 12"H (48.26 cm x 81.28 cm x 30.48 cm)
Number of Wheels	3 (1 front swivel, 2 rear with brakes)
Number of Cup Holders	2

PRODUCT DIMENSIONS



Image: A detailed diagram illustrating the dimensions of the MoNiBloom 3 Wheels Pet Stroller in both unfolded and folded states.

8. WARRANTY AND SUPPORT

For warranty information and customer support regarding your MoNiBloom 3 Wheels Pet Stroller, please contact the seller directly. Keep your purchase receipt as proof of purchase.

MoNiBloom is committed to providing high-quality products and excellent customer service. If you have any questions or require assistance, do not hesitate to reach out.