

[Manuals.plus](#) /

> [APEXEL](#) /

> APEXEL Flexible Phone Tripod (Model CH-2) Instruction Manual

APEXEL CH-2

APEXEL Flexible Phone Tripod (Model CH-2) Instruction Manual

Your guide to setting up and using your APEXEL Flexible Phone Tripod.

INTRODUCTION

Thank you for choosing the APEXEL Flexible Phone Tripod. This manual provides detailed instructions for setting up, operating, and maintaining your tripod to ensure optimal performance for your photography and videography needs. This versatile tripod is designed for use with smartphones, digital cameras, and GoPro devices, offering stability and flexibility for various shooting environments.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1x Flexible Tripod
- 1x Phone Clip
- 1x Wireless Remote Control
- 1x GoPro Adapter

SETUP INSTRUCTIONS

1. Attaching the Phone Clip or GoPro Adapter

The tripod features a standard 1/4-inch screw mount. To attach the phone clip or GoPro adapter:

1. Locate the 1/4-inch screw on the tripod's ball head.
2. Align the threaded hole on the phone clip or GoPro adapter with the screw.
3. Rotate clockwise until securely fastened. Do not overtighten.



HARD WITH SOFTNESS, FLEXIBLE AND VERSATILE LIKE AN OCTOPUS



High elastic foam
protective cover



Bold aluminum
alloy inner core



Flexible winding,
repeated bending
without breaking

Image: The flexible tripod with the phone clip attached, ready for use.

2. Mounting Your Device (Phone, Camera, or GoPro)

Once the appropriate adapter is attached, mount your device:

- **For Smartphones:** Gently pull apart the spring-loaded phone clip and insert your smartphone. Ensure it is centered and held firmly. The clip accommodates phones from 2.16 to 3.67 inches wide.
- **For Digital Cameras:** Screw the camera directly onto the 1/4-inch screw mount on the tripod's ball head.

- **For GoPro:** Attach your GoPro to the provided GoPro adapter, then secure the adapter to the tripod.



Multifunctional Mobile Phone Holder

Allows More Accessories & Fuctional



Image: The tripod demonstrating compatibility with both a smartphone and a digital camera.

3. Pairing the Wireless Remote Control

The wireless remote control allows you to capture photos and videos from a distance (up to 10m/30ft). It is compatible with iOS and Android phones.

1. Ensure the remote control has a working battery.

2. Turn on the remote control (usually a small switch on the side). A blue LED indicator should blink.
3. On your smartphone, go to **Settings** > **Bluetooth**.
4. Search for available devices and select "AB Shutter3" or a similar name.
5. Once paired, the LED indicator will stop blinking.
6. Open your phone's camera app. Press the corresponding button on the remote (iOS or Android) to take a photo or start/stop video recording.

Wide Compatibility



For Phone from 2.16-3.67"



For Camera



For Sport Camera
(GoPro adapter Included)



Image: A user pairing the wireless remote control with a smartphone.

OPERATING INSTRUCTIONS

Flexible Legs for Versatile Positioning

The tripod's legs are made of durable metal with a rubber coating, allowing them to be bent and twisted into various shapes. This flexibility enables you to:

- **Stand on Uneven Surfaces:** Adjust the legs to stabilize the tripod on rocks, stairs, or other irregular terrain.
- **Wrap Around Objects:** Securely attach the tripod to poles, branches, railings, or chair backs for unique angles and hands-free operation.
- **Use as a Handheld Grip:** Straighten the legs to use the tripod as a comfortable grip for vlogging or selfies.



Handheld Selfie Stick
Stable handle when shooting vlog or selfie



Winding Fixed
Can be wrapped around various objects for more shooting angles and creativity



Stable Tripod
Triangular stable support, photography, drama watching, live broadcasting, desktop use, etc.

Image: The flexible tripod legs wrapped around a railing, securely holding a smartphone.



Image: The tripod configured as a handheld selfie stick for vlogging.

Multi-Angle Shooting with 360° Swivel Ball Joint

The integrated 360-degree swivel ball joint allows for precise positioning of your device. You can easily switch between vertical, horizontal, and high-angle shooting modes without removing your phone or camera. Simply loosen the knob on the ball joint, adjust the angle, and tighten to secure.



Image: The smartphone holder demonstrating its 360-degree rotation capability.

MAINTENANCE

To ensure the longevity and optimal performance of your APEXEL Flexible Phone Tripod, follow these maintenance guidelines:

- **Cleaning:** Wipe the tripod with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Overloading:** Do not exceed the maximum weight limit of 6.6 pounds (3 kg) to prevent damage to the tripod.

- **Inspect Regularly:** Periodically check all screws and joints for tightness.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Wireless Remote not pairing.	Remote battery low or off; Bluetooth not enabled on phone; remote not in pairing mode.	Ensure remote is on and battery is charged. Enable Bluetooth on your phone and search for "AB Shutter3". If already paired, try unpairing and re-pairing.
Tripod is unstable.	Legs not properly adjusted; device too heavy; uneven surface.	Adjust the flexible legs to create a stable base. Ensure your device's weight does not exceed 6.6 lbs. Find a more level surface or adjust legs to compensate.
Phone not fitting in clip.	Phone is too wide for the clip.	The phone clip supports devices between 2.16-3.67 inches (5.5-9.4 cm) wide. Ensure your phone is within this range.

SPECIFICATIONS

Feature	Detail
Brand	APEXEL
Model Name	CH-2
Color	Black
Compatible Devices	Smartphones (2.16-3.67 inches wide), Digital Cameras, GoPro
Special Features	Flexible Legs, Portable Design, Wireless Remote Control
Weight Limit	6.6 Pounds (approx. 3 kg)
Tripod Head Type	Ball Heads (360° Swivel)
Minimum Height	10 Inches (approx. 25.4 cm)
Remote Control Range	Up to 10m (30ft)

WARRANTY AND SUPPORT

APEXEL is committed to providing high-quality products and customer satisfaction. If you encounter any problems or have questions regarding your Flexible Phone Tripod, please contact our customer support team. We aim to provide a satisfactory reply within 24 hours.

For support, please visit the APEXEL Store on Amazon or contact us through the platform where you purchased the product.



