

[Manuals.plus](#) /

› [Aqua Laser](#) /

› Aqua Laser Multi Stain Cleaner User Manual

## Aqua Laser 843860

# Aqua Laser Multi Stain Cleaner User Manual

Model: 843860

## INTRODUCTION

---

Thank you for purchasing the Aqua Laser Multi Stain Cleaner. This versatile device is designed for effective cleaning of various surfaces, including carpets, upholstery, and more. With its powerful suction and efficient cleaning mechanism, it helps remove spills and stains quickly and thoroughly. Please read this manual carefully before operating the device to ensure safe and optimal performance.



**Figure 1:** The Aqua Laser Multi Stain Cleaner. This image shows the compact design of the cleaner, featuring a clear top for water tanks, a dark grey base, and a flexible hose neatly stored around the bottom.

## SAFETY INSTRUCTIONS

---

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury:

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not use the appliance with a damaged cord or plug.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Unplug from outlet when not in use and before cleaning.

- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Exercise extreme care when cleaning on stairs.

## SETUP

---

Before first use, ensure all components are present and undamaged. The cleaner comes pre-assembled for ease of use.

1. **Unpacking:** Carefully remove the cleaner and all accessories from the packaging. Retain packaging for future storage or transport.



**Figure 2:** Unpacking the Aqua Laser Spot Cleaner. This image shows a person carefully opening the product box, revealing the cleaner inside.

2. **Fill the Clean Water Tank:** Locate the clean water tank (usually the larger, clear tank). Fill it with clean water and, if desired, a suitable cleaning solution specifically designed for carpet and upholstery cleaners. Do not overfill past the MAX line.
3. **Connect Accessories:** Attach the desired cleaning tool (e.g., upholstery tool, crevice tool) to the end of the hose until it clicks securely into place.
4. **Power Connection:** Unwind the power cord and plug the cleaner into a grounded electrical outlet.

## OPERATING

---

Follow these steps for effective stain removal:

1. **Pre-test:** Before cleaning, always test a small, inconspicuous area of the surface for colorfastness and material compatibility.
2. **Power On:** Press the power button located on the top of the unit to turn on the cleaner.
3. **Apply Solution:** Hold the cleaning tool over the stained area. Press the trigger on the tool handle to spray cleaning solution onto the stain.

4. **Scrub and Extract:** Gently scrub the stained area with the brush on the cleaning tool. Release the trigger and slowly pull the tool over the wet area to suction up the dirty water. Repeat as necessary until the stain is removed and the water being extracted is clear.
5. **Drying:** For best results, make several dry passes over the cleaned area to remove as much moisture as possible. Allow the cleaned area to air dry completely before use.
6. **Versatile Cleaning:** The cleaner can be used on various surfaces. For example, with the appropriate attachment, it can also be used for cleaning hard surfaces like windows.



**Figure 3:** Using the cleaner for window cleaning. This image demonstrates the versatility of the cleaner, showing it being used with a specialized attachment to clean a glass surface, producing cleaning foam.

## MAINTENANCE

---

Regular maintenance ensures the longevity and efficiency of your cleaner.

1. **Emptying Dirty Water Tank:** After each use, or when the dirty water tank reaches its MAX fill line, turn off and unplug the cleaner. Remove the dirty water tank and empty its contents into a sink or drain. Rinse the tank thoroughly with clean water.



**Figure 4:** Emptying the dirty water tank. This image illustrates the process of safely disposing of the collected dirty water from the cleaner's transparent tank into a sink.

2. **Clean Water Tank:** If any cleaning solution remains in the clean water tank, empty it and rinse the tank.
3. **Clean Nozzles and Brushes:** Remove any debris or hair from the suction nozzle and brush attachments. Rinse them under running water.
4. **Hose Cleaning:** Periodically, run clean water through the hose to flush out any residue.
5. **Storage:** Store the cleaner in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure the tanks are empty and dry before storage.

## TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Not plugged in; power outlet not working; power button not pressed.	Ensure plug is securely inserted; test outlet with another device; press power button firmly.
No spray	Clean water tank empty; tank not seated correctly; spray nozzle clogged.	Refill clean water tank; re-seat tank firmly; clean spray nozzle with a small brush.
Poor suction	Dirty water tank full; hose/nozzle clogged; tank lid not sealed properly.	Empty dirty water tank; clear any blockages from hose/nozzle; ensure tank lid is securely closed.
Leaking	Tanks not seated correctly; tank seals damaged; overfilled tanks.	Re-seat tanks firmly; check seals for damage and replace if necessary; do not overfill tanks.

## SPECIFICATIONS

**Model:** 843860

**Brand:** Aqua Laser

**Power:** 350 W

**Suction Power:** 10 KPa

**Cable Length:** 5 m

**ASIN:** B0C85NDS86

**Date First Available:** July 16, 2024

## WARRANTY AND SUPPORT

---

Information regarding specific warranty terms and customer support contact details is not available in this manual. Please refer to the product packaging or the manufacturer's official website for warranty registration and support inquiries.

## OFFICIAL PRODUCT VIDEOS

---

No official product videos from the seller were provided in the product data for inclusion in this manual.

