



Manuals.plus /

› G-Mee /

› G-Mee Connect Pro 64GB Android Phone Instruction Manual

G-Mee G-mee Connect Pro

G-Mee Connect Pro 64GB Android Phone Instruction Manual

Model: G-mee Connect Pro L | Brand: G-Mee

1. INTRODUCTION

The G-Mee Connect Pro is designed to provide a safe, simple, and durable digital experience. This Android 13 smartphone features a 5.72-inch touchscreen, 64GB internal storage (expandable), and a 3000 mAh battery. It is equipped with advanced parental controls, including the G-Mee Co-pilot feature, and is designed without cameras to enhance privacy and prevent social media oversharing.

The device supports 4G network connectivity (T-Mobile locked), Bluetooth 5.0, and NFC for contactless payments. It offers an HD+ 1440x720 display and mono/stereo speakers for an excellent audio-visual experience, allowing users to enjoy music, videos, and educational apps in a controlled environment.

2. WHAT'S IN THE BOX

- G-Mee Connect Pro Smartphone
- USB-C Power Cable (power adapter not included)
- Wired Earbuds
- Clear Protective Case
- Screen Protector (pre-installed)



Image: Contents of the G-Mee Connect Pro package, including the smartphone, charging cable, earbuds, and protective accessories.

3. SETUP

3.1. Initial Power On

Press and hold the power button on the side of the device until the G-Mee logo appears. Follow the on-screen prompts to complete the initial setup process.

3.2. SIM Card Installation

The G-Mee Connect Pro supports up to two nano SIMs. To install, locate the SIM tray on the side of the device. Use the provided SIM ejector tool to open the tray. Insert your nano SIM card(s) into the designated slots, ensuring proper orientation. Close the tray securely.

3.3. Wi-Fi Connection

During the initial setup, you will be prompted to connect to a Wi-Fi network. Select your preferred network and enter the password. The device supports 2.4 GHz and 5 GHz Wi-Fi for stable connectivity.

3.4. G-Mee Co-pilot Setup

The G-Mee Co-pilot feature allows remote management of the device. For detailed setup instructions, please

refer to the official G-Mee website or the quick guide included in the box. You can also find setup videos on the Amazon storefront.

For a quick setup guide, visit: g-mee.com/quick-set-up/

4. OPERATING INSTRUCTIONS

4.1. Basic Navigation

The G-Mee Connect Pro operates on Android 13. Use the touchscreen for navigation. Swipe up from the bottom to access the app drawer, swipe down from the top for quick settings and notifications, and use the navigation buttons (back, home, recent apps) at the bottom of the screen.

4.2. Making Calls and Sending Texts

Use the pre-installed Phone app to make calls and the Messages app to send and receive text messages. Parental controls can be configured via G-Mee Co-pilot to manage contacts and communication settings.

4.3. Using Apps

The device comes with essential pre-installed apps. Additional apps can be downloaded from the Google Play Store. The built-in app locker allows guardians to PIN lock individual applications before providing the device to users, ensuring controlled access.

4.4. Media Consumption

Stream video content in HD+ resolution from popular apps like Disney+, Netflix, and Amazon Video. The mono and stereo speakers provide a good listening experience for music and audiobooks. Parental controls can be used to block in-app videos and manage screen time for media applications.

5. SPECIAL FEATURES

- **G-Mee Co-pilot:** Remotely manage calls, texts, apps, videos (beta for Spotify), and screen time from your own device.
- **No Cameras:** Designed without cameras to prevent photo/video sharing and protect privacy.
- **Fingerprint Scanner:** For secure and convenient device access by authorized users.
- **NFC Capability:** Enables quick and secure contactless payments using mobile wallets like Google Pay.
- **Torch/Flashlight:** A practical built-in flashlight for convenience.

Why Choose G-mee?



Image: Visual representation of the G-Mee Connect Pro's key special features.

5.1. How to use Tap and Pay (NFC)

Your browser does not support the video tag.

Video: This video demonstrates how to utilize the NFC feature for tap and pay functionality on the G-Mee Connect Pro.

5.2. How to Lock Apps Using G-Mee App Locker

Your browser does not support the video tag.

Video: This video provides a step-by-step guide on how to set up and use the G-Mee App Locker to secure individual applications on the device.

5.3. How to Block In-App Videos using G-Mee Co-Pilot (beta)

Your browser does not support the video tag.

Video: This video illustrates the process of blocking in-app videos using the G-Mee Co-Pilot feature, currently in beta.

6. NETWORK COMPATIBILITY

The G-Mee Connect Pro is a T-Mobile locked smartphone. It is compatible with any T-Mobile SIM reseller or provider. The device supports 4G LTE networks.

6.1. Compatible MVNOs (Mobile Virtual Network Operators)

The G-Mee Connect Pro is compatible with the following T-Mobile MVNOs:

- Consumer Cellular
- Gen Mobile
- Good2Go Mobile
- Google Fi
- Hello Mobile
- Metro by T-Mobile
- Mint Mobile
- Reach Mobile

- Red Pocket
- Straight Talk
- TextNow
- Ting
- Ultra Mobile
- Unreal Mobile
- US Mobile
- Wing

✓ Key Features

- Google Apps & Services
- Talk, Text and Track Management
- G-mee Co-Pilot Parental Control, Built-in App locker & Family Link
- NFC, Fingerprint Scanner
- No Cameras

📱 Performance

- 4 GB RAM + 64 GB Storage
- Octa-core 2.0 GHz
- Android 13

🔋 Battery & Connectivity

- 3000 mAh Lithium-Ion
- Wi-Fi 2.4 and 5 GHz | Bluetooth 5.0

What's in the Box?

- G-mee Connect Pro smartphone
- USB-C charging cable
- Wired earbuds
- Clear protector case
- Pre-installed screen protector
- Quick guide



Image: Overview of Mobile Virtual Network Operators (MVNOs) compatible with the G-Mee Connect Pro.

7. MAINTENANCE

To ensure the longevity of your G-Mee Connect Pro, keep the device clean and free from dust and debris. Use a soft, dry cloth for cleaning. Avoid exposing the device to extreme temperatures or moisture. Regularly check for system updates to maintain optimal performance and security.

8. TROUBLESHOOTING

8.1. General Issues

- **Device not responding:** Press and hold the power button for 10-15 seconds to force a restart.
- **Connectivity problems:** Check Wi-Fi and cellular data settings. Ensure your SIM card is properly inserted and activated.
- **App issues:** Try clearing the app's cache and data in Settings > Apps. If the problem persists, uninstall and reinstall the app.

8.2. Performing a System Update

Regular system updates ensure your device has the latest features and security patches. To check for and

install updates:

1. Connect your device to a stable Wi-Fi network.
2. Go to Settings > System > System update.
3. Follow the on-screen instructions to download and install any available updates.

Your browser does not support the video tag.

Video: This video demonstrates how to perform a system update on a G-Mee Play Pro device. The process is similar for the G-Mee Connect Pro.

9. SPECIFICATIONS

Feature	Detail
Model Name	Connect Pro L
Operating System	Android 13.0
Processor	2.0 GHz Octa-core (MediaTek MT8183)
RAM	4 GB
Internal Storage	64 GB (expandable up to 128+ GB via micro-SD)
Display Size	5.72 Inches
Display Resolution	HD+ 1440 x 720
Refresh Rate	60 Hz
Battery Capacity	3000 Milliamp Hours
Connectivity	Bluetooth 5.0, Cellular (4G), NFC, Wi-Fi (2.4 GHz & 5 GHz), USB-C
SIM Support	Dual Nano SIM
Special Features	G-Mee Co-pilot, Fingerprint Scanner, NFC Capability, No Cameras, Torch
Dimensions	5.98 x 2.87 x 0.38 inches
Item Weight	6.3 ounces

10. WARRANTY AND SUPPORT

G-Mee is committed to providing quality customer service and support. For any questions or concerns regarding your G-Mee Connect Pro, please contact the seller directly through the Amazon messaging system.

The product includes a standard manufacturer's warranty. For detailed warranty information and registration, please refer to the quick guide included in your product packaging or visit the official G-Mee website.

Email Support: support@g-mee.com

