

[Manuals.plus](#) /

› [Tribesigns](#) /

› Tribesigns 6-Tier Shoe Cabinet with Doors (Model HOGA-J0232) Instruction Manual

Tribesigns HOGA-J0232

Tribesigns 6-Tier Shoe Cabinet with Doors (Model HOGA-J0232) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Tribesigns 6-Tier Shoe Cabinet with Doors, Model HOGA-J0232. Designed for efficient shoe storage, this cabinet features adjustable shelves and a stylish white and gold finish, making it suitable for various rooms including entryways, hallways, closets, and living rooms.

The cabinet is constructed from premium E0 particle board, ensuring durability and stability. Its design allows for the organization of up to 30 pairs of shoes, with flexible shelving to accommodate different shoe types, from slippers to boots.



Image: The Tribesigns 6-Tier Shoe Cabinet, featuring a white finish with gold accents and doors, positioned in an entryway.

SAFETY INFORMATION

- Always assemble the cabinet according to the provided instructions to ensure structural integrity.
- Keep the cabinet away from heat sources and direct sunlight to prevent material damage.
- Do not place heavy objects on the top shelf that exceed the recommended weight limit of 24 kilograms.
- Keep the doors closed when not in use to prevent accidental tipping or injury.
- Be cautious of sharp edges and pinch points when handling and assembling the cabinet.
- Ensure the cabinet is placed on a level surface to maintain stability.

PACKAGE CONTENTS

Please refer to the included parts list and hardware bag in your product packaging to verify all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

SETUP AND ASSEMBLY

Assembly of the Tribesigns Shoe Cabinet is designed to be straightforward. Follow the step-by-step instructions provided in the separate assembly guide included with your product. Ensure all screws are properly tightened for stability.

Key Assembly Tips:

- Lay out all components on a soft, clean surface to prevent scratches.
- Identify each part using the labels in the assembly guide.
- Do not overtighten screws during initial assembly; tighten fully once the structure is stable.
- For optimal stability, consider having a second person assist with larger components.

Visual Aid: Product Overview

Your browser does not support the video tag.

Video: An overview of the Tribesigns Shoe Cabinet, demonstrating its features and potential placement. This video is provided by the seller.

OPERATING INSTRUCTIONS

Adjustable Shelves:

The Tribesigns Shoe Cabinet features 7 adjustable shelves, allowing you to customize the storage space to fit various shoe sizes and types, including boots. To adjust a shelf:

1. Empty the shelf of all items.
2. Carefully lift the shelf and remove the support pins from the side panels.
3. Reinsert the support pins into the desired holes on the side panels. Ensure they are securely seated.
4. Place the shelf onto the new support pins, ensuring it is level and stable before placing items on it.



Image: Interior of the shoe cabinet displaying multiple shelves, some filled with shoes, highlighting the storage capacity.

Removable Shelf For Different Shoes



Image: A visual representation of how shelves can be removed or adjusted to accommodate taller items like boots.

Door Operation:

The cabinet features two swinging doors with gold metal handles. Gently pull the handles to open the doors. Push the doors firmly until they close completely. The hinges are designed for smooth operation.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage. The cabinet features a water-resistant finish.
- **Hardware:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary to maintain stability.

TROUBLESHOOTING

Wobbly Cabinet:

- Ensure the cabinet is placed on a flat, level surface.
- Check all assembly screws and tighten any that are loose.
- Verify that all panels are correctly aligned according to the assembly instructions.

Doors Not Closing Properly:

- Check for any obstructions inside the cabinet that might be preventing the doors from closing.
- Inspect the hinges for proper alignment and tightness. Adjust if necessary.
- Ensure the cabinet itself is level, as an uneven base can affect door alignment.

Damaged or Missing Parts:

- If you encounter damaged or missing parts during assembly, please contact Tribesigns customer service immediately for assistance.

SPECIFICATIONS

Feature	Detail
Brand	Tribesigns
Model Number	HOGA-J0232
Color	Gold and White
Product Dimensions	14.57"D x 29.53"W x 43.3"H
Material	Engineered Wood
Number of Shelves	7 (Adjustable)
Weight Limit	24 Kilograms (52.9 lbs)
Item Weight	33.9 Kilograms (74.6 lbs)
Special Features	Adjustable, Heavy Duty, Scratch Resistant, Water Resistant, Waterproof
Mounting Type	Freestanding
Assembly Required	Yes




Image: Detailed dimensions of the shoe cabinet, including overall size and internal shelf heights.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Tribesigns website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Tribesigns customer service. They aim to provide a satisfactory response within 24 hours. You can typically find contact information on the manufacturer's website or through your purchase platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question