

## Relaxdays 10045841

# Relaxdays Candle Lanterns Instruction Manual

Model: 10045841

[Introduction](#)   [Overview](#)   [Setup](#)   [Operation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)  
[Safety](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Welcome to your new Relaxdays Candle Lanterns. This manual provides essential instructions for the safe setup, operation, and maintenance of your lanterns. Please read this guide thoroughly before first use and retain it for future reference.

These decorative lanterns are designed to create an inviting atmosphere for various occasions, suitable for both indoor and outdoor use.

## 2. PRODUCT OVERVIEW

The Relaxdays Candle Lanterns are a set of 12 transparent glass candle holders, each featuring a black iron handle. They are designed to hold standard tea lights.

### 2.1. Components

- 12 x Glass Lanterns
- 12 x Iron Handles (pre-attached)



Figure 1: Relaxdays Candle Lantern (example shown with tea light)

### 3. SETUP INSTRUCTIONS

---

#### 3.1. Unpacking

Carefully remove all lanterns from their packaging. Inspect each lantern for any signs of damage. If any damage is found, do not use the product and contact customer support.

#### 3.2. Placement

- **For Table Use:** Place lanterns on a stable, flat, and heat-resistant surface. Ensure they are not near flammable materials such as curtains, paper, or dry foliage.
- **For Hanging:** Use the attached iron handle to hang the lantern from a secure hook or branch. Verify that the hanging point can safely support the weight of the lantern and is stable, preventing accidental falls.

#### 3.3. Inserting Tea Lights

Place one standard tea light into the center of each glass lantern. Ensure the tea light is centered and stable within the lantern.



Figure 2: Lantern prepared for use, hanging with a lit tea light

## 4. OPERATING INSTRUCTIONS

---

### 4.1. Lighting the Candle

Carefully light the wick of the tea light inside the lantern using a long match or lighter. Exercise caution to avoid burns.

### 4.2. Safety Precautions During Operation

- **Never leave burning candles unattended.**
- Keep lanterns with lit candles away from children and pets.
- Ensure adequate ventilation in the area where candles are burning.
- Do not place lanterns near curtains, paper, fabrics, or any other flammable objects.
- Allow lanterns to cool completely before handling or moving them after use.
- Do not place lanterns in direct drafts, which can cause uneven burning or excessive flickering.

### 4.3. Versatile Use

Beyond holding tea lights, these lanterns can also be used for decorative purposes. They can be filled with items such as sand, small stones, shells, or artificial flowers to enhance your decor without a flame.



Figure 3: Lanterns creating ambient lighting for a social setting



Figure 4: Lantern used as a decorative planter

## 5. MAINTENANCE AND CARE

---

### 5.1. Cleaning

- Always allow lanterns to cool completely before attempting to clean them.
- Wipe glass surfaces with a soft, damp cloth. For stubborn residue, a mild glass cleaner can be used.
- Dry the glass thoroughly with a clean, lint-free cloth to prevent water spots.
- The iron handles can be wiped with a dry cloth to remove dust. Avoid abrasive cleaners on the metal.

### 5.2. Storage

When not in use, store the lanterns in a dry, safe place to prevent accidental damage or breakage. Keep them away from areas where they might be knocked over.

## 6. TROUBLESHOOTING

---

- **Candle not lighting:** Ensure the wick is intact and dry. Replace the tea light if the wick is damaged or too short.
- **Lantern appears unstable:** Verify that the surface on which the lantern is placed is flat and stable. If hanging, double-check that the hook or support is secure and properly installed.
- **Glass appears cloudy or stained:** Clean the glass thoroughly with a glass cleaner and dry with a clean, lint-free cloth. For wax residue, gently scrape off cooled wax before cleaning.

## 7. SPECIFICATIONS

- **Model Number:** 10045841
- **Material:** 80% Glass, 20% Iron
- **Color:** Clear/Black
- **Dimensions (Height x Width x Depth):** Approximately 6.5 x 9 x 7.5 cm (2.56 x 3.54 x 2.95 inches)
- **Glass Size (Height x Diameter):** Approximately 6.5 x 7.5 cm (2.56 x 2.95 inches)
- **Opening Diameter:** Approximately 5 cm (1.97 inches)
- **Height with Handle:** Approximately 11.5 cm (4.53 inches)
- **Weight per Lantern:** Approximately 140 g (0.31 lbs)
- **Quantity:** Set of 12 lanterns



Figure 5: Product dimensions

## 8. IMPORTANT SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- Always use extreme caution when handling open flames.

- Keep all flammable materials (e.g., curtains, paper, fabrics, dry plants) well away from the lanterns, especially when candles are lit.
- Do not move lanterns while candles are lit or if the glass is still hot. Allow them to cool completely.
- Ensure lanterns are placed on a stable, non-flammable surface to prevent tipping.
- For outdoor use, protect lanterns from strong winds that could cause flames to spread or lanterns to tip over.
- Never use water to extinguish a candle, as this can cause hot wax to splatter or glass to crack. Use a snuffer or carefully blow out the flame.

## **9. WARRANTY AND SUPPORT**

---

For product support, warranty inquiries, or to report any issues, please contact Relaxdays customer service. Refer to your purchase documentation or the retailer's website for specific warranty terms and contact details.

Please have your model number (10045841) and proof of purchase ready when contacting support.