

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Motorola](#) /

› [Motorola M750-2 Cordless Duo Fixed Line Phone User Manual](#)

Motorola M750-2

Motorola M750-2 Cordless Duo Fixed Line Phone User Manual

Model: M750-2

1. INTRODUCTION

Welcome to the user manual for your Motorola M750-2 Cordless Duo Fixed Line Phone. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new phone system. Please read this manual thoroughly to ensure proper use and to take full advantage of all features.



Image 1: Front view of two Motorola M750-2 cordless phones on their charging bases, showcasing the keypad and display.

2. PACKAGE CONTENTS

Before you begin, please check that your package contains the following items:

- 2 x Motorola M750-2 Cordless Handsets
- 2 x Charging Bases
- 2 x Power Adapters
- 1 x Telephone Line Cord
- 4 x AAA Rechargeable Batteries
- 1 x User Manual (this document)

3. SETUP

3.1. Battery Installation

1. Locate the battery compartment cover on the back of each handset.
2. Gently slide the cover downwards to remove it.
3. Insert the two AAA rechargeable batteries into the compartment, ensuring correct polarity (+ and -).
4. Replace the battery compartment cover by sliding it upwards until it clicks into place.



Image 2: Rear view of the Motorola M750-2 handsets, illustrating the battery compartment.

3.2. Connecting the Base Unit

1. Connect one end of the telephone line cord to the LINE jack on the main charging base.

2. Connect the other end of the telephone line cord to your telephone wall jack.
3. Plug the power adapter into the DC IN jack on the main charging base.
4. Plug the other end of the power adapter into a standard electrical outlet.
5. For the secondary charging base, simply plug its power adapter into a standard electrical outlet. No telephone line connection is needed for the secondary base.

3.3. Charging the Handsets

Place each handset onto its respective charging base. The display on the handset will indicate that it is charging. For optimal battery performance, allow the handsets to charge for at least 15-20 hours before initial use.

4. OPERATING YOUR PHONE

4.1. Making and Receiving Calls

- **To Make a Call:** Pick up the handset or press the **Talk** button. Dial the desired phone number.
- **To Receive a Call:** When the phone rings, pick up the handset or press the **Talk** button.
- **To End a Call:** Place the handset back on the charging base or press the **End** button.

4.2. Integrated Speakerphone

During a call, press the **Speakerphone** button to activate the speakerphone function. Press it again to switch back to the handset earpiece.

4.3. Caller ID

The phone supports Caller ID (subscription required from your telephone service provider). Incoming call information will be displayed on the handset screen.

4.4. 20 Contact Directory

Store frequently called numbers in the phone's directory. Refer to the on-screen menu for instructions on adding, editing, and deleting contacts.

4.5. Reminder Alarm

Set alarms for important events using the handset's menu options. The alarm will sound at the set time.

4.6. DECT 6.0 Technology

Your Motorola M750-2 utilizes DECT 6.0 technology, providing superior sound quality, enhanced security, and extended range compared to older cordless phone technologies.

4.7. Handset Locator

If you misplace a handset, press the **PAGE** button on the main charging base. All registered handsets will ring, helping you locate them.



Image 3: Angled view of the Motorola M750-2 handsets, highlighting the clear display and accessible keypad.

4.8. Eco Zero Emissions Mode

This phone features an Eco Zero Emissions mode, which reduces power consumption and transmission power when the handset is close to the base unit, contributing to energy efficiency.

5. MAINTENANCE

5.1. Cleaning

Wipe the phone and charging bases with a soft, damp cloth. Do not use harsh cleaning agents or abrasive materials, as they may damage the surfaces.

5.2. Battery Care

To prolong battery life, always return the handset to its charging base when not in use. If the phone will not be used for an extended period, remove the batteries.

6. TROUBLESHOOTING

If you encounter any issues with your Motorola M750-2 phone, please refer to the following common problems and solutions:

Problem	Possible Solution
No dial tone	Ensure the telephone line cord is securely connected to both the base unit and the wall jack. Check if the power adapter is properly connected.
Handset not charging	Verify the handset is correctly seated on the charging base. Check the power adapter connection to the base and the electrical outlet. Ensure batteries are inserted with correct polarity.
No Caller ID information	Confirm that you have subscribed to Caller ID service from your telephone service provider.
Poor sound quality/static	Move the handset closer to the base unit. Ensure there are no large metal objects or other electronic devices interfering with the signal.
Handset display is blank	Place the handset on the charging base to charge the batteries. If the issue persists, try replacing the batteries.

7. SPECIFICATIONS

- **Brand:** Motorola
- **Model Number:** M750-2
- **Color:** Black
- **Phone Type:** Cordless
- **Technology:** DECT 6.0
- **Caller ID:** Yes
- **Integrated Speakerphone:** Yes
- **Contact Directory Capacity:** 20 contacts
- **Reminder Alarm:** Yes
- **Multi-line Operation:** Single line operation
- **Batteries:** 4 x AAA rechargeable (included)
- **Power Source:** Battery operated
- **Dimensions (L x W x H):** 17.5 x 8.1 x 16.3 cm (approximate)
- **Weight:** 520 g (approximate)

8. WARRANTY AND SUPPORT

Your Motorola M750-2 Cordless Duo Fixed Line Phone is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or further assistance, please visit the official Motorola support website or contact their

customer service line. Contact information can typically be found on the Motorola website or in the product packaging.

Please retain your proof of purchase for warranty claims.

