

WIKO T10

WIKO T10 Smartphone User Manual

Model: T10

1. INTRODUCTION

The WIKO T10 is a 4G unlocked smartphone designed for everyday use, featuring a large display, long-lasting battery, and ample storage. This manual provides comprehensive instructions for setting up, operating, and maintaining your device.

Key features include:

- **5000 mAh Large Battery:** Provides extended usage times for calls, videos, and audio.
- **6.5" Edgeless Dewdrop Display:** Offers an immersive visual experience with minimal bezels.
- **13 MP Rear Camera:** Captures detailed photos and supports AI beauty algorithms for front camera.
- **64 GB Large Storage:** Ample space for apps, photos, and videos, expandable up to 512GB with a microSD card.
- **Android 11 Go Edition:** Optimized for faster app startup and seamless multitasking.




Image: A visual summary of the WIKO T10's main features, including storage, display size, battery capacity, and camera resolution.

2. WHAT'S IN THE BOX

Verify that all items are present in your product package:

- WIKO T10 Mobile Phone
- WIKO T10 Phone Case
- US Charging Adapter
- USB-C Charge Cable
- User Manual (this document)
- Card removal needle



Image: The WIKO T10 smartphone, showcasing its sleek design and camera module from both front and back perspectives.

3. SETUP

3.1. Inserting SIM Card(s) and MicroSD Card

The WIKO T10 supports dual Nano SIM cards or one Nano SIM and one microSD card for expandable storage up to 512GB.

1. Locate the SIM card tray on the side of the phone.
2. Insert the card removal needle into the small hole next to the tray to eject it.
3. Place your Nano SIM card(s) and/or microSD card into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully push the tray back into the phone until it is flush with the device body.

Up to **512GB** External memory

Makes Memories Last

WIKO T10 a whole new level of visual immersion.
Pioneering technology minimizes the amount of harmful blue light emitted by the screen , keeping your eyes refreshed and raring to go.




Image: An illustration of the WIKO T10's SIM and microSD card tray, demonstrating the correct placement of cards.

3.2. Charging the Battery

Before first use, fully charge your WIKO T10. The device comes with a 5000mAh battery.

1. Connect the USB-C end of the data cable to the charging port at the bottom of your phone.
2. Connect the USB-A end of the data cable to the US Charging Adapter.
3. Plug the charging adapter into a power outlet.
4. The charging indicator will appear on the screen. A full charge takes approximately 42 minutes with the provided 5V2A charger.

Takes Your Charge into Overdrive

WIKO T10 packs a 5000 mAh battery, complemented by smart power saving technology. You can rest assured knowing WIKO T10 has the power to get you through the day!

5000mAh



465h	50h	20h	30h	23h
standby times	Music	videos	Calling	internet browsing

Image: A visual representation of the WIKO T10's 5000mAh battery and its estimated usage times for various activities like standby, music, videos, calling, and internet browsing.

4. OPERATING YOUR DEVICE

4.1. Power On/Off and Restart

- **Power On:** Press and hold the Power button until the WIKO logo appears.
- **Power Off:** Press and hold the Power button, then select "Power off" from the options.
- **Restart:** Press and hold the Power button, then select "Restart" from the options.

4.2. Navigating the Android 11 Go Edition Interface

The WIKO T10 runs on Android 11 Go Edition, optimized for smooth performance on devices with 2GB RAM. This version boosts app startup speed by 15%.

- **Home Screen:** Swipe left or right to access different home screen panels.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.

- **Notifications & Quick Settings:** Swipe down from the top of the screen to view notifications and access quick settings toggles (Wi-Fi, Bluetooth, etc.).



Performs Like a Champ

Android 11 Go Edition boosts app start-up speed by 15% , freeing up RAM , for seamless multi-tasking at all times.

Image: The WIKO T10 displaying its home screen with various app icons, illustrating the clean and efficient Android 11 Go Edition interface.

4.3. Using the Camera

The WIKO T10 features a 13 MP rear camera and a 5 MP front camera with AI beauty algorithms.

1. Open the "Camera" application from your home screen or app drawer.
2. Switch between front and rear cameras using the camera switch icon.
3. Tap on the screen to focus on a specific object.
4. Press the Shutter button to take a photo.
5. Explore different modes like Portrait, Video, or Panorama if available in the camera app.

Capture More, From Landscapes to Selfies



Beyond All
Expectations

13MP
Camera

Image: A close-up view of the WIKO T10's rear camera module, clearly showing the 13MP camera lens.



AI beauty Algorithms

The front camera works with AI beauty algorithms to restore radiance and put your personality on full display.

AI beauty algorithms



13 MP Rear Camera

The 13 MP rear camera captures stunning scenery as it appears in front of you, full to the brim with detail, and teeming with life.

Image: This image demonstrates the AI beauty algorithms feature, which enhances facial features for improved selfies taken with the front camera.

4.4. Display Features


The 6.5-inch HD+ (720x1600) Dewdrop Display offers an 89.3% screen-to-body ratio with razor-thin 2.13mm bezels. It also features pioneering technology to minimize harmful blue light.

- Adjust brightness in Quick Settings or Display settings.
- Enable Eye Comfort Shield (Blue Light Filter) for reduced eye strain.

6.5" Dewdrop Large Display

More Screen , Less Strain

WIKO T10 a whole new level of visual immersion. Pioneering technology minimizes the amount of harmful blue light emitted by the screen , keeping your eyes refreshed and raring to go.



2.13mm razor-thin bezels

89.3% screen-to-body ratio

Image: The WIKO T10's 6.5-inch Dewdrop Display, emphasizing its thin bezels and high screen-to-body ratio for an immersive viewing experience.

5. MAINTENANCE

5.1. General Care

- Keep your phone dry. Moisture can damage the device.
- Avoid extreme temperatures. High or low temperatures can shorten the life of electronic devices.
- Do not drop, knock, or shake the phone. Rough handling can break internal circuit boards.
- Clean the phone with a soft, dry cloth. Do not use harsh chemicals or cleaning solvents.
- Use only approved accessories. Unapproved accessories may damage the phone and void the warranty.

5.2. Battery Optimization

- Close unused applications running in the background.
- Reduce screen brightness or enable adaptive brightness.
- Turn off Wi-Fi, Bluetooth, and GPS when not in use.
- Enable Battery Saver mode in settings for extended battery life.

6. TROUBLESHOOTING

6.1. Phone Not Turning On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

6.2. Apps Crashing or Slow Performance

- Close background applications.
- Clear cache for problematic apps in Settings > Apps & notifications > [App Name] > Storage & cache.
- Restart the phone.
- Ensure you have sufficient free storage space. Delete unnecessary files or apps.

6.3. Network Connectivity Issues

- **No Signal:** Check if your SIM card is properly inserted. Try restarting the phone. Verify network coverage in your area.
- **Wi-Fi Connection Issues:** Restart your Wi-Fi router. Forget the network on your phone and reconnect. Ensure Wi-Fi is enabled.
- **Bluetooth Pairing Issues:** Ensure both devices are in pairing mode and within range. Try restarting Bluetooth on both devices.

7. SPECIFICATIONS

Feature	Detail
Model Name	WIKO T10
Operating System	Android 11.0 (Go Edition)
CPU	MediaTek Helio A22 MT6761 (4*Cortex-A53 2.0GHz, 12nm)
RAM	2 GB
Internal Storage	64 GB
Expandable Storage	Up to 512 GB via microSD card
Screen Size	6.5 Inches
Display Type	LCD, HD+ (720 x 1600) Dewdrop Display
Rear Camera	13 MP Main Camera
Front Camera	5 MP
Battery Capacity	5000 mAh
Charging Power	5V2A (Type-C)
Network	4G LTE
Connectivity	Wi-Fi (2.4GHz & 5GHz 802.11b/g/n), Bluetooth 5.0, GPS (A-GPS, GLONASS, BDS, Galileo)

Feature	Detail
SIM Support	Dual Nano SIM or Single Nano SIM + MicroSD
Audio Jack	3.5 mm
Dimensions	163.94 x 75.79 x 8.97 mm
Weight	192 grams (approx. 6.77 ounces)
Color	Black (also available in Green)
Biometrics	Fingerprint

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your product package or visit the official WIKO website. Keep your proof of purchase for warranty claims.

Manufacturer: WIKO

Date First Available: June 16, 2023

Supported Certifications: CE, FCC

© 2024 WIKO. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Documents - WIKO – T10



[\[pdf\]](#) User Manual
User Manual Wiko SAS W V673 01 2AM86W 2AM86WV67301 w v673
W-V673-01 Gua de Usuario ENHORABUENA Acabas de adquirir tu telefono mvil
WIKO **T10** W-V673-01 . Podrs encontrar una versin completa de las instrucciones de
uso y recomendaciones de seguridad en nuestra pgina web es.wikomobile.com.
Puedes solicitar una versin impresa por correo postal o electrnico ...
lang:es score:25 filesize: 1.3 M page_count: 21 document date: 2022-03-02

Table with 4 columns: Manufacturer, Model, Version, and Status. It lists various Android devices supported by the Edge Family of Products, including manufacturers like Acer, Asus, and Samsung.




Table with 2 columns: UPC and Descripción. It lists various products participating in a promotion, including mobile phones and accessories.

[pdf]

Supported Android Devices Edge Family 2021 10 27.xlsx jwhetstone List of for Oct · 30 160 Page 31 E Boda Eclipse G400M Phone Premier Pro cv3 LGE X4 cv3n LG Q7 cv5a SBI srsltid AfmBOopD SbPvT4G5h04np7N71M2Q130MAxBV9LAR6uQi0yiPXN P F5 northshorecommercialdoor content manuals ||| List of Supported Android Devices for Edge Family of Products Manufacturer 10.or 10.or 10.or 10.or ... Zeus_10_Pro_ROW AURII_AMUSE_4G AURII_FAME AURII ULTRA AXXA_S45_PLUS AXXA S71 PRO Desert2 River1 FAST10 FAST73G PEARL A4 Lite Pearl A4 PLUS PEARL A6 Pearl_A4 SPEED S8 Model Code 10or_D E G G2 4GOOD_L... lang:es score:16 filesize: 441.94 K page_count: 160 document date: 2021-10-27

[1988 Industrial & Professional Video Equipment Buyers' Guide | Lucasey, Panasonic, Hitachi, Amperex, Abekas](#)

Explore the 1988 Industrial and Professional Video Equipment Buyers' Guide by Bill Daniels Co., Inc., featuring products from Lucasey, Panasonic, Hitachi, Amperex, Abekas, and many more. A comprehensive resource for video production and broadcast equipment. lang:en score:15 filesize: 60.54 M page_count: 1228 document date: 2021-10-31

[pdf] Specifications Guide Buyer's Guide Catalog

Broadcast Equipment Buyers Guide 1988 1989 21 10 18 worldradiohistory Archive Catalogs Retailers ||| In the broadcasting game, only one player holds all the marbles. Harris Broadcast Group 217/222-820 ... 0- 6A 189-790-6A 189-T120- 6A Bulk 189-T15- 6B 189- T30- 6B 189- T45- 6B 189-760-6B 189-T90-66 189- T105- 6B 189- T120- 6B 189- T127- 6B Play Time Minutes X1 X2 X3 30 60 90 60 120 180 90 180 ... lang:en score:15 filesize: 72.41 M page_count: 1308 document date: 2021-10-23

[pdf]

Esmeralda Noriega Hernandez Productos participantes con Bonificaciónen Tarjeta de Regalo 00750622734817 TELC OPPO A17 00750188264096 ATT MOTO G71 00750622733876 00750303092393 MOVI 00750622733799 XIAO NOTE 9 PRO k2 59de8c0b 4c7e 4f0d 87e4 28476cceb085 v1 i5 walmartimages dfw 3ccc2d91 aff5 ||| Productos participantes con Bonificacinen Tarjeta de Regalo con Telcel, AT T y Movistar UPC Descri ... ATT OPPO RENO7 00750188264821 ATT REALME C35 00750188264824 ATT REALME C35 00750188264712 ATT WIKO T10 00750188264715 ATT WIKO T10 00750188263259 ATT XIAO 9 64GB 00750188263252 ATT XIAO 9 64GB 007501... lang:de score:13 filesize: 628.33 K page_count: 9 document date: 2023-05-06

[illegible]

[\[pdf\]](#)

[\[pdf\]](#)

Supported Devices Googleapis 2 days ago — SmartWatch 3 tetra Sony D2302 Ericsson Live with Walkman WT19a WT19i E86190C474E7FDA6E489C44325CFEB66F959 storage googleapis support kms prod |||

Retail Branding 3Q 7Eleven A.O.I. ELECTRONICS FACTORY AG Mobile AG Mobile
AG Mobile AMTC AMTC AMTC A ... T004 PadFone Xmini PadFone mini PadFone
mini PadFone-T004 Padfone S Padfone X Padfone mini RTC-700A **T101**TA T50
TF700T TF700T TX201LAF Trans Pad Infinity Transformer 10 TF103CE K00U
K01U_1 K01U_2 ASU...

lang:it score:10 filesize: 762.27 K page_count: 271 document date: 2015-06-05

[illegible]

BRAND	MODEL	REORDER SIZE	REORDER MODEL NAME
30	0-Surf 015120	L2	ba1ncovr
30	0-Surf MT7853C	S	ba1ncovr
ACer	Aspire Switch 12V	L2	ba1ncovr
ACer	Iconia A3	L2	ba1ncovr
ACer	Iconia Tab 10.83-A20	L2	ba1ncovr
ACer	Iconia Tab 12.1	L2	ba1ncovr
ACer	Iconia Tab 12.0 (A3-A20)	L2	ba1ncovr
ACer	Iconia Tab 15 (A3-A20H-42A)	L2	ba1ncovr
ACer	Iconia Tab 15 (A3-A20H-42A-V)	L2	ba1ncovr
ACer	Iconia Tab 15 (A3-A20H-42A-D)	L2	ba1ncovr
ACer	Iconia Tab 10 (A3-A40)	L2	ba1ncovr
ACer	Iconia Tab A510	L2	ba1ncovr
ACer	Iconia Tab A511	L2	ba1ncovr
ACer	Iconia Tab A512	L2	ba1ncovr
ACer	Iconia Tab A701	L2	ba1ncovr
ACer	One 10	L2	ba1ncovr
ACer	Aspire Switch One	L2	ba1ncovr
ACer	Iconia Tab 15 A3-A50	L2	ba1ncovr
ACer	Iconia One 12	L2	ba1ncovr
ACer	Iconia Tab 10.81-A30	L2	ba1ncovr
ACer	Iconia One 8 (81-420)	M2	ba1ncovr
ACer	Iconia One 8 (81-420)	M2	ba1ncovr
ACer	Iconia One 8 (82-630)	M2	ba1ncovr
ACer	Iconia Tab 15	M2	ba1ncovr
ACer	Predator 8	M2	ba1ncovr
ACer	Iconia One 8 (81-455)	M2	ba1ncovr
ACer	Iconia A3-450	S	ba1ncovr
ACer	Iconia One 7 (82-750)	S2	ba1ncovr
ACer	Iconia Tab 7	S2	ba1ncovr

[\[pdf\]](#)

Productlist REBOON brand Eisenschmidt aero Galaxy Note 5 Winter Edition XS4 booncover boonflip
Samsung On7 Pro Page 58 LG G2 Mini LTE XS3 Optimus F6 reboon productList srsItd
AfmBOoobnlRR4m5talI5HzXVNI2UQqoHVBIOAr5fc2CLMr6SKznyD C eisenschmidt media 06 8c b3 |||
BRAND 3Q 3Q Acer Acer Acer Acer Acer Acer Acer Acer Acer Acer Acer Acer Acer Acer
Acer Acer Acer Acer Ace ... uls MP110CTA MPQC106i MPQC124i MPQC96i
MPQC800i Touch X80 X98 Air 3G X98 Air II X98 Air III X98 Pro **T10** X80 Power
P80H T8 P89H X16 Pro XS4 boonflip L2 booncover L2 booncover L2 booncover L2 ...
lang:pt score:9 filesize: 669.1 K page_count: 162 document date: 2018-03-23