

[manuals.plus](#) /

› [MoreJoy](#) /

› [MoreJoy M2 Mini Wireless Earbuds User Manual](#)

## MoreJoy M2 mini

# MoreJoy M2 Mini Wireless Earbuds User Manual

Model: M2 mini

## INTRODUCTION

---

Thank you for choosing the MoreJoy M2 Mini Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.3 connectivity, Hi-Fi stereo sound, and IPX7 waterproofing. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

## WHAT'S IN THE BOX

---

- MoreJoy M2 Mini Wireless Earbuds
- Charging Case
- USB Charging Cable
- User Manual




Image: The MoreJoy M2 Mini Earbuds in their charging case, with the product packaging visible in the background.

## PRODUCT OVERVIEW

---

## Lightweight and portable



Image: A hand holding the MoreJoy M2 Mini charging case, demonstrating its compact and lightweight design, easily fitting into a pocket.

The MoreJoy M2 Mini earbuds are designed for comfort and portability. Each earbud weighs approximately 3g, ensuring a comfortable fit for extended periods. The compact charging case allows for easy storage and on-the-go charging.

### Key Features:

- **Hi-Fi Stereo Sound & Clear Call:** Equipped with 13mm drivers for rich audio and built-in mics with call noise cancellation for clear conversations.
- **One-Step Pairing:** Advanced Bluetooth 5.3 technology ensures a stable, low-latency connection and automatic pairing after initial setup.
- **Smart Touch Control:** Manage music playback, calls, and activate voice assistants directly from the earbuds.
- **IPX7 Waterproof:** Designed to resist splashes, sweat, and rain, making them suitable for workouts and outdoor activities.
- **Ergonomic Design and Lightweight:** Provides a comfortable and secure fit for all-day wear.

## SETUP AND FIRST USE

### 1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the charging case to a USB power source using the provided USB cable.
3. The indicator light on the case will show charging status. A full charge provides up to 35 hours of total playtime (5 hours on a single charge for earbuds, plus 30 hours from the charging case).



Image: The MoreJoy M2 Mini charging case with earbuds inside, illustrating the 35-hour total battery life (5 hours for earbuds, 30 hours from case).

### 2. Pairing with Your Device (Bluetooth 5.3)

The earbuds utilize advanced Bluetooth 5.3 for a quick and stable connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.

2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
3. Search for "Morejoy M2mini" in the list of available devices and select it to connect.
4. Once connected, the earbuds will automatically pair with your device whenever you take them out of the case.

## Upgraded Bluetooth 5.3

One-step pairing , 0.05s low-latency



5.0 — 24Mbit/s

**5.3 — 48Mbit/s**



Image: A smartphone screen showing "Morejoy M2mini" in the Bluetooth device list, next to the open charging case with earbuds, demonstrating the one-step pairing process with Bluetooth 5.3.

## OPERATING INSTRUCTIONS

### Smart Touch Controls

The MoreJoy M2 Mini earbuds feature intuitive touch controls on each earbud.



# Smart Touch Control



Image: A diagram illustrating the various touch controls for the MoreJoy M2 Mini earbuds, including volume adjustment, track skipping, call management, and Siri activation.

## Touch Control Functions

Action	Function
Double Tap (L/R)	Play/Pause music
Triple Tap (L)	Previous Track
Triple Tap (R)	Next Track
Single Tap (L/R)	Answer/Hang Up Call
Press and Hold (L/R) for 2 seconds	Reject Call
Press and Hold (R) for 3 seconds	Volume Up

Action	Function
Press and Hold (L) for 3 seconds	Volume Down
Press and Hold (L/R) for 3 seconds	Activate Voice Assistant (Siri/Google Assistant)

## MAINTENANCE AND CARE

### Water Resistance (IPX7)



Image: The MoreJoy M2 Mini charging case with water droplets, illustrating its IPX7 waterproof and sweatproof capabilities. The MoreJoy M2 Mini earbuds are rated IPX7 waterproof, meaning they are resistant to splashes, sweat, and rain. This makes them ideal for workouts and outdoor activities.

- Do not submerge the earbuds or charging case in water for extended periods.
- Ensure the charging port is dry before charging to prevent damage.

## Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Gently clean the charging contacts on both the earbuds and the case to ensure proper charging.

## TROUBLESHOOTING

### Common Issues and Solutions

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off, earbuds not in pairing mode, device already connected to another earbud.	<ul style="list-style-type: none"><li>◦ Ensure Bluetooth is enabled on your device.</li><li>◦ Place earbuds back in case, close, then open to re-enter pairing mode.</li><li>◦ Forget "Morejoy M2mini" from your device's Bluetooth list and re-pair.</li><li>◦ Ensure earbuds are charged.</li></ul>
No sound or low volume	Volume too low on device/earbuds, earbuds not properly seated, dirty speaker mesh.	<ul style="list-style-type: none"><li>◦ Increase volume on both your device and the earbuds using touch controls.</li><li>◦ Ensure earbuds are securely placed in your ears.</li><li>◦ Clean the speaker mesh gently.</li></ul>
Earbuds not charging	Charging cable/port issue, dirty charging contacts, case battery low.	<ul style="list-style-type: none"><li>◦ Check if the charging cable is securely connected.</li><li>◦ Try a different USB port or power adapter.</li><li>◦ Clean the charging contacts on both earbuds and case.</li><li>◦ Ensure the charging case itself has sufficient battery.</li></ul>
Call quality issues	Microphone obstruction, weak signal, environmental noise.	<ul style="list-style-type: none"><li>◦ Ensure the microphone area on the earbuds is not covered.</li><li>◦ Move closer to your connected device.</li><li>◦ Try making a call in a quieter environment.</li></ul>

## SPECIFICATIONS



MoreJoy M2 Mini Earbuds Specifications

Feature	Detail
Model Name	M2 mini
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Size	13 Millimeters
Battery Life	35 Hours (with charging case)
Water Resistance Level	IPX7
Control Method	Touch, Voice (Siri, Google Assistant)
Ear Placement	In Ear
Item Weight	3.17 ounces (total)
Product Dimensions	0.39 x 0.39 x 0.39 inches (approximate for earbuds)
Material	Silicone, Plastic, Metal
Manufacturer	MoreJoy

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official MoreJoy website or contact their customer service directly.

A digital version of this user manual is available for download:[MoreJoy M2 Mini User Manual \(PDF\)](#).