

[manuals.plus](#) /

› [Mcbazel](#) /

› [Mcbazel Foldable Bluetooth Keyboard Instruction Manual](#)

Mcbazel B033 Plus

Mcbazel Foldable Bluetooth Keyboard Instruction Manual

Model: B033 Plus

1. INTRODUCTION

Thank you for choosing the Mcbazel Foldable Bluetooth Keyboard. This ultra-thin, portable wireless keyboard with a numeric keypad is designed for seamless compatibility with Mac, iOS, Android, and Windows devices. Its compact and lightweight design makes it ideal for travel, business trips, and everyday use. This manual will guide you through the setup, operation, and maintenance of your new keyboard.



Image 1.1: The Mcbazel Foldable Bluetooth Keyboard shown in both its compact, folded state and fully extended for use. This illustrates its portability and full keyboard layout.

2. KEY FEATURES

- **Stable Bluetooth 5.0 Connection:** Supports up to 3 devices simultaneously with a stable connection and quick response within 10 meters.
- **Precise Typing Experience:** Standard keyboard-like design with quiet keys for accurate and comfortable typing.
- **Innovative Touchpad:** Features a redesigned touchpad with press function, mimicking a laptop's touchpad for mouse-free control. Compatible with iOS for drag-and-drop functionality (double-tap and hold).
- **Rechargeable Battery:** Built-in low-power consumption battery with 2-3 hours charging time and approximately 560 hours standby time. Features a convenient Type-C charging input.
- **Compact & Portable Design:** Folds to approximately 15 x 9.7 x 1.3 cm, making it easy to carry anywhere.



Image 2.1: Visual representation of the keyboard's wide compatibility, supporting Android, Windows, and iOS systems. It highlights the QWERTY layout and notes that the touchpad is not compatible with iOS versions below 13.

Bluetooth 5.0 Connection

Connect up to 3 devices simultaneously



Image 2.2: Diagram illustrating the Bluetooth 5.0 connection, showing the ability to connect up to 3 devices simultaneously (iOS, Android, Windows) and how to switch between them using Fn+Q/W/E.

3. SETUP

3.1 Parts Overview



Image 3.1: Detailed view of the keyboard's components, including the Charging Indicator Light, Bluetooth Indicator Light, Caps Lock Light, Touchpad, Left Button, Right Button, Power Switch, Bluetooth Connect button, and Type-C Charging Interface.

3.2 Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided Type-C USB cable to the keyboard's charging port and the other end to a USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 2-3 hours.



Built-in Rechargeable Battery

Type-C charging port is convenient for charging



140 mAh
Battery Capacity



2-3 Hours
Charging Time



48 Hours
Working Time



560 Hours
Standby Time

Image 3.2: Illustration of the keyboard's built-in rechargeable battery, highlighting the convenient Type-C charging port and providing battery specifications: 140 mAh capacity, 2-3 hours charging time, 48 hours working time, and 560 hours standby time.

3.3 Bluetooth Pairing

1. Ensure the keyboard is charged.
2. Turn on the keyboard by sliding the Power Switch to the 'ON' position.
3. Press the 'Bluetooth Connect' button (usually located near the power switch) to put the keyboard into pairing mode. The Bluetooth indicator light will flash.
4. On your device (smartphone, tablet, laptop), go to Bluetooth settings and search for available devices.
5. Select 'Mcbazel Keyboard' or a similar name from the list of found devices.
6. If prompted, enter the pairing code displayed on your device using the keyboard and press Enter.
7. Once connected, the Bluetooth indicator light will stop flashing and remain solid or turn off, depending on the model. The keyboard will automatically connect to the last paired device upon power-on.

Note: For desktop and laptop computers without built-in Bluetooth, a third-party Bluetooth adapter (not included) is required.

3.4 Switching Between Systems

The keyboard supports iOS, Android, and Windows systems. To switch between operating systems for optimal key mapping:

- For **iOS**: Press **Fn + Q**
- For **Android**: Press **Fn + W**
- For **Windows**: Press **Fn + E**

4. OPERATING INSTRUCTIONS

4.1 General Typing

Simply unfold the keyboard to its full size. The standard QWERTY layout allows for comfortable and efficient typing. The quiet keys minimize noise, allowing you to focus on your work.

4.2 Using the Touchpad

The integrated touchpad functions similarly to a laptop touchpad, allowing you to control your device without a separate mouse. It supports standard gestures.



Image 4.1: Close-up of the high-sensitive touchpad, indicating the areas for left and right mouse button clicks, enabling

easy and efficient device control without a mouse.

- **Clicking:** Tap the touchpad surface or use the dedicated left/right buttons.
- **Dragging Files (iOS compatible):** Double-tap and hold on a file, then drag your finger to move it.

Important Note: The touchpad function is **not compatible with iOS systems below iOS 13**. Ensure your iOS device is updated to iOS 13 or higher for touchpad functionality.

4.3 Power Saving Mode

To conserve power, the keyboard will enter sleep mode if left unused for 10 minutes. To wake it up, simply press any key.

5. MAINTENANCE

- Keep the keyboard clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Do not expose the keyboard to extreme temperatures, direct sunlight, or excessive moisture.
- Store the keyboard in its folded state when not in use to protect the keys and touchpad.
- Charge the keyboard regularly to maintain battery health, even if not used frequently.

6. TROUBLESHOOTING

- **Keyboard not connecting:**
 - Ensure the keyboard is charged and powered on.
 - Make sure Bluetooth is enabled on your device.
 - Try unpairing and re-pairing the keyboard with your device.
 - Ensure you are within the 10-meter Bluetooth range.
- **Touchpad not working (iOS):**
 - Verify your iOS device is running iOS 13 or higher.
 - Check if the touchpad is activated in your iOS settings: Go to "Settings" > "Accessibility" > "Touch" > "AssistiveTouch" > "On".
- **Keyboard enters sleep mode too quickly:**
 - This is a power-saving feature. Press any key to wake the keyboard. This behavior is normal.
- **Keyboard layout issues (e.g., @ symbol):**
 - This wireless keyboard has a traditional English layout. Ensure your device's input language settings match the keyboard's layout (e.g., US English) to avoid conflicts with other regional layouts.

7. SPECIFICATIONS

Feature	Specification
Brand	Mcbazel

Model	B033 Plus
Connectivity Technology	Bluetooth 5.0
Compatible Devices	Smartphone, Tablet, Laptop, Desktop
Operating Systems	iOS, Android, Windows
Special Features	Ergonomic, Foldable, Rechargeable, Touchpad
Power Source	Battery Powered (Built-in)
Battery Capacity	140 mAh
Charging Time	2-3 Hours
Standby Time	Approx. 560 Hours
Working Time	Approx. 48 Hours
Charging Interface	Type-C USB
Folded Dimensions	Approx. 15.2 x 9.8 x 1.3 cm (5.9 x 3.8 x 0.5 inches)
Unfolded Dimensions	Approx. 20 x 10.5 x 1.7 cm
Weight	260 g
Material Type	Plastic
Keyboard Language	English

Foldable Design & Portable

Fold it into small size and take to anywhere



Folding Size




Image 7.1: The keyboard in its folded state, showing its compact dimensions of 15.2 cm (5.9 in) length, 9.8 cm (3.8 in) width, and 1.3 cm (0.5 in) height, emphasizing its portability.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Mcbazel customer service directly. Keep your purchase receipt for warranty claims.