

[Manuals.plus](#) /

› [MEIDI](#) /

› MEIDI Smart Scent Air Machine for Home - Waterless Essential Oil Diffuser User Manual

MEIDI B0C8H61M55

MEIDI Smart Scent Air Machine User Manual

Model: B0C8H61M55 | Brand: MEIDI

INTRODUCTION

Thank you for choosing the MEIDI Smart Scent Air Machine. This waterless essential oil diffuser utilizes advanced two-fluid atomization technology to disperse your favorite essential oils into a cool mist, creating a tranquil and fragrant atmosphere without the need for water. Its smart app control and versatile design make it a perfect addition to any home, office, hotel, or spa environment.

This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new diffuser.



The MEIDI Smart Scent Air Machine, showcasing its sleek design and app connectivity.

PRODUCT FEATURES

- **Waterless Essential Oil Diffusion:** Utilizes revolutionary two-fluid atomization technology to disperse essential oils without water, eliminating the need for frequent refills.

- **App Control and Smart Timer:** Full control via a wireless app, allowing for advanced scheduling, specific spray times, fog intensity adjustment, and smart timers.
- **Wide Coverage:** Gracefully envelops spaces up to an impressive 3000 sq ft in a 360° symphony of delightful scents.
- **Exquisite Design:** Features an outer circle and inner square design with an elegant piano paint texture, balancing squareness and roundness.
- **Versatile Power Options:** Can be powered via Type-C cable or 4 alkaline batteries (included), offering portability and flexibility.
- **Desktop or Hang-up Design:** Equipped with wall panels for flexible placement on a desk or wall-mounting to suit space requirements.
- **Whisper Quiet Operation:** Noise-reducing design ensures a peaceful spraying process, akin to the comforting ticking of a watch.

TRANSFORM YOUR SPACE

Create a captivating atmosphere with pure essential oils



Type-C
Battery



Waterless
Diffuser



APP
Control



Pets&Kids
Friendly



Exquisite
Design



Cool
Mist



Key features of the MEIDI Smart Scent Air Machine, including Type-C charging, waterless operation, app control, pet & kid-friendly design, exquisite aesthetics, and cool mist.

PACKAGE CONTENTS

Please check the box for the following items:

- MEIDI Smart Scent Air Machine (Diffuser Unit)
- Type-C USB Charging Cable

- 4 x AA Alkaline Batteries
- Wall Mounting Back Plate
- Adhesive Strips for Wall Mounting
- Hardware (Screws and Anchors) for Wall Mounting
- User Manual (This document)

SETUP AND INSTALLATION





1. Inserting Batteries and Essential Oil


1. Gently open the front cover of the diffuser.
2. Locate the battery compartment and insert the 4 AA alkaline batteries, ensuring correct polarity.
3. Unscrew the cap from your essential oil bottle and carefully screw it onto the nozzle of the diffuser.
4. Insert the essential oil bottle with the attached nozzle into its designated slot within the diffuser.
5. Close the front cover securely.

2. Wall Mounting (Optional)


The diffuser can be wall-mounted for space-saving and aesthetic purposes. Follow these steps:

1. Remove the wall mounting back plate from the diffuser unit.
2. Choose your desired wall location. You can use the provided adhesive strips for a temporary hold or drill holes for a more permanent fixture.
3. If using adhesive: Apply the 3M adhesive strips to the back of the wall mounting board as shown in the diagram. Stick the hanging board to the wall, ensuring it is level. Wait 24 hours before hanging the product to allow the adhesive to cure.
4. If drilling: Mark the screw positions on the wall using the back plate as a template. Drill 3 holes of 5mm diameter at the marked positions. Insert the plastic expanding nails (anchors) into the drilled holes, then secure the back plate to the wall using the screws.
5. Once the back plate is securely installed, align the diffuser unit with the back plate and slide it into place until it clicks.
6. For added security, it is suggested to use the anti-theft screws to fix the diffuser to the back plate after drilling holes in the wall surface.


				
1 Apply 3M glue to the back of the wall hangingboard. (There have corresponding position where shown on the diagram)	2 Stick the hanging board to the wall, and keep it level	3 Wait 24 hours before hanging the product	4 Fill the essential oil bottle and place it in the diffuser	5 Close the cover to complete the installation




1 Remove the wall panel and mark the screw




2 Drill 3 holes of 5mm diameter at the marked position and hang the wall plate with plastic expanding nails and screws




3 Hang the product



4 It is suggested to use anti-theft screws to fix the screws in the anti-theft holes after drilling holes in the wall surface



5 Put the essential oil bottle into the difuser at the designated positin



6 Close the cover to complete the installation

Step-by-step guide for wall mounting using screws and optional anti-theft screws.

Your browser does not support the video tag.

Official product video demonstrating the setup, oil refill, and wall-mounting process of the MEIDI Smart Scent Air Machine.

OPERATING INSTRUCTIONS

1. App Download and Connection

1. Scan the QR code located inside the diffuser's front cover (for iOS or Android) to download the companion app.
2. Follow the in-app instructions to pair your smartphone with the MEIDI Smart Scent Air Machine via Bluetooth.
3. Ensure Bluetooth is enabled on your device and the diffuser is powered on.

2. Using the App

The app provides comprehensive control over your diffuser:

- **Manual Spray:** Instantly activate a spray of fragrance.
- **Scheduling:** Set specific working plans, including start and end times, and days of the week for operation.
- **Spray Interval:** Adjust the frequency of sprays (e.g., every 15 minutes, 30 minutes).
- **Fog Intensity:** Control the strength of the fragrance output.
- **Smart Timers:** Utilize pre-set or custom timers for automated operation.

SMART WIRELESS APP CONTROL

Elevate the sense of atmosphere to a whole new level



The smart wireless app provides comprehensive control over the diffuser's settings and scheduling.

MAINTENANCE

1. Refilling Essential Oil

When the essential oil level is low, follow the steps for 'Inserting Batteries and Essential Oil' to replace or refill the bottle. Ensure the diffuser is turned off before refilling.

2. Cleaning

To maintain optimal performance and prevent oil residue buildup:

- Wipe the exterior of the diffuser regularly with a soft, dry cloth.
- If changing essential oil types, it is recommended to clean the nozzle and the inside of the oil bottle with a small amount of rubbing alcohol to prevent mixing scents.
- Do not submerge the diffuser in water or use harsh chemical cleaners.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Diffuser not spraying/no mist.	Low or empty essential oil. Batteries depleted or incorrectly inserted. Nozzle clogged.	Refill essential oil. Replace batteries or check polarity. Clean the nozzle with rubbing alcohol.
App not connecting to diffuser.	Bluetooth is off. Diffuser is out of range. App issue.	Ensure Bluetooth is on. Move closer to the diffuser. Restart the app or reinstall it. Check the manual for the 6-digit PIN if prompted.
Weak scent output.	Low oil level. Low intensity setting. Large room size.	Refill oil. Increase fog intensity in the app. Consider using multiple diffusers for very large spaces.
Diffuser is leaking oil.	Oil bottle not securely attached. Damaged seal.	Ensure the essential oil bottle is screwed tightly onto the nozzle and properly seated in the diffuser. Inspect the seal for damage.

If problems persist, please contact customer support.

TECHNICAL SPECIFICATIONS

Specification	Detail
Brand	MEIDI
Model	B0C8H61M55
Color	Black
Recommended Uses	Office, Home
Material	Plastic
Special Features	Portable, Cool Mist, Cordless, App Control, Wall-Mountable
Power Source	Battery Powered (4x AA Alkaline, included) / Type-C USB
Product Dimensions	5.9"L x 2.5"W x 5.9"H
Coverage Area	Up to 3000 Sq Ft

Specification	Detail
Wattage	12 watts
Item Weight	2.07 pounds
Auto Shutoff	No

SAFETY INFORMATION

- Keep the diffuser out of reach of children and pets.
- Use only 100% pure essential oils. Do not use synthetic oils or fragrances that are not designed for diffusers.
- Do not block the mist outlet.
- Ensure proper ventilation in the room where the diffuser is used.
- Avoid direct contact with the mist, especially for prolonged periods.
- Do not disassemble or attempt to repair the unit yourself. Contact qualified personnel for service.
- If using battery power, ensure batteries are inserted correctly and replace all batteries at the same time. Do not mix old and new batteries or different types of batteries.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not available in the provided data. Please refer to the product packaging or the manufacturer's official website for warranty details and contact information for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question