

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SoBuy](#) /
- › [SoBuy FSR16-HG Shoe Storage Bench with Cushion, 3-Tier, White+Grey User Manual](#)

SoBuy FSR16-HG

SoBuy FSR16-HG Shoe Storage Bench with Cushion

Model: FSR16-HG | Brand: SoBuy

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your SoBuy FSR16-HG Shoe Storage Bench. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The SoBuy FSR16-HG shoe storage bench, white with a grey cushion, positioned in an entryway. A straw hat rests on the cushion, and a striped shirt hangs on a wall hook above.

SAFETY INFORMATION

Warning: This product is intended for domestic use only. To prevent injury or damage, adhere to the following safety guidelines:

- Do not exceed the maximum load capacity of **120 kg (264 lbs)** on the bench.
- Carefully follow all assembly instructions to ensure the stability and safety of the product.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the bench.
- Place the bench on a flat, stable surface.

PRODUCT OVERVIEW

The SoBuy FSR16-HG is a compact and functional shoe storage bench designed for entryways, hallways, or dressing rooms. It features a comfortable seating cushion and a multi-tier shoe storage compartment.

Key Features:

- **Compact Design:** Optimal dimensions (60x30x46cm) for small spaces.
- **3-Tier Shoe Storage:** A lower compartment provides three levels for shoe organization.
- **Hidden Storage:** An integrated compartment under the cushion offers discreet storage for small items.
- **Comfortable Seating:** Padded cushion made from linen-effect polyester fabric and foam for comfortable use.
- **Durable Construction:** Made from MDF and particle board, reinforced with metal and plastic components for longevity.



Image: Technical drawing showing the dimensions of the SoBuy FSR16-HG shoe storage bench: 60cm width, 30cm depth, 46cm height, with cushion thickness of 3cm.



Image: A detailed view of the internal 3-tier shoe storage mechanism, showing how shoes are organized within the pull-down compartment.

SETUP AND ASSEMBLY

Your SoBuy FSR16-HG Shoe Storage Bench requires assembly. Detailed assembly instructions, including a list of all parts and hardware, are provided in the package. Please ensure all components are present and undamaged before starting assembly.

General Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Frame:** Follow the step-by-step diagrams to connect the main frame pieces using the provided hardware (screws, dowels, etc.).
4. **Install Shoe Compartment:** Assemble and install the 3-tier shoe storage mechanism into the main frame.
5. **Attach Back Panel:** Secure the back panel to the assembled frame.
6. **Place Cushion:** Position the comfortable cushion on top of the bench.
7. **Final Check:** Ensure all connections are tight and the bench is stable.

If you encounter any difficulties or missing parts, please refer to the "Warranty and Support" section for assistance.

OPERATING INSTRUCTIONS

Using the Shoe Storage:

- To access the shoe compartment, gently pull the handle on the front panel. The panel will tilt forward, revealing the three tiers for shoe storage.
- Arrange shoes neatly on each tier. Note that larger shoe sizes or high-top shoes may require adjusting the position or removing a tier for optimal fit.
- To close, push the panel back into its upright position until it clicks securely.



Image: The SoBuy FSR16-HG shoe storage bench with its front panel tilted open, displaying multiple pairs of shoes neatly arranged on the internal tiers.

Using the Seating Cushion:

- The top cushion provides a comfortable surface for sitting while putting on or taking off shoes.
- The cushion is designed to rest on top of the bench. For added stability, anti-slip pads can be placed underneath the cushion if it tends to slide.



Image: A close-up view of the grey linen-effect fabric cushion, highlighting its texture and comfortable appearance on the bench top.

Using the Hidden Storage:

- Lift the seating cushion to reveal a hidden compartment underneath.
- This space is ideal for storing small items such as keys, gloves, shoe care products, or other entryway essentials.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your shoe storage bench.

- **Cleaning the Frame:** Wipe the wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Dry immediately with a clean cloth.
- **Cleaning the Cushion:** Spot clean the fabric cushion with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.

- **Avoid Moisture:** Protect the bench from excessive moisture and direct sunlight to prevent warping or discoloration.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bench is wobbly or unstable.	Loose fasteners; uneven floor.	Check and tighten all screws. Ensure the bench is on a level surface.
Shoe compartment does not open/close smoothly.	Obstruction; misaligned parts; worn mechanism.	Check for any items blocking the mechanism. Verify assembly of the compartment. Contact support if mechanism is faulty.
Cushion slides off the bench.	No anti-slip feature.	Apply anti-slip pads (not included) to the underside of the cushion.
Shoes do not fit in the compartment.	Shoes are too large (length/height).	The compartment is designed for standard shoe sizes. For larger shoes or boots, consider removing one of the internal tiers if possible, or storing them elsewhere.
Missing or damaged parts during assembly.	Packaging error; shipping damage.	Do not proceed with assembly. Contact SoBuy customer support immediately for replacement parts.

SPECIFICATIONS

Feature	Detail
Model Number	FSR16-HG
Brand	SoBuy
Color	White + Grey
Product Dimensions (L x W x H)	60 cm x 30 cm x 46 cm
Item Weight	11.8 Kilograms
Maximum Load Capacity	120 kg
Materials	MDF, Particle Board, Polypropylene, Linen-effect Polyester Fabric, Foam, Metal/Plastic components
Style	Scandinavian
Shoe Storage Tiers	3 levels
Seat Height	46 cm

WARRANTY AND SUPPORT

SoBuy is committed to providing high-quality products. If you encounter any issues or require assistance, please contact our customer support team.

Contacting Support:

- For missing parts, damaged components, or assembly difficulties, please reach out to SoBuy customer service.
- If you are not satisfied with your product or if there is a problem, you may be eligible for a free return voucher. Please contact us for details.
- You can often find additional support and contact information by scanning the QR code on the product packaging or visiting the official SoBuy website.

Please have your model number (FSR16-HG) and purchase details ready when contacting support.