Acer X32 Fpbmiiiiphuzx

Acer Predator X32 32-inch 4K UHD Gaming Monitor User Manual

Model: X32 Fpbmiiiiphuzx

Introduction

This manual provides essential information for setting up, operating, and maintaining your Acer Predator X32 32-inch 4K UHD Gaming Monitor. Please read this manual thoroughly before using the product to ensure proper functionality and to prevent damage.



Figure 1: Front view of the Acer Predator X32 32-inch 4K UHD Gaming Monitor, showcasing its display and sleek design.

Safety Information

Observe the following safety precautions to ensure safe operation and to prevent damage to your monitor:

- Always place the monitor on a stable, level surface to prevent it from falling.
- Do not block ventilation openings on the monitor. Adequate airflow is essential to prevent overheating.
- Use only the power adapter and cables supplied with the monitor. Using unauthorized accessories may cause damage or fire.
- Keep the monitor away from water, excessive moisture, and high humidity environments.
- Unplug the monitor from the power outlet before cleaning or if it will be unused for an extended period.
- Do not attempt to open or service the monitor yourself. Refer all servicing to qualified service personnel.
- Avoid exposing the monitor to direct sunlight or extreme temperatures.

Package Contents

Before proceeding with setup, please verify that all the following items are included in your package:

- Acer Predator X32 Monitor

- Monitor Stand (Base and Neck)
- Power Cable
- HDMI Cable
- DisplayPort Cable
- USB Upstream Cable
- User Manual / Quick Start Guide

Setup

1. Assembling the Monitor Stand

1. Carefully remove the monitor and stand components from the packaging, placing them on a soft, flat surface to prevent scratches.
2. Attach the stand base to the stand neck, securing it firmly with the provided screw.
3. Align the assembled stand with the mounting slot on the back of the monitor and push until it clicks into place. Ensure the stand is securely fastened to the monitor.



Figure 2: Acer Predator X32 Monitor with its stand fully assembled, shown from a slight angle to highlight the display and the sturdy base. This image illustrates the monitor's overall appearance once set up.

2. Connecting Cables

1. **Power Connection:** Connect the power cable to the monitor's power input, then plug the other end into a grounded electrical outlet.
2. **Video Connection:** Connect one end of the HDMI or DisplayPort cable to the corresponding port on your computer's graphics card and the other end to an available HDMI or DisplayPort on the monitor. For optimal performance, a DisplayPort connection is recommended.
3. **USB Connection (Optional):** If your monitor has USB ports, connect the USB upstream cable from your computer to the monitor to enable the monitor's integrated USB hub functionality.



Figure 3: The rear panel of the Acer Predator X32 Monitor, displaying the arrangement of its input ports, including HDMI, DisplayPort, and power connections. This view is crucial for understanding where to connect the necessary cables.

3. Initial Power On

After connecting all necessary cables, press the power button, typically located on the back or bottom right of the monitor, to turn it on. The power indicator light will illuminate, and the monitor will attempt to detect an input signal.

Operating the Monitor

1. On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Access it using the joystick or dedicated buttons typically located on

the back or bottom right of the monitor.

- **Navigation:** Use the joystick (if present) to move through menu options and press it to select. Alternatively, use dedicated buttons for navigation and selection.
- **Exit:** Select the 'Exit' option or press the designated 'Exit' button to close the OSD menu.





Figure 4: A side profile of the Acer Predator X32 Monitor, illustrating its slim design and the typical placement of control buttons or a joystick on the rear-right side for OSD navigation.

2. Adjusting Display Settings

Key settings to adjust for optimal viewing and gaming experience:

- **Brightness/Contrast:** Adjust these settings to suit your ambient lighting conditions and personal preference.
- **Color Settings:** Fine-tune color temperature, gamma, and saturation for accurate color reproduction.
- **Refresh Rate:** Ensure your operating system and graphics card are configured to utilize the monitor's maximum refresh rate (up to 165Hz) for the smoothest visual experience.
- **Response Time:** Adjust the GTG (Gray-to-Gray) response time setting to minimize motion blur and ghosting in fast-paced content.
- **Input Source:** Manually select the active input (e.g., HDMI 1, HDMI 2, DisplayPort) if the monitor does not automatically detect the signal.

Maintenance

Cleaning the Monitor

- Always unplug the monitor from the power outlet before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a non-abrasive, anti-static screen cleaner.
- Do not spray cleaner directly onto the screen. Apply it to the cloth first.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the screen and casing.

Storage

When storing the monitor for an extended period, disconnect all cables and pack it in its original packaging or a suitable protective container to prevent dust accumulation and physical damage.

Troubleshooting

If you encounter issues with your monitor, refer to the following common problems and solutions:

- **No Power:**
  - Ensure the power cable is securely connected to both the monitor and a functional power outlet.
  - Verify the power outlet is working by plugging in another device.
  - Check the monitor's power button to ensure it is pressed.

- **No Signal:**
  - Confirm the video cable (HDMI/DisplayPort) is securely connected to both the monitor and the computer's graphics card.
  - Select the correct input source via the monitor's OSD menu.
  - Ensure your computer is powered on and not in sleep or standby mode.
  - Test with a different video cable or a different port on your graphics card/monitor if available.
- **Image is Distorted or Unclear:**
  - Adjust the resolution and refresh rate settings on your computer to match the monitor's native resolution (3840x2160) and desired refresh rate (up to 165Hz).
  - Reset the OSD settings to factory defaults.
- **Dead Pixels:**
  - A small number of bright or dark pixels are inherent to LCD technology and are generally not considered a defect. If the number of non-functioning pixels exceeds manufacturer specifications, contact support.

Specifications

Feature	Specification
Model Number	X32 Fpbmiiiphuzx
Brand	Acer
Screen Size	32 Inches
Panel Type	IPS
Resolution	3840 x 2160 (4K UHD)
Refresh Rate	165Hz
Response Time	1ms GTG
Brightness	400 nits
Aspect Ratio	16:9
Screen Surface	Glossy
Product Dimensions	174 x 28.63 x 25.1 inches
Item Weight	22.7 pounds

Warranty and Support

This Acer Predator X32 monitor is a renewed product. Please refer to the specific warranty terms and conditions provided by the seller, Acer Recertified Store, at the time of purchase. Renewed products typically come with a limited warranty.
For technical assistance, troubleshooting beyond this manual, or to inquire about warranty claims, please contact Acer customer support or the seller directly. You can usually find contact information on the Acer official website or within your purchase documentation.

© 2023 Acer Inc. All rights reserved. Information in this document is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question