

Philips Sonicare HX3826/23

Philips Sonicare Cordless Power Flosser 3000 User Manual

Model: HX3826/23

INTRODUCTION

This manual provides instructions for the safe and effective use of your Philips Sonicare Cordless Power Flosser 3000. Please read this manual thoroughly before first use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, burns, fire, or injury:

- Do not use the device with damaged cords or while charging.
- Keep the device away from water when not in use.
- This product is not intended for use by individuals with certain medical conditions without consulting a healthcare professional.
- Do not share nozzles for hygiene reasons.
- Clean and maintain the device as instructed in this manual.

PRODUCT OVERVIEW

The Philips Sonicare Cordless Power Flosser 3000 is designed for effective interdental cleaning and gum health improvement. Key features include:

- **Quad Stream Technology:** Delivers four wide streams of water for comprehensive cleaning.
- **360-Degree Rotating Tip:** Allows access to all areas of the mouth.
- **Two Flossing Modes:** Clean and Deep Clean.
- **Three Pressure Settings:** For customized cleaning intensity.
- **Cordless Design:** Lightweight and portable with a 14-day battery life.
- **8 fl oz Water Reservoir:** Sufficient for a 60-second cleaning session.
- **IPX7 Waterproof:** Suitable for use in wet environments.

360-degree tip
to access hard-to
reach areas

3 Pressure settings

2 Flossing modes:
Clean & Deep Clean

14-day battery life⁶

8 fl oz reservoir
sufficient for a full
clean in 60 seconds



Figure 1: Philips Sonicare Cordless Power Flosser 3000 with labeled features including 360-degree tip, pressure settings, flossing modes, battery life, and reservoir capacity.

PACKAGE CONTENTS

Your Philips Sonicare Cordless Power Flosser 3000 package includes the following items:

- 1x Cordless Water Flosser (main unit)
- 1x Standard Nozzle (F1)
- 1x Quad Stream Nozzle (F3)
- 1x USB-A Charging Cable
- 1x Wall Adapter



2 nozzles:
Standard for power cleaning
between teeth



Quadstream for thorough
yet gentle cleaning

Figure 2: The Philips Sonicare Cordless Power Flosser 3000 package contents, including the main unit, two nozzles (Standard and Quad Stream), USB charging cable, and power adapter.

SETUP INSTRUCTIONS

1. **Unpack the Device:** Carefully remove the Power Flosser and all accessories from its packaging.
2. **Charge the Device:** Before first use, fully charge the device. Connect the USB-A charging cable to the flosser and the wall adapter, then plug it into a power outlet. The battery indicator will show charging status. A full charge provides up to 14 days of use.
3. **Fill the Water Reservoir:** Open the reservoir cap and fill the reservoir with lukewarm water. Ensure the water level does not exceed the maximum fill line. Close the cap securely.
4. **Attach a Nozzle:** Select either the Standard Nozzle (F1) for a focused stream or the Quad Stream Nozzle (F3) for broader coverage. Insert the chosen nozzle into the handle until it clicks into place.

PHILIPS

sonicare

Cordless
Power Flosser

3000

Oral Irrigator

**Up to 150%
more effective
than floss**
in improving
gum health¹



Figure 3: The Philips Sonicare Cordless Power Flosser 3000 shown in its retail packaging, illustrating the initial state before setup.

OPERATING INSTRUCTIONS

1. **Power On:** Press the power button to turn on the device.
2. **Select Mode:** Choose between 'Clean' mode for continuous water pressure or 'Deep Clean' mode which uses Pulse Wave technology to guide you.
3. **Adjust Pressure:** Select one of the three pressure levels using the intensity button to suit your comfort and cleaning needs.
4. **Position the Nozzle:** Lean over a sink and place the nozzle tip between your teeth and along the gumline. Keep your mouth slightly open to allow water to flow out.
5. **Begin Flossing:** Press the start button to begin the water stream. Guide the device slowly along your gumline, pausing briefly between each tooth. The 360-degree rotating tip allows for easy access to all areas.
6. **Pulse Wave Technology (Deep Clean Mode):** In Deep Clean mode, the device will briefly pause the water flow every 15 seconds to indicate when to move to the next section of your mouth, ensuring a thorough 60-second clean.
7. **Power Off:** Press the power button again to turn off the device after use.



Up to 150% more
effective than floss
in improving gum health¹

Figure 4: An illustration demonstrating the Quad Stream Technology, showing four wide streams of water effectively cleaning between teeth and along the gumline.

**Up to 1.5x
more effective**
than interdental
brushes for
healthier gums¹



Figure 5: An illustration depicting the Pulse Wave technology, which guides the user through tooth-to-tooth flossing by indicating when to move the nozzle.

CARE AND MAINTENANCE

- **After Each Use:** Empty any remaining water from the reservoir. Rinse the reservoir with clean water.
- **Cleaning the Reservoir:** The reservoir is removable and dishwasher-safe for thorough cleaning.
- **Cleaning the Nozzles:** Remove the nozzle from the handle and rinse it under running water. Replace nozzles every 6 months or sooner if they show signs of wear.
- **Cleaning the Handle:** Wipe the handle with a damp cloth. Do not immerse the main unit in water for extended periods, although it is IPX7 waterproof.
- **Storage:** Store the device in a clean, dry place when not in use.



Pulse Wave
guides you from
tooth-to-tooth flossing

Figure 6: The two types of nozzles included with the Power Flosser: a Standard nozzle for focused cleaning and a Quad Stream nozzle for broader coverage.

SPECIFICATIONS

Model Number	HX3826/23
Power Source	Battery Powered (1 Lithium Ion battery required)
Product Dimensions	3.62 x 5.28 x 9.72 inches
Weight	14.88 ounces
Water Reservoir Capacity	8 fl oz
Waterproof Rating	IPX7
Flossing Modes	Clean, Deep Clean

WARRANTY AND SUPPORT

Philips Sonicare products are designed for durability and performance. In the event of a product defect, please refer to your purchase documentation for warranty details. Many users have reported positive experiences with warranty claims, receiving replacements within a reasonable timeframe.

For further assistance, product registration, or to inquire about replacement parts, please visit the official Philips Sonicare support website or contact their customer service.

LEGAL DISCLAIMER

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is intended for oral hygiene purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Answered questions about this manual

Is there any video tutorial on how to assemble the Philips Sonicare Cordless Power Flosser 3000 (Model HX3826/23) when first purchased?

The provided user manual for the Philips Sonicare Cordless Power Flosser 3000 (Model HX3826/23) does not include links to video tutorials for assembly. However, it does provide clear step-by-step setup instructions: Unpack the Device:...

[Read full answer](#)

