Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Green Thumb 106839

Green Thumb Adjustable Tripod Impulse Sprinkler User Manual

1. Introduction

The **Green Thumb Adjustable Tripod Impulse Sprinkler** is designed to provide efficient and versatile watering for your lawn and garden. This sprinkler system features a robust tripod base for stability and an adjustable impulse sprinkler head, allowing for precise control over watering area and pattern. It is capable of watering an area of up to 5,800 square feet.

Please read this manual thoroughly before operating the sprinkler to ensure proper setup, safe use, and optimal performance.

2. Safety Information

- Always disconnect the water supply before attempting to adjust, move, or perform maintenance on the sprinkler.
- Ensure the tripod legs are fully extended and securely positioned on a stable, level surface to prevent tipping during operation.
- Do not leave children or pets unattended near an operating sprinkler.
- Avoid directing the water spray towards electrical outlets, appliances, or people.
- Store the sprinkler in a dry, protected area when not in use, especially during freezing temperatures.

3. Package Contents

Verify that all components are present:

- 1 x Green Thumb Adjustable Tripod Impulse Sprinkler (Model 106839)

4. Setup Instructions

1. **Unpack the Sprinkler:** Carefully remove the sprinkler from its packaging. Inspect for any signs of damage.
2. **Position the Tripod:** Place the tripod in the desired watering location. Extend the telescopic legs to the desired height. The sprinkler can reach up to 56 inches tall. Use the quick and easy-to-use snap locks to secure the leg extensions firmly. The weighted legs and spiked feet provide enhanced stability.
3. **Connect Water Hose:** Attach a standard garden hose to the inlet connection at the base of the tripod. Ensure

the connection is tight to prevent leaks.



Figure 1: Close-up of the tripod base and water connection.

5. Operating Instructions

1. **Turn on Water:** Slowly turn on the water supply from your faucet. Observe the sprinkler for any leaks.
2. **Adjust Spray Pattern:** The impulse sprinkler head allows for adjustment of both distance and stream pattern. Use the adjustment collars and levers on the sprinkler head to set the desired full-circle or part-circle spray. Refer to the markings on the sprinkler head for guidance.
3. **Adjust Spray Distance:** The range of the water spray can be adjusted by manipulating the diffuser pin and tension spring on the impulse head.

4. **Monitor Coverage:** Observe the watering pattern to ensure adequate coverage of your desired area. Make further adjustments as needed.



Figure 2: Sprinkler in operation, demonstrating water distribution.

6. Maintenance

- **Clean Sprinkler Head:** Periodically check the sprinkler head nozzle for debris or mineral buildup. Clean with a soft brush or a small wire if necessary.
- **Inspect Connections:** Regularly inspect hose connections and seals for wear or damage. Replace washers as needed to prevent leaks.
- **Winterization:** Before the first frost, disconnect the sprinkler from the hose and drain all water from the unit. Store the sprinkler in a dry, frost-free location to prevent damage from freezing water.

7. Troubleshooting

- **Sprinkler Not Rotating:** Check for obstructions in the sprinkler head mechanism. Ensure adequate water pressure.
- **Uneven Spray Pattern:** Adjust the diffuser pin and tension spring. Clean the nozzle for any blockages.
- **Low Water Pressure:** Ensure the water source is fully open. Check for kinks in the hose or blockages in the hose filter.
- **Leaks at Connections:** Tighten hose connections. Replace worn rubber washers if necessary.

8. Specifications

- **Brand:** Green Thumb
- **Model Number:** 106839

- **UPC:** 644097293732
- **Coverage Area:** Up to 5,800 sq. ft.
- **Maximum Height:** 56 inches
- **Dimensions (L x W x H):** 56 x 48 x 48 inches (fully extended)
- **Style:** Adjustable Tripod Impulse

9. Warranty and Support

For specific warranty information, product registration, or customer support, please refer to the packaging or visit the official Green Thumb website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question