

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sunbeam](#) /
- › [Sunbeam 1700W Steam Iron Instruction Manual](#)

Sunbeam 32610050

Sunbeam 1700W Steam Iron Instruction Manual

Model: 32610050

PRODUCT OVERVIEW

The Sunbeam 1700W Steam Iron is designed for efficient and effective garment care. It features a powerful steam output, a non-stick soleplate for smooth gliding, and a convenient retractable cord for easy storage. This iron incorporates advanced safety features, including a 3-way auto shut-off, ensuring peace of mind during use. Its precision tip allows for detailed ironing around buttons and collars, making it a versatile tool for all your ironing needs.



Image: The Sunbeam 1700W Steam Iron, showcasing its sleek blue and white design with visible controls and soleplate.

KEY FEATURES

- **1700W Power:** Provides rapid heating for quick ironing sessions.
- **Powerful Shot of Steam:** Delivers an extra burst of steam for stubborn wrinkles, usable horizontally or vertically.
- **Dual Spray Mist:** Dampens fabrics to assist in smoothing out tough creases.
- **Non-Stick Soleplate:** Ensures smooth gliding over various fabric types.
- **3-Way Auto Shut-Off:** Automatically turns off the iron if left unattended or in an improper position for safety.
- **8-Foot Retractable Cord:** Offers convenient storage and reduces clutter.
- **280ml Water Tank:** Large capacity for extended ironing without frequent refills.
- **Precision Tip:** Designed for easy access around buttons, lapels, and collars.

SETUP AND PREPARATION

1. **Unpacking:** Carefully remove the iron and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the soleplate with a soft, damp cloth to remove any manufacturing residue.
3. **Filling the Water Tank:**

Ensure the iron is unplugged and cool. Open the water fill cover and slowly pour tap water into the 280ml water tank up to the MAX fill line. Do not overfill. For optimal performance and to prevent mineral buildup, distilled or demineralized water is recommended, especially in hard water areas.



Image: A hand pouring water into the easy-fill 280ml water tank of the iron, demonstrating the filling process.

4. **Power Connection:** Extend the 8-foot retractable cord by pulling it gently until it locks into place. Plug the iron into a standard 120V AC electrical outlet.
5. **Temperature Setting:** Turn the temperature dial to the desired fabric setting. Allow the iron to heat up until the indicator light turns off, signaling it has reached the selected temperature.

OPERATING INSTRUCTIONS

Dry Ironing

For dry ironing, ensure the steam control is set to the "OFF" position. Select the appropriate temperature for your fabric using the temperature dial. Once the iron is heated, begin ironing your garments. The non-stick soleplate will glide smoothly over fabrics.

Steam Ironing

For steam ironing, fill the water tank as described in the Setup section. Set the temperature dial to a steam-appropriate setting (usually indicated by steam icons on the dial). Once the iron is heated, move the steam control to the "ON" position. Steam will be emitted from the soleplate. For best results, iron with continuous, even strokes.



Image: A person using the iron to smooth a garment, with steam visibly emanating from the soleplate, highlighting the powerful Shot of Steam feature.

Shot of Steam Feature

To use the Shot of Steam feature, ensure the water tank is filled and the iron is heated to a steam-appropriate temperature. Press the "Shot of Steam" button located on the handle. This feature can be used for horizontal ironing to remove stubborn wrinkles or vertically for steaming hanging garments, drapes, or upholstery. Allow a few seconds between bursts for optimal steam generation.

Dual Spray Mist Feature

The Dual Spray Mist feature helps to dampen fabrics for easier wrinkle removal. Simply press the "Spray Mist" button to release a fine mist onto the garment. This is particularly useful for heavy fabrics or deeply creased areas.



Image: A close-up of the iron in use, showing the spray mist feature in action, dampening a garment.

Precision Tip and Non-Stick Soleplate

The iron's precision tip allows you to easily navigate around buttons, collars, and other intricate areas of your garments, ensuring a crisp finish. The non-stick soleplate is designed to glide effortlessly over all types of fabrics, preventing snagging and sticking.



Image: A close-up view of the iron's precision tip being used to iron around buttons on a shirt, demonstrating its maneuverability.



Image: A detailed view of the iron's large non-stick soleplate, highlighting its smooth surface and steam holes.

3-Way Auto Shut-Off

For enhanced safety, the iron is equipped with a 3-way auto shut-off feature. If the iron is left motionless on its soleplate for 30 seconds, or on its side for 30 seconds, or upright on its heel rest for 8 minutes, it will automatically turn off. The indicator light will illuminate to show the iron is in auto shut-off mode. To reset, simply move the iron.

MAINTENANCE AND CARE

- **Cleaning the Soleplate:**

To clean the non-stick soleplate, ensure the iron is unplugged and completely cool. Wipe the soleplate with a soft, damp cloth. For stubborn stains, a mild, non-abrasive cleaner designed for iron soleplates can be used. Never use abrasive scouring pads or harsh chemicals, as these can damage the non-stick coating.

- **Self-Cleaning Function:**

The iron features a self-cleaning function to remove mineral buildup from the steam vents. Fill the water tank to the MAX line. Set the temperature to MAX and allow the iron to heat up. Once hot, unplug the iron and hold it horizontally over a sink.

Press and hold the self-clean button (if available, otherwise refer to manual for specific self-clean instructions) until all water and steam have been expelled. Repeat if necessary. (Note: The provided data mentions "Self-Cleaning" as a special feature, but no specific button or detailed instruction is given. This is a general instruction.)

• **Water Tank Emptying:**

After each use, it is recommended to empty any remaining water from the tank to prevent mineral buildup and prolong the life of the iron. Unplug the iron and allow it to cool. Open the water fill cover and invert the iron over a sink to drain the water.

• **Storage:**

Once the iron is completely cool and dry, retract the 8-foot cord by pressing the cord rewind button. Store the iron upright on its heel rest in a safe, dry place, away from direct sunlight and moisture.



Image: The iron shown with its 8-foot retractable cord fully extended, illustrating the cord management feature.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet malfunction; auto shut-off activated.	Ensure iron is securely plugged into a working outlet. Move the iron to reset the auto shut-off.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to OFF; mineral buildup.	Fill water tank. Set temperature to a steam setting. Move steam control to ON. Perform self-cleaning.
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled; iron not hot enough before steaming.	Ensure iron is fully heated before using steam. Do not overfill water tank.
Iron sticks to fabric.	Soleplate is dirty; temperature setting too high for fabric type.	Clean the soleplate. Adjust temperature according to fabric care labels.
Cord does not retract fully.	Cord may be tangled or obstructed.	Gently pull the cord out completely, then press the retract button again. Ensure no obstructions.

SPECIFICATIONS

Feature	Detail
Brand	Sunbeam
Model Name	1700W Retractable Iron
Item Model Number	32610050
Power	1700W
Special Features	Self-Cleaning, Non-Stick Soleplate, Retractable Cord, 3-Way Auto-Off
Color	White/Blue
Base Material	Stainless Steel
Voltage	120 Volts
Frequency	50 Hz
Product Dimensions	12.83 x 4.8 x 5.98 inches
Item Weight	3.86 pounds
Water Tank Capacity	280ml
Cord Length	8 feet (retractable)





Image: A diagram showing the key dimensions of the Sunbeam 1700W Steam Iron: 12.4 inches in length and 4.8 inches in width.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Sunbeam website. Keep your purchase receipt as proof of purchase for any warranty claims.

You can visit the [Sunbeam Store](#) for more product information and support resources.

