

- › [DeLUX](#) /
- › [DELUX GM905DB Wireless Ergonomic Keyboard User Manual](#)

DeLUX GM905DB

DELUX GM905DB Wireless Ergonomic Keyboard User Manual

Model: GM905DB | Brand: DeLUX

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your DELUX GM905DB Wireless Ergonomic Keyboard. Designed for comfort and efficiency, this keyboard features a split ergonomic structure, dual-mode connectivity (2.4G wireless and Bluetooth), and a built-in wrist rest to support natural typing posture and reduce strain.



2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- DELUX GM905DB Wireless Ergonomic Keyboard
- USB 2.4G Receiver
- User Manual

3. PRODUCT OVERVIEW

The DELUX GM905DB keyboard is engineered to provide a comfortable typing experience. Its key features include:

- **Split Ergonomic Design:** The keyboard is divided into two sections, allowing for a more natural hand and wrist position.
- **Integrated Wrist Rest:** A soft, pillowed wrist rest made of skin-friendly synthetic leather supports your palms during typing.
- **Dual-Mode Connectivity:** Connect wirelessly via 2.4G USB receiver or Bluetooth 5.0 (BT1, BT2 channels).
- **Multi-Device Support:** Seamlessly switch between up to three connected devices.
- **Dedicated Multimedia Keys:** Easy access to volume, brightness, and other media controls.
- **Adjustable Kickstands:** Customize the keyboard's tilt angle for optimal comfort.






Image 3.1: Illustration of the split ergonomic structure promoting a natural arm angle for comfortable typing.



FULL-SIZE. FULL-FUNCTION.

Standard layout with ergo form factor

Image 3.2: The full-size layout of the keyboard, featuring 112 keys and an ergonomic form factor.



DEDICATED MULTIMEDIA KEYS

Easy-access controls

Image 3.3: A close-up view of the dedicated multimedia control keys located on the keyboard.

4. SETUP

4.1. Battery Installation

The keyboard requires two AAA batteries (not included). To install:

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

LONG BATTERY LIFE

Up to 12 months with 2 pcs AAA batteries



Image 4.1: The underside of the keyboard showing the battery compartment and two AAA batteries.

4.2. Connecting via 2.4G Wireless

To connect using the 2.4G USB receiver:

1. Insert the USB 2.4G receiver into an available USB port on your computer.
2. Turn on the keyboard.
3. Press the '2.4G' button on the keyboard. The indicator light will illuminate, confirming the connection.

4.3. Connecting via Bluetooth

The keyboard supports two Bluetooth channels (BT1 and BT2). To connect:

1. Turn on the keyboard.
2. Press and hold either the 'BT1' or 'BT2' button for 3-5 seconds until the corresponding indicator light flashes rapidly. This indicates pairing mode.
3. On your device (computer, tablet, etc.), navigate to Bluetooth settings and search for new devices.
4. Select 'DELUX Keyboard' (or similar name) from the list of available devices to pair.
5. Once paired, the indicator light will stop flashing and remain solid for a few seconds, then turn off.

MULTI-DEVICES CONNECTION. MULTI-SYSTEM COMPATIBILITY.



Image 4.2: The keyboard demonstrating multi-device connectivity with a laptop (2.4G), tablet (BT1), and monitor (BT2).

5. OPERATING INSTRUCTIONS

5.1. Switching Between Connected Devices

To switch between devices connected via 2.4G, BT1, or BT2, simply press the corresponding button ('2.4G', 'BT1', or 'BT2') on the keyboard. The keyboard will connect to the selected device.

5.2. Using Multimedia Keys

The keyboard features dedicated multimedia keys for quick access to various functions:

- **Volume Control:** Use the dedicated volume up, volume down, and mute buttons.
- **Brightness Control:** Adjust screen brightness with the dedicated brightness keys.
- **FN Lock:** Some function keys (F1-F12) may have secondary functions. Use the Fn key in combination with these keys, or use an Fn-lock feature if available, to toggle between primary and secondary functions.

EASY-ACCESS MULTI-MEDIA CONTROLS

Be more productive with FN-lock shortcuts and dedicated function keys



Image 5.1: A close-up of the keyboard highlighting the multimedia controls and function keys.

5.3. Adjusting Keyboard Angle

The keyboard is equipped with adjustable kickstands to modify its tilt angle for personalized comfort. There are four kickstands located at the corners of the keyboard. Adjust them to achieve 0°, 3°, or 5° tilt as preferred for seated or standing postures.



FRONT AND PALM KICKSTAND

Considering seated or standing posture

Image 5.2: Side view illustrations showing the keyboard at 0°, 3°, and 5° tilt angles using the adjustable kickstands.

6. MAINTENANCE

6.1. Cleaning

To clean your keyboard:

- Ensure the keyboard is turned off before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid excessive moisture and do not spray cleaners directly onto the keyboard.
- For dust and debris between keys, use compressed air.

6.2. Battery Replacement

When the keyboard's performance degrades or the connection becomes unstable, it may be time to replace the AAA batteries. Follow the battery installation steps in Section 4.1.

7. TROUBLESHOOTING















Issue	Possible Cause	Solution
Keyboard not connecting via 2.4G	USB receiver not properly inserted; low keyboard battery; incorrect mode selected.	Ensure USB receiver is fully inserted. Replace batteries. Press the '2.4G' button. Try a different USB port.
Keyboard not connecting via Bluetooth	Keyboard not in pairing mode; device Bluetooth off; low keyboard battery.	Press and hold 'BT1' or 'BT2' to enter pairing mode. Ensure Bluetooth is enabled on your device. Replace batteries. Remove and re-pair the keyboard in device settings.
Keys are unresponsive or laggy	Low keyboard battery; interference; distance from receiver/device.	Replace batteries. Move closer to the receiver/device. Ensure no large metal objects are between the keyboard and receiver/device.
Multimedia keys not working	Software conflict; driver issue.	Ensure your operating system is up to date. Check for specific keyboard drivers if available from the manufacturer's website.

8. SPECIFICATIONS

Feature	Detail
Brand	DeLUX
Model	GM905-XXX
Connectivity Technology	2.4GHz Wireless, Bluetooth 5.0
Keyboard Description	Membrane
Number of Keys	112
Special Features	Ergonomic, Full Size, Wrist Rest
Compatible Devices	Laptop, PC
Operating Systems	Mac OS, Windows 10, Windows 7, Windows 8
Power Source	Battery Powered (2 x AAA, not included)
Material Type	Synthetic Leather (for wrist rest)
Product Dimensions	48.54 x 25.49 x 4.66 cm
Item Weight	980 g

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product packaging or visit the official DeLUX website. Keep your purchase receipt for warranty claims.




<div><div></div><div></div><div><p>User Manual M618XSU</p></div><div><p>Thank you for choosing DELUX SENSA, please read all instructions thoroughly before beginning the installation.</p><p>SYSTEM Windows7/Windows8/Windows10/ Mac OS</p><p>FUNCTIONS</p><p>Connection Press the power switch into ON position. Can be set after identified.</p><p>Light mode switching Support of light can be switched when you press right button and backward button at the same time.</p><p>DPI switching Tap DFI button to switch the DPI. 400 (purple light) - 1600 (green light) - 3200 (blue light) - 4800 (orange light) - 6400 (red light) Switching DPI automatically when the corresponding light turned on/off. Default DPI: 1600DPI-4800</p></div></div> <div><p>Report rate Connect DELUX SENSA to 1000Hz. Default 1000Hz, can be changed by the driver.</p><p>Thumb scroll wheel Rolling up - Moving to the left Rolling down - Moving to the right (Can be used in office software, browser, etc.)</p><p>Driver Installation 1. Installation Download from DELUX website: www.deluxworld.com 2. Setting Opening the driver (when using the mouse) to set the functions. A. Main page for configuration Click "X" on the top left of the interface to create a new configuration file. Click  the current configuration file can be deleted. Click  the current configuration file can be loaded. Click  the current configuration file can be saved.</p></div> <div><p>a. Light setting Click "Light setting" to set the light.</p></div> <div><p>c. Button setting Click "Button setting" to set the buttons. Click  for all settings done.</p></div> <div><p>d. Macro management Click "Macro management" to set the Macro. Click "X" to create a new Macro, then click "OK" to return. Entering the key that you need at the software driver recording. Click "OK" to stop the Macro recording. Input Macro key combination when the button you need to set, then click "Macro key board" to choose Macro name, then click "Save" to complete the setting.</p></div> <div><p>e. Driv setting Click "Other settings" to set the DPI.</p></div> <div><p>f. Device setting Click  New, then click "OK" to complete the setting.</p></div>	<p>DELUX M618XSU Vertical Mouse User Manual</p> <p>User manual for the DELUX M618XSU wired ergonomic vertical mouse, detailing setup, functions, and software customization for DPI, lighting, and button programming.</p>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

[DELUX GM902PRO Ergonomic Keyboard User Manual](#)


User manual for the DELUX GM902PRO Ergonomic Keyboard, detailing setup, connection, battery indicators, and key functions for wireless and Bluetooth connectivity.

[DELUX HD308-3G02 Wireless Ergonomic Keyboard User Manual](#)

User manual for the DELUX HD308-3G02 Wireless Ergonomic Keyboard, detailing connection, usage, features, indicator lights, multimedia functions, design specifications, and FCC compliance information.

	<p>DELUX M900 Series Mouse User Manual and Warranty</p> <p>Official user manual and warranty information for the DELUX M900 Series mouse, detailing DPI settings, connection modes, FCC compliance, hazardous substances, and warranty terms.</p>
 <p>GM901U User Manual - Uživatelský manuál - Uživatelský manuál - Benutzerhandbuch</p>	<p>Delux GM901U Ergonomic Keyboard User Manual</p> <p>User manual for the Delux GM901U ergonomic keyboard, covering setup, key functions, compatibility, warranty, and EU declaration of conformity.</p>
	<p>DELUX M618MINI GX Vertical Mouse User Manual</p> <p>User manual for the DELUX M618MINI GX vertical wireless mouse, covering features, installation, specifications, driver instructions, connection troubleshooting, and FCC compliance.</p>

Documents - DeLUX – GM905DB



1. Rozpoznac i:

1. Rozpoznac i:




2




In the current era, however, we also need to consider the

- In 1840, the first literary magazine, *Putnik*, was published in St. Petersburg.
- *Putnik* was the first Russian literary magazine.
- It was the first Russian literary magazine.
- It was the first Russian literary magazine.




4



Gdy pojmanol, białe i spadnie pociąg, to

Gdy pojemność baterii spadnie poniżej 10%, wskaznik baterii będzie naigł na czerwono, proste wyjąć baterie na czys.



1

111

if device	1.4.1.1 URL: 192.168.1.1	if device	1.4.1.1 URL: 192.168.1.1
	Home		Wi-Fi
	Mobile net		Bluetooth
	Search		Calendar
	App drawer		Alarm clock
	Camera		Music
	Gmail		Phone
	Messages		Browser
	App Store		Settings
	Google Assistant		Power
	Battery		Lock
	Wi-Fi		Bluetooth
	Mobile net		Calendar
	Search		Alarm clock
	App drawer		Music
	Camera		Phone
	Gmail		Browser
	Messages		Settings
	App Store		Power
	Google Assistant		Lock
	Battery		Bluetooth
	Wi-Fi		Calendar
	Mobile net		Alarm clock
	Search		Music
	App drawer		Phone
	Camera		Browser
	Gmail		Settings
	Messages		Power
	App Store		Lock
	Google Assistant		Bluetooth
	Battery		Calendar
	Wi-Fi		Alarm clock
	Mobile net		Music
	Search		Phone
	App drawer		Browser
	Camera		Settings
	Gmail		Power
	Messages		Lock
	App Store		Bluetooth
	Google Assistant		Calendar
	Battery		Alarm clock
	Wi-Fi		Music
	Mobile net		Phone
	Search		Browser
	App drawer		Settings
	Camera		Power
	Gmail		Lock
	Messages		Bluetooth
	App Store		Calendar
	Google Assistant		Alarm clock



2