

Graywind CAPJ-BD15

Graywind 15-Channel Timing Remote Controller Instruction Manual

Model: CAPJ-BD15

Brand: Graywind

INTRODUCTION

This manual provides comprehensive instructions for the Graywind 15-Channel Timing Remote Controller (Model CAPJ-BD15). This remote is designed to operate Graywind smart roller shades, zebra blinds, shangrila shades, roman shades, dual shades, curtains, and panel track blinds. Please read this manual thoroughly before use to ensure proper operation and to maximize the functionality of your remote controller.

PRODUCT FEATURES

- **Multi-Channel Control:** Capable of controlling up to 15 smart shades individually or in groups.
- **Light Adjustment:** Dedicated function buttons for flexible light adjustment.
- **Favorite Position:** Allows setting and recalling a preferred shade position.
- **Timing Function:** Supports up to 20 date-time groups for automatic shade control.
- **Ergonomic Design:** Features an all-black, ergonomic design with a backlight for clear display in low light conditions.
- **Versatile Use:** Can be used handheld or wall-mounted. Includes a removable silicone case.



Image: The Graywind 15-Channel Timing Remote Controller, showcasing its ergonomic design and digital display.

PACKAGE CONTENTS

The Graywind 15-Channel Timing Remote Controller package typically includes:

- 1 x Graywind 15-Channel Timing Remote Controller (Model CAPJ-BD15)
- Mounting Hardware (for wall-mounting option)
- User Manual (this document)



Image: The retail packaging for the Graywind 15-Channel Timing Remote Controller, indicating included features like 20 timing groups and 15 channels.

SETUP

1. Initial Power-On

Ensure the remote has sufficient power. If applicable, insert batteries according to the polarity markings inside the battery compartment. The remote's display should illuminate.

2. Pairing with Shades

Refer to the specific instructions provided with your Graywind smart shades for pairing procedures. Generally, this

involves a sequence of button presses on both the remote and the shade motor to establish a connection. The remote can be paired with up to 15 individual shades or groups of shades.

3. Wall Mounting (Optional)

If you choose to wall-mount the remote, use the provided mounting hardware. Select a convenient location, ensuring the remote is easily accessible. Secure the mounting bracket to the wall and then attach the remote controller.

OPERATING INSTRUCTIONS

The remote controller features an intuitive button layout for easy operation of your Graywind shades.

INSTRUCTIONS



Image: A detailed diagram illustrating the buttons on the Graywind remote control and their respective functions, including Open, Close, Stop, Channel selection, Function buttons, and Favorite Position.

- **Open Button:** Raises the selected shade(s) to the fully open position.
- **Close Button:** Lowers the selected shade(s) to the fully closed position.
- **Stop Button (||):** Halts the movement of the selected shade(s) at the current position.
- **Channel +/- Buttons:** Used to select individual channels (1-15) or the group channel (00) for controlling multiple shades simultaneously.
- **Function Buttons (Circular Arrows):** Used for advanced settings such as adjusting light levels or navigating

menus. Refer to the shade's specific manual for detailed use.

- **Favorite Position Button (Heart Icon):** Moves the selected shade(s) to a pre-set favorite position. To set a favorite position, move the shade to the desired height, then press and hold the Favorite Position button until the shade briefly jogs.

Timing Schedule

The remote supports setting up to 20 date-time groups for automated shade operation. Consult the remote's on-screen menu and your shade's manual for detailed instructions on programming timing schedules. This feature allows shades to open or close at specific times, enhancing convenience and energy efficiency.



Remote Control



Timing Schedule



Favorite Position



Separate Control



Group Control



Adjust Light




7:00AM

DAY

07:00

open shade



10:30PM

NIGHT

22:30

close shade

Support handheld or wall-mounted



Strong Magnetic Force

Image: An infographic showing the remote's capabilities, including timing schedules for opening shades in the morning and closing them at night, along with separate and group control options.

MAINTENANCE

- **Cleaning:** Spot clean the remote controller only. Use a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** If the display dims or the remote becomes unresponsive, replace the batteries. Refer to the battery compartment for the correct battery type and polarity.
- **Storage:** Store the remote in a dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Low or dead batteries. Remote not paired. Obstruction between remote and shade.	Replace batteries. Re-pair the remote with the shade (refer to pairing instructions). Ensure a clear line of sight.
Shade not moving to favorite position.	Favorite position not set or incorrectly set.	Re-set the favorite position (see Operating Instructions).
Timing function not working.	Incorrect time/date setting. Schedule not programmed correctly.	Verify time and date settings on the remote. Review and re-program the timing schedule.
Difficulty controlling multiple shades.	Incorrect channel selected. Shades not grouped properly.	Ensure the correct channel (1-15 for individual, 00 for group) is selected. Verify shade grouping in pairing process.

SPECIFICATIONS

Model Number	CAPJ-BD15
Brand	Graywind
Control Type	Remote
Number of Channels	15
Timing Groups	Up to 20 date-time groups
Material	Plastic
Product Dimensions	Approximately 5"L x 5"W
Item Weight	6.7 ounces (0.19 Kilograms)
Recommended Uses	Indoor control of smart shades
Mounting Type	Handheld or Wall Mount
Product Care	Spot Clean Only

WARRANTY AND SUPPORT

Graywind offers a **5-year extended warranty** on its products. For warranty claims, technical support, or any inquiries regarding your Graywind 15-Channel Timing Remote Controller, please contact Graywind customer service. Contact information can typically be found on the product packaging or the official Graywind website. For additional resources and product information, visit the official Graywind store: [Graywind Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question