

## HOUSBAY B0C8MXRRCX

# Housbay Glows White Noise Sound Machine User Manual

Model: B0C8MXRRCX | Brand: HOUSBAY

### 1. INTRODUCTION

The Housbay Glows White Noise Sound Machine is designed to create a peaceful and conducive environment for sleeping, relaxation, and concentration. It effectively tunes out disruptive noises, offering a variety of soothing sounds to enhance your personal space.



Figure 1: Front view of the Housbay Glows White Noise Sound Machine.

## 2. KEY FEATURES

- **Noise Cancellation:** Effectively blocks out disruptive sounds such as loud neighbors, street noise, snoring, tinnitus, and office conversations, promoting better sleep and focus.
- **Extensive Sound Library:** Features 31 soothing sounds, including 7 fan sounds, 7 white noises (non-looping), and 17 realistic nature sounds (e.g., ocean, waves, thunderstorm, brook).
- **Portable Design:** Compact and lightweight, making it ideal for travel to maintain a consistent sleep environment.
- **Customizable Settings:** Offers 15 adjustable volume levels, a sleep timer (1, 2, or 3 hours), and continuous play option. The device auto-saves preferred settings.
- **Simple Operation:** No app, Wi-Fi, or Bluetooth required. Comes with an AC adapter and a 59-inch USB cable for easy plug-and-play functionality.

## ***Tune Out All Disruptive Noise***



***sleep well, concentrate better,  
and have more privacy***

Figure 2: The sound machine helps tune out disruptive noise for better sleep and concentration.

# 31 Soothing Sounds



7 White Noises



17 Nature Sounds



7 Fan Sounds



Figure 3: Detailed breakdown of the 31 soothing sounds available.

## 3. SAFETY INFORMATION

This product is battery powered and should be used with the correct type of batteries. Do not expose the device to water or moisture. Use with adult supervision and keep out of reach of small children due to the potential choking hazard from small parts.

## 4. SETUP

The Housbay Glows White Noise Sound Machine is designed for easy setup. Follow these steps to get started:

1. Unpack the sound machine, AC adapter, and USB cable from the box.
2. Connect the 59-inch (1.5M) USB cable to the sound machine's power input port.
3. Plug the AC adapter into a standard wall outlet.

4. Ensure the connection is secure. The device is now ready for operation.



## ***Make Anywhere Feel Like Home***

Figure 4: Included components: sound machine, 59-inch (1.5M) DC cable, and AC adapter.

### **5. OPERATING INSTRUCTIONS**

Operate your sound machine using the intuitive controls on the top panel:

1. **Power On/Off:** Press the **Power button** (🔘) to turn the device on or off.
2. **Sound Selection:**
  - Press the **White Noise icon** (🔘) to cycle through 7 white noise sounds.
  - Press the **Nature Sound icon** (🔘) to cycle through 17 nature sounds.
  - Press the **Fan Sound icon** (🔘) to cycle through 7 fan sounds.
3. **Volume Adjustment:**
  - Press the **Volume Up button** (🔘) to increase the volume.
  - Press the **Volume Down button** (🔘) to decrease the volume. There are 15 adjustable levels.
4. **Sleep Timer:** Press the **Timer button** (🔘) to set the auto-off timer for 1, 2, or 3 hours. Pressing it a fourth time will set it to continuous play. The device will remember your last settings.

## ***Auto- Off Timer:*** ***1h, 2h, 3h***



Figure 5: Auto-off timer options (1h, 2h, 3h).



# 15 *Adjustable Volume Levels*

Figure 6: Volume controls with 15 adjustable levels.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your Housbay Glows White Noise Sound Machine, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the exterior of the device. Do not use liquid cleaners or abrasive materials, as they may damage the finish.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care. Avoid dropping it or subjecting it to strong impacts, which could damage internal components.

## 7. TROUBLESHOOTING

If you encounter any issues with your Housbay Glows White Noise Sound Machine, please refer to the

following common troubleshooting tips:

- **No Power:** Ensure the AC adapter is securely plugged into both the device and a working wall outlet. Check if the power outlet is functional.
- **No Sound:** Verify that the volume is not set to the lowest level. Try cycling through different sound options to ensure a sound is selected.
- **Sound Distortion:** If the sound is distorted, try lowering the volume. Ensure the device is placed on a stable, flat surface.
- **Device Not Responding:** Unplug the device from the power source, wait for 10 seconds, and then plug it back in to perform a soft reset.

If the problem persists after trying these steps, please contact customer support for further assistance.





## 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	4.61 x 3.31 x 4.57 inches; 15.52 ounces
Color	Gray
Material	Plastic
Power Source	Battery Powered (operates via AC adapter/USB cable)
Manufacturer	HOUSBAY
Country of Origin	China
ASIN	B0C8MXRRCX

## 9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to inquire about replacement parts, please refer to the warranty card included in your product packaging or visit the official HOUSBAY website.

For customer service inquiries, please contact HOUSBAY support directly through their official channels.

<a href="#">Preview</a>	<a href="#">HOUSBAY RS10 Sound Machine with Alarm Clock User Manual</a> Comprehensive user manual for the HOUSBAY RS10 Sound Machine with Alarm Clock, detailing features, setup, operation, and troubleshooting. Learn how to set the time, alarm, use sound machine functions, and more.
<a href="#">Preview</a>	<a href="#">HOUSBAY KW244 Magnetic Sleep Charger Quick Start Guide</a> A quick start guide for the HOUSBAY KW244 Magnetic Sleep Charger, detailing its features as a wireless charger and sound machine, and providing setup instructions.
	<a href="#">HOUSBAY GLOW Digital Alarm Clock User Manual - Setup, Features, and Operation</a> Comprehensive user manual for the HOUSBAY GLOW digital alarm clock. Learn how to set the time, alarms, use the FM radio, nightlight, sleep timer, nap timer, and understand its features and specifications.
	<a href="#">HOUSBAY TS9 White Noise Machine with Alarm Clock User Manual</a> User manual for the HOUSBAY TS9 White Noise Machine with Alarm Clock, detailing features, setup, operation, and safety precautions.
	<a href="#">HOUSBAY TS3 Digital Alarm Clock User Manual</a> Discover the HOUSBAY TS3 User Manual, your comprehensive guide to operating the HOUSBAY sound machine with alarm clock. Learn about its features including wireless charging, Bluetooth music streaming, 21 soothing sounds, 10 night light modes, and adjustable brightness. This manual provides detailed instructions for time setting, alarm setup, sound machine operation, and troubleshooting, ensuring optimal use of your HOUSBAY device.
	<a href="#">HOUSBAY Digital Alarm Clock User Manual</a> User manual for the HOUSBAY Digital Alarm Clock (Model RS13), detailing features, setup, time and alarm settings, nightlight, display brightness, volume, timer functions, battery operation, and support information.