Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax SL-939-BRN

Snailax 4D Massage Chair User Manual

Model: SL-939-BRN

1. Introduction

Thank you for choosing the Snailax 4D Massage Chair. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new massage chair. Please read this manual thoroughly before using the product and retain it for future reference.
The Snailax 4D Massage Chair is designed to provide a comprehensive full-body massage experience, featuring advanced SL-track technology, zero gravity recline, heat therapy, and various massage techniques to promote relaxation and alleviate muscle tension.

2. Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Always unplug the massage chair from the electrical outlet immediately after using and before cleaning.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Never use pins or other metallic fasteners with this appliance.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep air openings free of lint, hair, and the like.
- Never drop or insert any object into any opening.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- To disconnect, turn all controls to the off position, then remove plug from outlet.

- This appliance is designed for household use only.
- Consult your doctor before using if you have any medical conditions, are pregnant, or have a pacemaker.
- Do not exceed the maximum weight capacity of the chair (refer to specifications).

3. Product Overview

The Snailax 4D Massage Chair is engineered for ultimate relaxation and therapeutic benefits. Key features include:

- **4D SL Track Rolling Massage:** Conforms to the body's curve from neck to hips, simulating manual massage with adjustable speed and width.
- **Full-Body Air Compression:** Strategically placed airbags in arms, shoulders, legs, and feet.
- **Heat Therapy:** Integrated heating function in the back and calf areas.
- **Foot Roller Massage:** Three rollers with adjustable intensity for foot relief.
- **Zero Gravity Design:** Reclines to distribute body weight evenly, reducing spinal pressure.
- **12 Auto Massage Programs:** Pre-set programs for various needs (Comfort, Relax, Rocking, Back & Waist, Full Body, Health, Recovery, etc.).
- **Body Scan Technology:** Automatically adjusts shoulder position and extends footrest for personalized fit.
- **Bluetooth Speaker:** Integrated speakers for audio playback during massage.



Image: The Snailax 4D Massage Chair, showcasing its sleek brown design and integrated control panel.

4. Setup and Assembly

The Snailax 4D Massage Chair comes partially assembled. Due to its weight and size, it is recommended that two or more people assist with unpacking and positioning the chair. Ensure you have adequate space for assembly and operation.

1. **Unpacking:** Carefully remove all packaging materials. Inspect the chair for any signs of damage during transit.
2. **Positioning:** Place the main body of the chair in your desired location, ensuring there is sufficient clearance behind and in front of the chair for reclining and footrest extension.
3. **Connecting Components:** Follow the specific instructions provided in the separate assembly guide for attaching the footrest, armrests, and any other components. Ensure all connections are secure.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the power switch on the chair is in the OFF position before plugging in.



Image: The massage chair demonstrating its automatic adjustment capabilities for various user heights and weights, ensuring a comfortable fit for most individuals.

5. Operating Instructions

5.1 Powering On/Off

- Locate the main power switch, usually at the back or bottom of the chair. Flip it to the 'ON' position.
- Press the power button on the control panel to turn on the chair.
- To turn off, press the power button on the control panel again. For complete power disconnection, turn off the main power switch and unplug the chair.

5.2 Control Panel and Auto Programs

The chair features an intuitive control panel (often a touchscreen or remote) to select and customize your massage experience. Upon activation, the chair performs a body scan to adjust the shoulder position and footrest for optimal fit.



Image: The control panel interface displaying various auto massage programs such as Comfort, Relax, Rocking, Back & Waist, Full Body, Health, and Recovery.

- **Auto Programs:** Select from 12 pre-set auto massage programs designed for different needs and preferences. These programs combine various massage techniques, intensities, and heat settings.
- **Manual Mode:** For a customized experience, select manual mode to adjust specific massage techniques, areas, intensity, and speed.

5.3 Massage Techniques and Features



Image: Diagram showing the SL track contouring the body from neck to hip, along with icons representing five massage techniques: Knead, Beat, Knead Pad, Shiatsu, and Knock.

- **4D SL Track Rolling Massage:** The massage rollers follow the natural curve of your spine. You can choose to target a specific area (neck, shoulders, back, waist, hips) or opt for a full body massage. Available techniques include:
  - Kneading
  - Beating
  - Knead Pad
  - Shiatsu
  - Knock
- **Full-Body Air Compression:** Airbags inflate and deflate to provide compression massage to the arms, shoulders, legs, and feet. Adjust intensity as desired.



Image: An overhead view of the massage chair highlighting areas of full body air massage, including shoulder, arms, calves, and foot roller & air massage, along with neck to hip 3D Shiatsu kneading massage.

- **Heat Therapy:** Activate the heating function for the back and calf areas to promote circulation and muscle relaxation.



Image: A diagram illustrating the heat distribution in the back and calf areas of the massage chair, providing soothing warmth.

- **Foot Roller Massage:** The foot massager features three rollers with three adjustable intensity levels. It is recommended to start with the lowest setting and wear thick socks for initial use.



Image: The footrest of the massage chair, demonstrating its extendable feature (up to 7.87 inches) and the integrated foot rollers with three intensity levels.

- **Zero Gravity Recline:** Press the Zero Gravity button to recline the chair into a position that elevates your legs above your heart, distributing body weight evenly and reducing pressure on the spine. There are typically multiple zero gravity positions (e.g., Initial, Comfort, Deep).



Image: A visual representation of the three zero gravity recline positions: Initial Zero Gravity, Comfort Zero Gravity, and Deep Zero Gravity, showing how the chair elevates the user's legs.

- **Bluetooth Speaker:** Connect your device via Bluetooth to enjoy music or audio during your massage session.



Image: The massage chair with a smartphone connected via Bluetooth, indicating the integrated speakers for enjoying music while massaging.

6. Maintenance

6.1 Cleaning

- Always unplug the chair before cleaning.
- Wipe the faux leather surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- For fabric areas, use a mild upholstery cleaner if necessary, testing on an inconspicuous area first.
- Keep the chair dry and away from direct sunlight or excessive humidity.

6.2 Storage

- When not in use for extended periods, store the chair in a cool, dry place, away from extreme temperatures.
- Cover the chair with a dust cover to protect it from dust and dirt.

7. Troubleshooting

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not securely plugged in; Main power switch is off; Circuit breaker tripped.	Ensure power cord is fully inserted. Check main power switch on the chair. Check household circuit breaker.
Massage feels too strong/weak.	Intensity settings are not adjusted; Body scan not optimal.	Adjust intensity levels via the control panel. Re-start the chair to initiate a new body scan. Use a blanket or towel to soften the massage if needed.
Foot rollers are uncomfortable.	Intensity too high; Bare feet.	Reduce foot roller intensity. Wear thick socks during use.
Airbags are not inflating/deflating.	Air compression function is off; Air hose disconnected.	Ensure air compression is activated on the control panel. Check for any disconnected air hoses (refer to assembly guide).
Bluetooth not connecting.	Bluetooth on device is off; Chair's Bluetooth is off; Device too far.	Ensure Bluetooth is enabled on your device and the chair. Move device closer to the chair. Try restarting both devices.

If the problem persists after attempting these solutions, please contact Snailax customer support.

8. Specifications

- **Brand:** Snailax
- **Model Number:** SL-939-BRN
- **Colour:** Brown
- **Material:** Faux Leather
- **Product Dimensions (L x W x H):** 139.7 x 71.12 x 101.6 cm (55 x 28 x 40 inches)
- **Item Weight:** 77.1 kg (170 lbs)
- **Special Features:** Zero Gravity, SL Track, 12 Auto Programs, Compression, Rolling, Kneading, Heating, Stretch, Body Scan, Foot Roller Massage, Bluetooth Speaker.
- **Power Supply:** [Not explicitly stated in input, assume standard household voltage, e.g., AC 110-120V, 60Hz]
- **Rated Power:** [Not explicitly stated in input]
- **Maximum User Weight:** [Not explicitly stated in input, common for massage chairs is 250-300 lbs]
- **Extendable Footrest:** Up to 7.87 inches

9. Warranty and Support

Snailax provides a warranty for this product against defects in materials and workmanship. The specific terms and duration of your warranty may vary. Please refer to the warranty card included with your purchase or visit the official Snailax website for detailed warranty information.

For technical support, troubleshooting assistance, or warranty claims, please contact Snailax Customer Service. Have your model number (SL-939-BRN) and purchase information ready when contacting support.

Snailax Official Website: www.snailax.com (Please note: This is a placeholder URL as no specific support link was

provided in the input. Users should refer to their product documentation for the correct contact information.)

© 2024 Snailax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C8N245QR

More documents and user manuals: **https://manuals.plus/**