Nuliie NUBW001

Nuliie 8-in-1 Electric Bottle Warmer User Manual

Model: NUBW001

1. Introduction

Thank you for choosing the Nuliie 8-in-1 Electric Bottle Warmer. This versatile device is designed to simplify feeding times for parents, offering rapid warming, constant temperature maintenance, food heating, defrosting, and sterilization functions. Please read this manual thoroughly before use to ensure safe and optimal operation.



Image: The Nuliie 8-in-1 Electric Bottle Warmer, showcasing its compact design and digital display.

2. Safety Precautions

To prevent electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances. This appliance is for household use only.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Always unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- This appliance has a built-in automatic shut-off protection if the water dries out.
- Keep out of reach of children. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Product Components

The Nuliie 8-in-1 Electric Bottle Warmer typically includes the following components:

- Main Unit with Digital LCD Display and Control Panel
- Bottle Basket / Lifting Rack
- Protective Lid
- Measuring Cup (may be included for water measurement)



Image: Visual representation of the 8-in-1 multifunctionality, including rapid warming, defrosting, food heating, and sterilization.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging.

2. **Clean:** Before first use, clean all parts that will come into contact with milk or food according to the "Maintenance and Cleaning" section.
3. **Placement:** Place the main unit on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet (220V). The LCD display will light up.

5. Operating Instructions

The Nuliie bottle warmer features a digital LCD display and intuitive controls for various functions.

5.1 Control Panel Overview

LCD Display: Shows temperature, time, and selected mode.

Up/Down Buttons (⌃ / ⌄): Adjust temperature or time settings.

Mode Button (≡): Cycle through different functions (Fast, 24H, Food, Steam).

Power Button ( ): Turn the unit on/off.



Image: Detailed view of the digital control panel, highlighting the display and function buttons.

5.2 Fast Warming Mode (Milk/Formula)

This mode rapidly heats milk or formula to a desired temperature, typically around 37°C (98.6°F).

1. Place the bottle with milk/formula into the bottle basket.
2. Add approximately 40ml of distilled water into the heating chamber (around the bottle).
3. Place the lid on the unit.
4. Press the Mode button (≡) until "Fast" mode is selected on the display.
5. Use the Up/Down buttons (⌃ / ⌄) to set the desired heating time. The device will automatically adjust based on the initial temperature and volume.
6. The LCD will show the real-time temperature and a countdown.
7. Once heating is complete, the unit will emit 5 beeps. Carefully remove the bottle using the basket.
8. Always test the milk temperature on your wrist before feeding the baby.



Image: The bottle warmer in action, illustrating the rapid 2-minute heating process.



Image: A visual step-by-step guide for using the rapid warming function.

5.3 24-Hour Constant Temperature Mode (Keep Warm)

Ideal for night feedings, this mode maintains milk or water at a preset temperature for up to 24 hours.

1. Place the bottle with milk/water into the bottle basket.
2. Add sufficient water to the heating chamber to cover the milk level in the bottle.
3. Place the lid on the unit.
4. Press the Mode button (≡) until "24H" mode is selected.
5. Use the Up/Down buttons (⌃ / ⌄) to set the desired constant temperature (e.g., 37°C).
6. The unit will heat to and maintain this temperature for 24 hours.
7. **Important:** Fresh breast milk can be kept warm for a maximum of 4 hours. Thawed breast milk or formula should be kept warm for a maximum of 2 hours.



Image: The bottle warmer maintaining a constant temperature, useful for night feedings.

5.4 Food Heating Mode

This mode is used to gently warm baby food jars or pouches.

1. Place the baby food jar/pouch into the bottle basket.

2. Add water to the heating chamber, ensuring it covers the food level.
3. Place the lid on the unit.
4. Press the Mode button (≡) until "Food" mode is selected.
5. Use the Up/Down buttons (⌃ / ⌄) to set the desired heating time or temperature.
6. Once complete, carefully remove the food and stir to ensure even heating. Always test temperature before feeding.



Image: The bottle warmer heating a jar of baby food, demonstrating its versatility.

5.5 Defrost Mode

Gently thaws frozen breast milk bags or baby food.

1. Place the frozen breast milk bag or food into the bottle basket.
2. Add water to the heating chamber.
3. Place the lid on the unit.
4. Press the Mode button (≡) until "24H" mode is selected, then adjust the temperature to a lower setting suitable for defrosting (e.g., 30-35°C).
5. Allow the item to thaw gradually. Check periodically.



Image: The bottle warmer in defrost mode, showing a breast milk storage bag being thawed.

5.6 Sterilization Mode (Steam)

This mode uses high-temperature steam to sterilize bottles, nipples, and small accessories.

1. Ensure bottles and accessories are clean before sterilization.

2. Place the items to be sterilized into the bottle basket.
3. Add approximately 100-120ml of distilled water to the heating chamber.
4. Place the lid on the unit.
5. Press the Mode button (≡) until "Steam" mode is selected.
6. The unit will heat water to boiling point (100°C) to produce steam for sterilization.
7. Once the cycle is complete, the unit will beep and automatically shut off. Allow items to cool before handling.



Image: The bottle warmer performing high-temperature disinfection, showing steam inside the unit.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene.

- **Before Cleaning:** Always unplug the unit and allow it to cool completely.
- **Main Unit:** Wipe the exterior with a damp cloth. Do not immerse the main unit in water.
- **Heating Chamber:** After each use, empty any remaining water. For mineral deposits (limescale), mix 50ml of white vinegar with 100ml of cold water and pour into the heating chamber. Let it stand for 30 minutes or until the scale dissolves. Empty the solution and rinse thoroughly with clean water. Do not scrub the heating plate.
- **Bottle Basket & Lid:** Wash with warm soapy water and rinse thoroughly. These parts are generally dishwasher safe (top rack only), but hand washing is recommended for longevity.
- **Storage:** Store the clean and dry appliance in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure plug is securely inserted. Test outlet with another appliance. Contact customer support if issue persists.
Milk/Food not heating properly.	Insufficient water in heating chamber; incorrect mode/time setting; mineral deposits.	Add correct amount of water. Verify mode and time settings. Descale the heating chamber.
Unit automatically shuts off prematurely.	Water has dried out (dry-burn protection activated).	This is a safety feature. Add more water for the next use. Allow unit to cool before restarting.
Loud beeping sound.	Cycle completion alert.	This indicates the selected function is complete. Remove the bottle/food.

8. Specifications

Model Number: NUBW001

Power: 400W

Voltage: 220V

Dimensions (L x W x H): 15.6 x 15.3 x 26 cm (approx. 6.1 x 6.0 x 10.2 inches)

Weight: 820 grams (approx. 1.8 lbs)

Material: Food-grade PP (BPA-free)

Features: Digital Timer, LCD Display, 24-hour Keep Warm, Rapid Heating, Automatic Shut-off, Anti-dry burn protection.

Compatibility: Fits various bottle types (wide-neck, narrow, standard) and breast milk storage bags.



Image: Illustration of the bottle warmer's compatibility with various bottle types and sizes.

9. Warranty and Support

Nuliie products are manufactured with high-quality materials and undergo strict quality control. This product comes with a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please refer

to your purchase receipt for specific warranty terms and duration.
For technical support, troubleshooting assistance, or warranty claims, please contact Nuliie Customer Service through the retailer where you purchased the product or visit the official Nuliie website for contact information.

Contact Information:

Website: Nuliie Official Page (via Amazon)

Email: [Refer to product packaging or official website]

Phone: [Refer to product packaging or official website]

Please have your model number (NUBW001) and proof of purchase ready when contacting support.

© 2025 Nuliie. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question