MOKKOM MK-600B

MOKKOM Automatic Nut Milk Maker (Model MK-600B) Instruction Manual

Your guide to creating fresh, homemade plant-based beverages.

1. Important Safety Information

Please read all instructions carefully before using the MOKKOM Automatic Nut Milk Maker. Retain this manual for future reference.

- Always ensure the appliance is placed on a stable, flat, and dry surface.
- Do not immerse the main unit or power cord in water or other liquids.
- Keep hands and utensils away from the moving blades during operation to prevent injury.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- The appliance features a safety mechanism that automatically powers off when the lid is opened during operation.

2. Product Overview

The MOKKOM Automatic Nut Milk Maker is designed for convenient preparation of various plant-based milks and beverages. It features a compact design and multiple functions.





Image: The MOKKOM Automatic Nut Milk Maker in green, showcasing its sleek design and integrated control panel.



Image: The MOKKOM Nut Milk Maker demonstrating its versatility by being surrounded by various homemade beverages it can produce, including juices, different nut milks, and baby food.

Components:

- Main Unit with Stainless Steel Liner
- Lid with Safety Lock
- Ergonomic Handle

- Control Panel with Function Buttons
- 4-Leaf Stainless Steel Blade

3. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, clean the interior of the main unit and the lid with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior with a damp cloth. Ensure the power cord connection area remains dry.
3. **Placement:** Place the nut milk maker on a dry, stable, and level surface, away from heat sources and direct sunlight.
4. **Close the Lid Correctly:** Ensure the lid is properly aligned and securely closed. The safety mechanism prevents operation if the lid is not correctly positioned.



Image: Visual guide on how to correctly close the lid, highlighting the proper alignment for secure operation.

4. Operating Instructions

Basic Operation:

1. **Add Ingredients:** Place your desired nuts, grains, or seeds into the stainless steel liner. Refer to specific recipes for recommended quantities.
2. **Add Water:** Pour water into the liner, ensuring it is between the minimum and maximum fill lines.
3. **Secure Lid:** Close the lid firmly until it clicks into place.
4. **Select Mode:** Press the 'Menu' button to cycle through the available functions:
    - **Room Temp:** For chilled beverages like almond milk, juices, and smoothies.
    - **Warm (140°F):** For warm beverages such as oat milk.
    - **Hot (212°F):** For hot beverages like soy milk, rice milk, and hot chocolate.*Note: You must select 'Hot 212°F' when making soy milk.*
    - **Boil Water:** Heats water to boiling point.
    - **Self Clean:** Initiates a 90-second rinse cycle.
5. **Start Cycle:** Once the desired mode is selected, press the 'Start/Cancel' button to begin the process.
6. **Delay Start:** To use the delay function, select your desired mode, then press the 'Delay Time' button to choose between 7, 9, or 11 hours. Press 'Start/Cancel' to confirm. The machine will begin operation after the set delay.
7. **Keep Warm:** After hot beverage cycles, the machine can keep the contents warm for up to 2 hours.



Image: A three-panel illustration demonstrating the initial steps of operation: adding nuts/grains, adding water, and selecting the desired mode on the control panel.



Image: The control panel of the MOKKOM Nut Milk Maker, illustrating the three basic temperature modes: Room Temp, Warm (140°F), and Hot (212°F).




Image: A visual representation of the delay start function, showing how to set the machine to prepare beverages after 7, 9, or 11 hours, allowing for fresh morning drinks.

Recipe Examples:

The MOKKOM Nut Milk Maker is designed to produce smooth, unfiltered plant-based milks due to its powerful grinding mechanism.




Image: An example recipe for almond milk, detailing ingredients such as raw almonds, pitted dates, vanilla extract, salt, and water, alongside the MOKKOM Nut Milk Maker.



Image: An example recipe for cashew milk, detailing ingredients such as raw cashews, maple syrup, salt, and water, alongside the MOKKOM Nut Milk Maker.



Image: An example recipe for hot chocolate, detailing ingredients such as almond milk, cacao powder, cinnamon powder, and coconut sugar, with a finished drink.



Image: An example recipe for soy milk, detailing ingredients such as soybeans, pitted date, maple syrup or honey, and water, with a note to use the 'Hot 212°F' setting.

Product Demonstration Video:

Your browser does not support the video tag.

Video: A demonstration of the MOKKOM Automatic Nut Milk Maker in use, showcasing its features and the process of making various beverages. This video is provided by the seller.

5. Maintenance and Cleaning

Proper cleaning and maintenance ensure the longevity and optimal performance of your nut milk maker.

1. **Self-Clean Function:** After use, add a small amount of water and a drop of dish soap to the liner. Select the 'Self Clean' mode for a quick 90-second rinse cycle.
2. **Manual Cleaning:** For thorough cleaning, unplug the appliance. Carefully hand wash the interior stainless steel liner and the lid with warm, soapy water. Use a soft brush if necessary to clean around the blades. *Caution: Blades are sharp.*
3. **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scourers.
4. **Drying:** Ensure all parts are completely dry before storing. It is recommended to turn the unit upside down to allow the interior to air dry.
5. **Storage:** Store the appliance in a dry place.



Image: An illustration emphasizing the smooth, integrally formed 304 stainless steel liner and the convenience of the self-clean function, indicating easier cleaning and reduced dirt accumulation.

6. Troubleshooting

If you encounter issues with your MOKKOM Nut Milk Maker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Lid not properly closed; Power outage.	Ensure power cord is securely plugged in. Close the lid firmly until it clicks. Check household power supply.
Operation stops unexpectedly.	Lid opened during operation; Overheating protection activated.	Ensure lid remains closed during operation. If overheated, unplug and allow to cool for 15-20 minutes before restarting.
Milk consistency is too thick/thin.	Incorrect ingredient-to-water ratio.	Adjust the amount of ingredients or water according to desired consistency and recipe guidelines.
Unusual noise during operation.	Ingredients too hard or too much; Appliance not stable.	Ensure ingredients are suitable for blending. Check if the appliance is on a stable, flat surface.




Image: A visual explanation of the safety protection feature, showing that the appliance automatically powers off if the lid is opened during operation.

7. Specifications

- **Brand:** MOKKOM
- **Model Name:** MK-600B
- **Capacity:** 20 Fluid Ounces (600ml)
- **Color:** Green
- **Material:** Stainless Steel (Liner)
- **Power Source:** Corded Electric
- **Wattage:** 500 watts
- **Special Feature:** Automatic Cleaning, Delay Start
- **Product Dimensions:** 10.24 x 7.68 x 6.5 inches
- **Item Weight:** 1.25 pounds
- **UPC:** 768461940487

8. Warranty and Support

MOKKOM products are manufactured to high-quality standards. For any warranty claims or technical support, please refer to your purchase documentation or contact the retailer where the product was purchased. Keep your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question