

Nasitip Nasitip-motor-YC186-Black

Nasitip 36V Electric Dirt Bike for Kids Instruction Manual

Model: Nasitip-motor-YC186-Black
Brand: Nasitip

1. SAFETY INFORMATION

Read all instructions carefully before operating the electric dirt bike. Failure to follow safety guidelines may result in serious injury.

- **Age Recommendation:** Suitable for users aged 14 years and older (Manufacturer Minimum Age: 168 months).
- **Weight Limit:** Maximum load capacity is 175 lbs (80 kg).
- **Protective Gear:** Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads, when riding.
- **Adult Supervision:** Adult supervision is recommended, especially for younger riders or those new to electric dirt bikes.
- **Operating Environment:** Ride in safe, open areas away from traffic, pedestrians, and obstacles. Avoid riding on public roads.
- **Pre-Ride Check:** Before each ride, ensure brakes are functioning correctly, tires are properly inflated, and all fasteners are secure.
- **Battery Safety:** Do not tamper with the battery or charger. Use only the provided charger.

2. WHAT'S IN THE BOX

The Nasitip 36V Electric Dirt Bike package includes the following components:

- 1x Electric Motorcycle
- 1x User Manual
- 1x Charger

3. PRODUCT SPECIFICATIONS

Brand	Nasitip
Model Number	Nasitip-motor-YC186-Black
Motor	350W Brushless Motor (Black model)
Battery	36V 7AH Rechargeable Battery System

Max Speed	Up to 15.5 MPH
Max Load	175 lbs (80 kg)
Dimensions (L x W x H)	49.2" x 24.8" x 32.4"
Item Weight	80 Pounds
Tires	High-quality pneumatic tires
Brakes	Disc brakes (Front + Back)
Suspension	Full metal spring suspension
Seat	Leather seat
Lights	Bright LED headlights
Material	Iron, Polypropylene



Image: Nasitip Electric Dirt Bike with key dimensions (49.2"L x 24.8"W x 32.4"H) and suitable age (14+ years) indicated. The bike is shown

on various terrains including field land, masonry road, grass, and plastic track.

Electric Powered Dirt Bike-Off-Road



Image: Detailed view highlighting various features of the Nasitip Electric Dirt Bike. These include ASTM Certification, a bright LED headlight, a comfortable leather seat, robust spring suspension, a non-chain version with brushless motors, and two pneumatic tires for off-road performance.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Nasitip Electric Dirt Bike:

1. Remove the dirt bike from its packaging.
2. Assemble the bike according to the included instructions.
3. Charge the battery using the provided charger. The first charge should be approximately 12 hours.

Your browser does not support the video tag.

Video: An installation guide for the Nasitip 36V Dirt Bike, demonstrating the assembly process step-by-step. This video is provided by Nasitip Direct (Seller).

Your browser does not support the video tag.

Video: An assembly introduction for an electric motorcycle, showing the unpacking and initial setup of components. This video is provided by SHENZHEN SHENGLIXING TRADE CO., LTD (Vendor).

5. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and follow these steps for safe operation:

1. Once charged, turn on the bike by pressing the power button.
2. Adjust the speed setting to an appropriate level for the rider's skill. The bike features adjustable speed settings.
3. Have the rider sit on the bike, place their feet on the footpegs, and grip the handlebars.
4. The rider can then twist the throttle to accelerate and use the disc brakes to slow down or stop.

5. Utilize the bright LED headlights for visibility, especially in low-light conditions.

1 Rear Brake

4 Power Switch

2 Front Brake

5 Power Display

3 Throttle for Accelerate

6 Front Light Button



Image: Close-up of the Nasitip Electric Dirt Bike's handlebar controls, detailing the rear brake, front brake, throttle for acceleration, power switch, power display, and front light button.

REALLY POWERFUL DIRT BIKE



36V 7AH Battery



1-15.5MPH(0-25KM/H)



175 lb (80 kg) Max Load



**350W Brushless Motor:
More Using Years
(7-10 years),
Most Silent**



Image: Key performance features of the Nasitip Electric Dirt Bike are displayed, including a 36V 7AH battery, variable speed from 1-15.5 MPH, a maximum load of 175 lbs, and a 350W brushless motor known for quiet operation and longer service life.

Your browser does not support the video tag.

Video: A demonstration of the 36V Electric Dirt Bike in use, showcasing its speed and handling. This video is provided by KERRY YOO (Seller).

Your browser does not support the video tag.

Video: An electric dirt bike for kids, suitable for ages 3-10, demonstrating its features and ride. This video is provided by ApolloUS (Seller).

6. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your dirt bike:

- **Cleaning:** Wipe down the bike with a damp cloth after each use. Avoid using high-pressure water jets directly on electrical components.
- **Battery Care:** Charge the battery fully after each use. Store the bike in a cool, dry place when not in use, and charge the battery at

least once a month to maintain its health.

- **Tire Pressure:** Regularly check and maintain the recommended tire pressure for optimal performance and safety.
- **Brake Inspection:** Periodically inspect the disc brakes for wear and tear. Adjust or replace brake pads as necessary.
- **Fasteners:** Ensure all nuts, bolts, and fasteners are tightened securely before each ride.

7. TROUBLESHOOTING

If you encounter issues with your dirt bike, refer to the following common troubleshooting tips:

- **Bike Not Turning On:** Ensure the power switch is in the 'ON' position and the battery is charged. Check all connections.
- **Reduced Performance/Speed:** This may indicate a low battery charge. Fully charge the battery. Also, check tire pressure.
- **Brakes Not Responding:** Inspect brake cables for proper tension and ensure brake pads are not excessively worn. Adjust or replace as needed.
- **Unusual Noises:** Stop riding immediately and inspect the bike for loose parts or obstructions.
- For persistent issues, contact customer support.

8. WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts, please refer to the contact details provided in your product packaging or visit the official Nasitip website.

Always provide your model number (Nasitip-motor-YC186-Black) and purchase date when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

