

[Manuals.plus](#) /

› [Bruni](#) /

› Bruni Screen Protector compatible with Bafang DP C220 Instruction Manual

Bruni Bruni Basics-Clear 4061187915859

Bruni Screen Protector for Bafang DP C220 Instruction Manual

Model: Bruni Basics-Clear 4061187915859

1. PRODUCT OVERVIEW

The Bruni Screen Protector is designed to provide crystal clear protection for your Bafang DP C220 display. Made from highly transparent PET material, it offers scratch resistance and maintains the original touch sensitivity and display clarity.



Figure 1.1: Bruni Screen Protector packaging and the protector film. The packaging highlights easy installation, impact and scratch resistance, and "Made in Germany".

DISPLAY PROTECTION IN PREMIUM QUALITY



Figure 1.2: An illustration emphasizing the premium quality display protection, showing sparks as a metal object impacts a surface, symbolizing durability.

BENEFITS



Simple
installation



Sensitive
Touch



Safe and
scratch-resistant



Clear
Colors



Made in
Germany



Maximum
Shatterproof

Figure 1.3: Key benefits of the Bruni screen protector, including simple installation, sensitive touch, scratch resistance, clear colors, German manufacturing, and maximum shatterproof properties.

Features:

- Accurately developed and compatible with Bafang DP C220.


- Made of scratch-resistant, highly transparent PET material.
- Easy, bubble-free application and residue-free removal.
- Optimal edge adhesion, preventing slipping.
- Optimized for touch displays, ensuring unadulterated display content and usability.
- Manufactured in Germany.

2. SETUP AND INSTALLATION

Proper installation is crucial for optimal performance and longevity of the screen protector. Follow these steps carefully.



Figure 2.1: Contents of the Bruni screen protector package, including the screen protector film, a mounting tool, a microfiber cloth, and detailed installation instructions.



SUPER EINFACHE MONTAGE

In nur 3 Schritten. Eine Anleitung liegt dem Lieferumfang bei.

Figure 2.2: A visual guide demonstrating the application of the screen protector, highlighting the "Super Simple Installation" process in just three steps.

Installation Steps:

1. **Clean the Display:** Use the provided microfiber cloth to thoroughly clean the Bafang DP C220 display. Ensure there are no dust particles, smudges, or fingerprints. For stubborn dirt, a screen cleaning solution can be used, but ensure the screen is completely dry before proceeding.
2. **Align the Protector:** Carefully peel off a small portion of the protective layer from the screen protector. Align the protector with the edges of your Bafang DP C220 display. Take your time to ensure precise alignment, especially around any cutouts or sensors.
3. **Apply and Smooth:** Slowly lower the screen protector onto the display, using the mounting tool (squeegee) to gently push out any air bubbles as you go. Work from one end to the other, applying even pressure. If bubbles persist, gently lift the nearest edge of the protector and re-apply, pushing the air out.
4. **Final Touches:** Once the protector is fully applied, use the microfiber cloth to wipe down the surface, removing any remaining smudges and ensuring a clean, bubble-free finish.

Note: The screen protector is designed for bubble-free application. If bubbles appear, they can often be smoothed out by gently pushing them towards the nearest edge with the provided tool.

3. OPERATING WITH THE SCREEN PROTECTOR

The Bruni screen protector is designed to integrate seamlessly with your Bafang DP C220, maintaining full functionality.



Figure 3.1: An image depicting a key attempting to scratch a screen protected by the Bruni film, demonstrating its scratch-resistant properties.

Schneller-Touch

Blitzschnell,
hochsensibel und
präzise



Figure 3.2: A close-up of a finger interacting with a digital display, highlighting the screen protector's "Faster-Touch" capability, ensuring lightning-fast, highly sensitive, and precise touch response.

Echte Farben

Klare Schutzfolie, keine Farbabschwächung



Figure 3.3: An image of a smartphone screen displaying vivid colors, demonstrating that the clear protective film does not attenuate colors, ensuring "Real Colors" are visible.

Key Operational Aspects:

- **Touch Sensitivity:** The screen protector is optimized for touch displays, ensuring no impairment of the usability. Your touch commands will be registered accurately and quickly.
- **Display Clarity:** The highly transparent material ensures an unadulterated display of the screen contents. Colors remain vibrant and true.
- **Protection:** The film provides a protective barrier against scratches, scuffs, and minor impacts, preserving the original display of your Bafang DP C220.

4. MAINTENANCE

Maintaining your screen protector will ensure its clarity and protective qualities over time.

- **Cleaning:** Use a soft, lint-free cloth (like the one provided) to gently wipe the screen protector. For smudges or fingerprints, a slightly damp cloth with water or a mild, electronics-safe cleaning solution can be used. Avoid harsh chemicals or abrasive materials.
- **Avoid Sharp Objects:** While the protector is scratch-resistant, extreme pressure or very sharp objects can still damage it. Avoid placing your device face down on rough surfaces or in pockets with keys and coins.
- **Replacement:** If the screen protector becomes heavily scratched, discolored, or starts peeling at the edges, it is recommended to replace it to maintain optimal display clarity and protection. The protector can be removed without leaving residue.

5. TROUBLESHOOTING

Common issues and their solutions related to the screen protector.

Problem	Possible Cause	Solution
Bubbles under the protector	Dust particles or trapped air during installation.	Gently lift the nearest edge of the protector and use the squeegee to push the air/dust out. Ensure the screen is clean before re-applying.
Protector not adhering properly at edges	Improper alignment or dust/oil on the display edges.	Ensure the display is thoroughly clean and dry before application. Re-align carefully. If the issue persists, the protector might need replacement.
Reduced touch sensitivity	Incorrect installation or a faulty protector (rare).	Ensure the protector is applied smoothly without air gaps. If the problem persists, contact customer support.
Scratches on the protector	Normal wear and tear or contact with sharp objects.	The protector is doing its job by absorbing scratches instead of your device's screen. Replace the protector for optimal clarity.

6. SPECIFICATIONS

Attribute	Detail
Product Dimensions	2.17 x 1.57 x 0.5 inches (packaging) / 2.2"L x 1.6"W (film)
Item Weight	0.212 ounces
Model Number	Bruni Basics-Clear 4061187915859
Special Features	Very easy to apply, compatible with Bafang DP C220, Residue-free removable, Made in Germany, crystal clear Protector Film
Color	Basics-Clear
Manufacturer	atFoliX GmbH

Attribute	Detail
Country of Origin	Germany
Compatible Devices	Bafang DP C220
Material	Polyethylenterephthalat
Item Hardness	4H
Number of Items	2

7. WARRANTY INFORMATION

Bruni products are manufactured with high quality standards. For specific warranty details, please refer to the information provided with your product packaging or contact the manufacturer directly.

- **Return Policy:** The product has a 30-day refund/replacement return policy as per Amazon's buybox winner information.
- **Manufacturer:** atFoliX GmbH, Germany.

8. CUSTOMER SUPPORT

For further assistance, questions, or support regarding your Bruni Screen Protector, please contact the manufacturer or seller.

- **Seller:** atFoliX Germany
- **Amazon Seller Page:** [Visit Seller Page](#)
- **General Inquiries:** Refer to the contact information on the product packaging or the manufacturer's official website.

© 2023 Bruni. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question