

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Midea](#) /

› [Midea X6 3-in-1 Wet & Dry Self-Cleaning Floor Cleaner Instruction Manual](#)

Midea MWD-X6

Midea X6 3-in-1 Wet & Dry Self-Cleaning Floor Cleaner

MODEL: MWD-X6

Introduction

Thank you for choosing the Midea X6 3-in-1 Wet & Dry Self-Cleaning Floor Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.



Figure 1: Midea X6 3-in-1 Wet & Dry Self-Cleaning Floor Cleaner

Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. This includes:

- Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not handle the charger or appliance with wet hands.
- Exercise extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Ensure the appliance is switched off before connecting or disconnecting the charger.
- Store the appliance indoors in a cool, dry place.

Product Overview

The Midea X6 is a versatile 3-in-1 wet and dry floor cleaner designed for efficient cleaning of various hard floor surfaces. Key features include:

- **3-in-1 Cleaning:** Vacuums, washes, and mops simultaneously.
- **Dual Tank System:** Separate tanks for clean water (600ml) and dirty water (400ml) ensure continuous cleaning with fresh water.
- **Self-Cleaning Function:** Automatic cleaning cycle for the roller brush.
- **Cordless Operation:** Powered by a 2500 mAh Lithium-ion battery for up to 20 minutes of runtime.
- **Multi-Surface Capability:** Safe and effective for hard floors, wood, granite, and ceramic tiles.

SISTEMA DEL SERBATOIO



Figure 2: Dual Tank System (600ml Clean Water, 400ml Dirty Water)



Figure 3: Included Accessories (Charging Base, Cleaning Brush)

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Assembly:** Insert the handle into the main body of the cleaner until it clicks securely into place.
3. **Initial Charge:** Place the cleaner on its charging base. Connect the power adapter to the charging base and plug it into a wall outlet. Allow the unit to fully charge before first use. The indicator light will show charging status.
4. **Fill Clean Water Tank:** Remove the clean water tank (usually located at the top or front). Fill it with clean tap water up to the MAX line. For enhanced cleaning, you may add a small amount of Midea-approved floor cleaning solution. Do not use foaming detergents. Reattach the tank securely.

Operating Instructions

1. **Power On:** Press the Power button on the handle to turn on the cleaner.
2. **Select Mode:** Use the Mode button to switch between different cleaning modes (if available). Refer to the display for the selected mode.
3. **Start Cleaning:** Tilt the cleaner back to engage the roller brush and begin cleaning. Move the cleaner slowly over the floor surface to allow it to vacuum, wash, and dry effectively.
4. **Monitor Tanks:** The cleaner will alert you when the dirty water tank is full or the clean water tank is empty.
5. **Empty Dirty Water Tank:** When prompted, turn off the cleaner, remove the dirty water tank, and empty its contents. Rinse the tank thoroughly before reattaching.
6. **Power Off:** Press the Power button again to turn off the cleaner when finished.

**PULISCE E ASPIRA CON
UN SOLO GESTO**



Figure 4: Wet and Dry Cleaning in One Pass

FUNZIONAMENTO INDIVIDUALE



Figure 5: Control Panel for Mode Selection and Self-Cleaning



Figure 6: Effective on Multiple Floor Surfaces

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Midea X6 cleaner.

- 1. Self-Cleaning Cycle:** After each use, place the cleaner on its charging base and press the Self-Cleaning button. The cleaner will perform an automatic cycle to clean the roller brush.
- 2. Clean Dirty Water Tank:** Always empty and rinse the dirty water tank after each use to prevent odors and bacterial growth.
- 3. Clean Roller Brush:** Even with the self-cleaning function, it is recommended to periodically remove and manually clean the roller brush to remove any tangled hair or debris. Use the provided cleaning brush.
- 4. Clean Filter:** The HEPA filter should be cleaned regularly (e.g., once a month, depending on usage). Tap out loose dirt or rinse under running water. Ensure it is completely dry before reinserting.
- 5. Store Properly:** Store the cleaner on its charging base in a dry, cool place.



Figure 7: Self-Cleaning System in Action

LA POTENTE SPAZZOLA PULISCE ANCHE LE MACCHIE PIU' OSTINATE



Figure 8: Roller Brush for Stubborn Stains

Troubleshooting

If you encounter issues with your Midea X6 cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power / Not Turning On	Battery depleted; Unit not charged; Power button not pressed correctly.	Charge the unit fully; Ensure the power button is pressed firmly.
Poor Suction / Streaks on Floor	Dirty water tank full; Clean water tank empty; Roller brush clogged; Filter clogged.	Empty dirty water tank; Refill clean water tank; Clean roller brush; Clean or replace filter.
Unpleasant Odor	Dirty water tank not cleaned properly; Roller brush needs cleaning.	Thoroughly clean dirty water tank and roller brush after each use.
Self-Cleaning Not Working	Insufficient water in clean tank; Unit not properly docked.	Ensure clean water tank is filled; Place unit correctly on charging base.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Specification
Brand	Midea
Model Number	MWD-X6
Color	White/Black
Product Dimensions (L x W x H)	29 x 24 x 119 cm
Item Weight	3.9 Kilograms
Clean Water Tank Capacity	600 Milliliters
Dirty Water Tank Capacity	400 Milliliters
Power	190 Watts
Noise Level	80 Decibels
Runtime	Up to 20 minutes
Battery Type	1 Lithium-ion (included)
Filter Type	HEPA Filter
Special Features	Wet/Dry, Self-cleaning system, Cordless
Surface Recommendation	Hard floor, stairs, wood, granite

Warranty and Support

Midea products are manufactured to the highest quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Midea website. Please have your model number (MWD-X6) and proof of purchase ready when contacting support.