realme Buds Wireless 3

realme Buds Wireless 3 Bluetooth Headphones User Manual

Model: Buds Wireless 3 (Rma2119)

1. Introduction

Thank you for choosing the realme Buds Wireless 3 Bluetooth Headphones. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before use to ensure optimal performance and longevity of your headphones.



Image: realme Buds Wireless 3 headphones, Pure Black variant.

The realme Buds Wireless 3 are designed for an immersive audio experience, featuring a 13.6mm Dynamic Bass Driver, 30dB Active Noise Cancellation, and 360° Spatial Audio. They offer up to 40 hours of playback and support dual device connection for seamless switching.

2. What's in the Box

- realme Buds Wireless 3 Headphones
- Eartips (various sizes)
- USB Charging Cable
- User Manual

3. Setup

3.1 Charging the Headphones

Before first use, fully charge your realme Buds Wireless 3. Connect the USB charging cable to the charging port on the neckband and to a power source. The indicator light will show charging status.



Image: Close-up of the realme Buds Wireless 3 neckband, highlighting the charging port and internal battery components.

- A 10-minute charge provides approximately 25 hours of playback.
- A full charge offers up to 40 hours of total battery life.

3.2 Bluetooth Pairing

To connect your headphones to a device:

1. Ensure the headphones are charged and powered on.
2. Activate Bluetooth on your smartphone, tablet, or laptop.
3. The headphones will automatically enter pairing mode when powered on for the first time or when disconnected from a previous device.
4. On your device's Bluetooth settings, select "realme Buds Wireless 3" from the list of available devices.
5. For Android devices, Google Fast Pairing may automatically detect the headphones for quick connection.

4. Operating Instructions

4.1 Controls

The realme Buds Wireless 3 feature integrated push-button controls on the neckband for easy management of audio and calls.



Image: Detailed view of the control buttons on the realme Buds Wireless 3 neckband.

- **Volume Up/Down:** Press '+' or '-' buttons.
- **Play/Pause:** Single press the multi-function button (center button).
- **Next Track:** Double press the multi-function button.
- **Previous Track:** Triple press the multi-function button.
- **Answer/End Call:** Single press the multi-function button.
- **Reject Call:** Press and hold the multi-function button.
- **Activate Voice Assistant:** Press and hold the multi-function button (specific duration may vary).

4.2 Active Noise Cancellation (ANC)

The headphones feature 30dB Active Noise Cancellation to reduce ambient noise. This function can be toggled on or off using the dedicated button or through the realme Link app.



Image: Visual representation of Active Noise Cancellation technology.

4.3 360° Spatial Audio Effect

Experience an immersive audio environment with the 360° Spatial Audio Effect, providing a theatre-like listening experience. This feature can be activated via the realme Link app.




Image: A user experiencing the 360° Spatial Audio effect with the headphones.

4.4 13.6mm Dynamic Bass Driver

The integrated 13.6mm Dynamic Bass Driver delivers powerful and clear bass response for an enhanced audio experience.



Image: Detailed view of the 13.6mm Dynamic Bass Driver component.

4.5 45ms Ultra-low Latency for Gaming

For a smooth gaming experience, activate the 45ms ultra-low latency mode. This reduces audio delay, ensuring synchronized sound with on-screen action.



Image: A smartphone screen showing a racing game, with the realme Buds Wireless 3 connected, illustrating low-latency gaming.

4.6 Dual Device Connection

The headphones support simultaneous connection to two devices, allowing for seamless switching between them without manual re-pairing.



Image: The realme Buds Wireless 3 neckband positioned between a smartphone and a tablet, indicating dual device connectivity.

4.7 realme Link App

Download the realme Link app for additional features and customization options:




Image: Screenshot of the realme Link app interface displaying various settings for the Buds Wireless 3, including noise control options.

- Download Firmware Updates
- Select EQ Presets
- Volume Enhancements
- Switch Sound Modes (e.g., ANC, Transparency, Normal)
- 360° Spatial Audio Toggle

5. Maintenance

5.1 IP55 Dust and Water Resistance

The realme Buds Wireless 3 are rated IP55 for dust and water resistance, making them suitable for workouts and outdoor activities. Avoid submerging the headphones in water.



Image: realme Buds Wireless 3 headphones with water droplets, demonstrating their IP55 dust and water resistance.

5.2 Cleaning and Storage

- Clean the earbuds and neckband regularly with a soft, dry cloth.
- Remove and clean eartips with mild soap and water, then dry thoroughly before reattaching.
- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

- **No Power:** Ensure the headphones are fully charged.
- **Cannot Pair:** Ensure Bluetooth is enabled on your device and the headphones are in pairing mode. Try restarting both devices.
- **No Sound:** Check volume levels on both the headphones and the connected device. Ensure the headphones are correctly paired.
- **Poor Sound Quality:** Ensure there are no obstructions between the headphones and the connected device. Try

moving closer to the device. Check for firmware updates via the realme Link app.

- **Call Quality Issues:** Ensure the microphone is not obstructed. In noisy environments, ANC may affect call clarity for the other party; try disabling it.

7. Specifications

Feature	Specification
Model Name	Buds Wireless 3
Driver Size	13.6mm Dynamic Bass Driver
Noise Control	30dB Active Noise Cancellation
Spatial Audio	360° Spatial Audio Effect
Bluetooth Version	5.3
Bluetooth Range	10 Metres
Battery Life	Up to 40 Hours
Fast Charging	10 mins charge for 25 hours playback
Latency	45ms (Ultra-low latency mode)
Water Resistance	IP55 Dust and Water Resistant
Impedance	32 Ohms
Frequency Range	20-20000 Hz
Control Type	Push Button, Call Control
Material	Plastic
Weight	30 Grams

8. Warranty Information

The realme Buds Wireless 3 come with a**1-year manufacturer warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

9. Support

For further assistance, technical support, or warranty claims, please contact realme customer service through their official website or the realme Link app. You may also refer to the official realme support channels for FAQs and additional resources.

© 2023 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question