

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Nerf F9704

NERF Pro Stryfe X Dart Semi-Auto Blaster Instruction Manual

Model: F9704 | Brand: Nerf

INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your NERF Pro Stryfe X Dart Semi-Auto Blaster. Please read this manual thoroughly before operating the blaster and retain it for future reference. The Nerf Pro Stryfe X blaster is designed for high-performance play, featuring a semi-automatic firing mechanism, rechargeable LiPo battery, and specialized AccuStrike half-length darts for enhanced accuracy.

IMPORTANT SAFETY INFORMATION

WARNING: Do not aim at eyes or face. Use of eyewear is recommended for players and people within range. Use only official Nerf darts. Other darts may not meet safety standards. Do not modify darts or blaster. Impact from darts may cause temporary marks on skin. Ages 14 and up. This is not a toy. Read instructions before use for important safety information.



Image: The product packaging highlighting the 14+ age recommendation and safety warnings regarding eye protection and dart usage.



Image: A close-up of the clear protective eyewear included with the blaster, emphasizing the importance of eye protection during use.

WHAT'S IN THE BOX

Your NERF Pro Stryfe X Dart Semi-Auto Blaster package includes the following components:

- NERF Pro Stryfe X Blaster
- Rechargeable 11.1V 1000mAh LiPo Battery
- USB-A to USB-C Charging Cable
- 30 Nerf AccuStrike Half-Length Darts
- 15-Dart Magazine
- Protective Eyewear
- Instruction Manual (this document)



Image: All components of the NERF Pro Stryfe X Blaster package laid out, including the blaster, 30 darts, 15-dart magazine, rechargeable battery, USB charging cable, and protective eyewear.

SETUP

1. Charging the Battery

The NERF Pro Stryfe X Blaster is powered by a rechargeable 11.1V 1000mAh LiPo battery.

1. Locate the battery compartment on the blaster.
2. Insert the rechargeable LiPo battery into the compartment.
3. Connect the USB-A to USB-C charging cable to the battery and a compatible USB-A wall charger (not included).
4. Allow the battery to fully charge before first use. Refer to the battery's specific charging indicators for completion.

RECHARGEABLE LiPo BATTERY



Image: A detailed view of the rechargeable LiPo battery being placed into its designated compartment on the blaster.

2. Loading the Magazine

The blaster uses 15-dart magazines and AccuStrike Half-Length darts.

1. Ensure the darts are clean and undamaged.
2. Carefully insert the 30 Nerf AccuStrike Half-Length darts into the 15-dart magazine, ensuring they are properly seated.
3. Once loaded, insert the magazine firmly into the blaster's magazine well until it clicks into place.



Image: A hand demonstrating the proper way to insert the 15-dart magazine into the blaster.



Image: The blaster with its magazine partially inserted, illustrating the loading process.

OPERATING INSTRUCTIONS

1. Powering On and Firing

1. Ensure the battery is charged and installed, and the magazine is loaded and inserted.
2. Put on the protective eyewear before operating the blaster.
3. Locate the power switch (if applicable) and turn the blaster ON.
4. Hold the blaster firmly with both hands.
5. Press and hold the acceleration trigger (if present) to spin up the flywheels.
6. Pull the main trigger to fire a dart. The blaster is semi-automatic, meaning one dart will fire each time the trigger is pulled while the acceleration trigger is held.
7. The blaster can achieve velocities of up to 150 feet per second (FPS).



Image: A user demonstrating the firing action of the blaster, with a dart visibly leaving the barrel, highlighting its high velocity.



Image: A user aiming the blaster, demonstrating proper stance and the use of protective eyewear during operation.

MAINTENANCE

1. Blaster Care

- Keep the blaster clean and free of dirt, dust, and debris. Use a dry cloth to wipe down the exterior.
- Do not submerge the blaster in water or any other liquids.
- Store the blaster in a cool, dry place away from direct sunlight and extreme temperatures.

2. Dart Care

- Only use official Nerf AccuStrike Half-Length darts. Using unofficial or damaged darts can impair performance and potentially damage the blaster.
- Inspect darts for damage (tears, bends, deformities) before use. Discard damaged darts.
- Keep darts clean and dry.



Image: A close-up view of the Nerf AccuStrike Half-Length darts, highlighting their design for accuracy and durability.

3. Battery Care

- Always use the provided USB-A to USB-C charging cable.
- Do not overcharge or completely drain the LiPo battery. Follow recommended charging practices.
- If the blaster will not be used for an extended period, remove the battery and store it separately in a cool, dry place.
- Do not expose the battery to extreme heat or cold.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Blaster not firing or weak firing.	<ul style="list-style-type: none">• Battery low or not charged.• Magazine not fully inserted.• Darts jammed or damaged.• Acceleration trigger not held down.	<ul style="list-style-type: none">• Charge the battery fully.• Ensure magazine is clicked into place.• Clear any jams and use undamaged darts.• Hold down the acceleration trigger before pulling the main trigger.
Darts not feeding properly.	<ul style="list-style-type: none">• Magazine incorrectly loaded.• Darts are not official AccuStrike Half-Length darts.• Darts are worn or damaged.	<ul style="list-style-type: none">• Reload magazine correctly, ensuring darts are seated.• Use only official Nerf AccuStrike Half-Length darts.• Replace worn or damaged darts.
Battery not charging.	<ul style="list-style-type: none">• Charging cable not properly connected.• USB-A wall charger is faulty or not providing enough power.• Battery is damaged.	<ul style="list-style-type: none">• Ensure secure connections for the charging cable.• Try a different USB-A wall charger.• Contact customer support if battery is suspected to be damaged.

SPECIFICATIONS

Feature	Detail
Model Number	F9704
Product Dimensions	2.87 x 17.52 x 8.5 inches
Item Weight	2.2 pounds
Recommended Age	14 years and up
Battery Type	11.1V 1000mAh LiPo (Rechargeable, included)
Dart Type	Nerf AccuStrike Half-Length Darts
Dart Capacity	15 darts per magazine (30 darts included)
Firing Velocity	Up to 150 feet per second (FPS)
Manufacturer	Hasbro
Release Date	September 22, 2023

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to purchase replacement parts, please visit the official Nerf website or contact Hasbro customer service.





Online Support: www.hasbro.com/en-us/consumer-care

Please have your product model number (F9704) and purchase information ready when contacting support.

PRODUCT VIDEOS

No official seller videos were found in the provided product data that meet the embedding criteria (e.g., specific video URLs with creator_type: "Seller"). Please refer to the manufacturer's official channels for product demonstration videos.

Related Documents

	<p>Nerf Rough Cut 2X4 Elite Blaster User Manual</p> <p>User manual for the Nerf Rough Cut 2X4 Elite Blaster, detailing its features, operation, and safety precautions. Includes instructions for loading, single fire, and slam fire modes.</p>
	<p>Nerf Roblox Arsenal Pulse Laser Blaster Instructions</p> <p>Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.</p>
	<p>NERF Modulus ECS-10 Blaster: Instructions and Safety Guide</p> <p>Official instructions and safety information for the NERF Modulus ECS-10 blaster by Hasbro. Learn how to load, fire, maintain, and safely use your NERF blaster.</p>
	<p>Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions</p> <p>A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.</p>

Documents - Nerf – F9704

[pdf] Instructions



Board Game Rules Toy Instructions Hasbro F9704US20 INST NER PRO Super Stryfe 526168 FAR assets us 01 kc usercontent 443 500e0a65 283d 00ef 33b2 7f1f20488fe2 b5e311b8 5e17 400a 8951 4bc2d43008e9 Transformers Legacy Evolution Titan Decepticon Nemesis Figure Adult Collectible 23 5 Nerf Pro X Dart Blaster Battery 30 AccuStrike Half Length Darts Magazine Eyewear ||| CLEARING A JAM REMOVE MAGAZINE FROM BLASTER. OPEN ACCESS DOOR AND REMOVE ANY JAMMED DARTS. CLOSE DOO ... of Hasbro, Inc. 2023 Hasbro. Hasbro, Pawtucket, RI 02861-1059 USA. US/CANADA TEL. 1-800-255-5516. **F9704** PN00086308 ENGINEERED EXCLUSIVELY FOR: NERF PRO ACCUSTRIKE HALF-LENGTH DARTS NERF PRO ACCU... lang:en score:27 filesize: 1.16 M page_count: 2 document date: 2023-05-04