

## Western Digital WDS100T3B0E

# Western Digital WD Blue SN580 NVMe SSD User Manual

**MODEL: WDS100T3B0E**

**Brand: Western Digital**

---

## 1. Introduction

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your Western Digital WD Blue SN580 NVMe Internal Solid State Drive. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

---

## 2. Product Overview

The WD Blue SN580 NVMe SSD is a high-performance internal solid-state drive designed for laptops and desktops, offering fast data transfer speeds and reliable storage. It utilizes PCIe Gen 4.0 technology for enhanced productivity and creative workflows.



Figure 2.1: The WD Blue SN580 NVMe SSD, showing its M.2 2280 form factor and branding.

### Key Features:

- PCIe Gen 4.0 interface for high-speed data transfer, up to 4,150 MB/s read speeds.
- Western Digital's nCache 4.0 technology for efficient handling of large files.
- Slim M.2 2280 form factor, suitable for various system builds.
- Low-power design to optimize laptop battery life.
- NVMe technology for improved application responsiveness during multitasking.
- High endurance rating (up to 900TBW for 2TB model) and a 5-year limited warranty.


### 3. Setup and Installation

Before installation, ensure your system supports M.2 NVMe PCIe Gen 4.0 SSDs. Refer to your motherboard or laptop manufacturer's documentation for compatibility and installation slot location.

#### Installation Steps:

1. **Power Off:** Completely shut down your computer and disconnect all power sources.
2. **Open Case:** Open your computer case or laptop's back panel to access the motherboard.

3. **Locate M.2 Slot:** Identify an available M.2 slot on your motherboard. It typically has a small screw hole at the end.
4. **Insert SSD:** Gently insert the WD Blue SN580 SSD into the M.2 slot at a 30-degree angle. It should slide in smoothly.
5. **Secure SSD:** Once fully seated, push the SSD down until it is parallel with the motherboard. Secure it with the small screw provided with your motherboard or laptop.
6. **Close Case:** Reassemble your computer case or laptop.
7. **Power On:** Connect power and boot your computer.
8. **Initialize and Format:** Once booted, you may need to initialize the new SSD and format it through Disk Management (Windows) or Disk Utility (macOS) before it can be used.



**Available with endurance ratings up to 900TBW(3) (2TB model only)**

(3)TBW (terabytes written) values calculated using JEDEC client workload (JESD219) and vary by product capacity.

Figure 3.1: The WD Blue SN580 SSD securely installed in an M.2 slot on a motherboard.

### **Data Migration:**

The WD Blue SN580 comes with support for Acronis migration software, which can be used to transfer your existing operating system and data to the new SSD. This feature is designed to simplify the upgrade process.



## Acronis Cloud Migration

Migrate data easily to the WD Blue SN580 NVMe SSD with Acronis migration software


*Figure 3.2: Visual representation of data migration using Acronis software.*

### 4. Operating Instructions

Once installed and formatted, your WD Blue SN580 SSD operates like any other storage drive. For optimal performance, ensure your operating system and drivers are up to date.

#### Tips for Optimal Performance:

- **TRIM Command:** Ensure TRIM is enabled in your operating system. This command helps the SSD maintain performance over time by efficiently managing data blocks. Modern operating systems typically enable this by default for SSDs.
- **Firmware Updates:** Periodically check the Western Digital support website for firmware updates for your SN580 SSD. Firmware updates can improve performance, stability, and compatibility.
- **Avoid Full Capacity:** While SSDs can be filled, leaving some free space (e.g., 10-15%) can help maintain performance, especially for write operations.



## PCIe Gen 4.0 SSD available in read speeds of up to 4,150 MB/s<sup>(1)</sup> (1TB and 2TB models)

(1)1 MB/s = 1 million bytes per second. Based on internal testing; performance may vary depending upon host device, usage conditions, drive capacity, and other factors.

*Figure 4.1: A user engaged in creative work, highlighting the productivity benefits of a high-speed SSD.*

## 5. Maintenance

SSDs require less maintenance than traditional hard drives. However, a few practices can help ensure its longevity and performance.

- **No Defragmentation:** Do not defragment an SSD. This is unnecessary and can reduce the lifespan of the drive.
- **Regular Backups:** Always back up important data regularly to another storage device. While SSDs are reliable, data loss can occur due to various factors.
- **Monitor Health:** Use S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology) tools to monitor the health and endurance of your SSD. Many operating systems and third-party utilities offer this functionality.

## 6. Troubleshooting

If you encounter issues with your WD Blue SN580 SSD, consider the following troubleshooting steps:

- **SSD Not Detected:**

- Ensure the SSD is properly seated in the M.2 slot.
- Check BIOS/UEFI settings to confirm the M.2 slot is enabled and configured correctly (e.g., NVMe mode).
- Try the SSD in a different compatible M.2 slot or system if available.

- **Slow Performance:**

- Verify that your system's M.2 slot supports PCIe Gen 4.0 speeds. If it's Gen 3.0, the SSD will operate at Gen 3.0 speeds.
- Ensure TRIM is enabled.
- Check for and install the latest NVMe drivers from Western Digital or your motherboard manufacturer.
- Ensure the SSD is not near full capacity.

- **Operating System Not Booting:**

- If this is a new OS installation, ensure the boot order in BIOS/UEFI is set to the correct drive.
- If migrating an OS, ensure the migration process completed successfully and the bootloader is correctly configured.

For further assistance, refer to the Western Digital support website or contact their customer service.

## 7. Specifications

Feature	Description
Model	WDS100T3B0E (1TB)
Digital Storage Capacity	1000 GB
Hard Disk Interface	NVMe
Connectivity Technology	NVMe
Brand	Western Digital
Special Feature	Acronis migration software
Hard Disk Form Factor	M.2 2280
Hard Disk Description	Solid State Drive
Compatible Devices	Laptop, Desktop, PC
Installation Type	Internal Hard Drive
Color	Blue
Read Speed (Max)	Up to 4,150 MB/s
Endurance (2TB model)	Up to 900 TBW

## 8. Warranty and Support

The Western Digital WD Blue SN580 NVMe SSD comes with a 5-year limited warranty or up to the maximum endurance (TBW) limit, whichever occurs first. For detailed warranty terms and conditions, please refer to the


official Western Digital website.

For technical support, driver downloads, firmware updates, and additional resources, please visit the official Western Digital support page:

### [Western Digital Support](#)

© 2023 Western Digital. All rights reserved.

## Related Documents - WDS100T3B0E

	<p><b><a href="#">How to Install and Set Up a WD Black SN850x SSD</a></b></p> <p>A step-by-step guide on installing and setting up a new WD Black SN850x NVMe SSD on a Windows computer, including physical installation and disk initialization/formatting.</p>
	<p><b><a href="#">Formatting WD Hard Drives and WD Black PCIe SSD Compatibility Guide</a></b></p> <p>Learn how to format Western Digital hard drives to exFAT or FAT32 file systems and understand the hardware and software requirements for WD Black PCIe SSDs on Windows and macOS.</p>
	<p><b><a href="#">How to Partition, Format, and Troubleshoot WD External Hard Drives on Windows and macOS</a></b></p> <p>A comprehensive guide from Western Digital (WD) detailing how to partition and format WD external hard drives for compatibility with Windows and macOS operating systems. It includes troubleshooting steps for common connection and recognition issues, guidance on using WD utilities like WD Security and WD Drive Utilities, and information on drive management.</p>
	<p><b><a href="#">Western Digital Dashboard: Install &amp; Use Guide</a></b></p> <p>Comprehensive guide on how to install and use the Western Digital Dashboard software for managing your Western Digital and SanDisk storage devices.</p>



### [IP Ratings Explained: A Guide to Ingress Protection Standards \(IEC 60529\)](#)

Understand Ingress Protection (IP) ratings for devices. This guide details the IEC 60529 standard, explaining the meaning of each numeral for protection against solid objects and water, with examples from Western Digital brands.



### [Western Digital OpenFlex Data24 4000 Series User Guide](#)

Comprehensive user guide for the Western Digital OpenFlex Data24 4000 Series, detailing its features, specifications, installation, maintenance, and safety information.