

[Manuals.plus](#) /

› [Oraimo](#) /

› Oraimo FreePods 3 Wireless Earbuds OEB-E104DC User Manual

## Oraimo OEB-E104DC

# Oraimo FreePods 3 Wireless Earbuds

Model: OEB-E104DC

Brand: Oraimo

## INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Oraimo FreePods 3 Wireless Earbuds, Model OEB-E104DC. Please read this manual carefully before using the product to ensure optimal performance and longevity.

## WHAT'S IN THE BOX

The Oraimo FreePods 3 package includes the following items:

- Oraimo FreePods 3 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual
- Multiple sizes of Ear Tips (S, M, L)



Image: Contents of the Oramo FreePods 3 package.

## SETUP

### Initial Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings.
3. Select "Oraimo FreePods 3" from the list of available devices to connect.
4. Once connected, you will hear a confirmation tone.

### Connecting to Oramo Sound App

For enhanced customization and access to 5 EQ modes, download the Oramo Sound App from your device's app store. Follow the in-app instructions to connect your FreePods 3 earbuds.

Your browser does not support the video tag.

Video: Unboxing and initial setup of Oraimo FreePods 3 (White version).

Your browser does not support the video tag.

Video: Unboxing and initial setup of Oraimo FreePods 3 (Black version).

## OPERATING INSTRUCTIONS

### Touch Controls

The FreePods 3 feature intuitive touch controls on each earbud:



Image: Detailed touch control functions for both earbuds.

- **Tap Twice (Left or Right):** Play/Pause music, Answer/End calls.
- **Press and Hold 1.5s (Left):** Previous track.
- **Press and Hold 1.5s (Right):** Next track.
- **Tap One and Hold 2s (Left or Right):** Reject calls.

- **Tap Triple (Left or Right):** Activate voice assistant (Google Assistant).

## Listening Modes

The FreePods 3C offers two distinct listening modes based on ear tip usage:

- **Bass Mode (with ear tips):** When ear tips are attached, this mode actively blocks ambient noise and minimizes sound leakage, providing a richer, more immersive bass experience.
- **Awareness Mode (without ear tips):** Removing the ear tips activates this mode, allowing for increased comfort and awareness of your surroundings, ideal for situations where you need to hear external sounds.



Image: Environmental Noise Cancellation (ENC) for clear calls.

## CHARGING

The Oraimo FreePods 3 provide extended playtime and quick charging capabilities:

- **Total Playtime:** Up to 36 hours with the charging case (8 hours from earbuds + 28 hours from case).
- **Fast Charging:** A 10-minute charge in the case provides up to 140 minutes of playback.
- Use the provided USB Type-C cable to charge the case. The LED indicators on the case show the charging status.



Image: Earbuds in charging case.

## MAINTENANCE

### Water Resistance

The FreePods 3 are IPX5 water-resistant, meaning they can withstand splashes and sweat. They are suitable for workouts and light rain, but should not be submerged in water.

## Simultaneous, Low Latency

BT 5.2 chip will simultaneously transmit sound to the left and right ears for a stable connection and impeccable sound experience.

5.2



Image: IPX5 Water Resistance.

### Cleaning

Regularly clean your earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals. Ensure the charging contacts are free of dust and debris.

## TROUBLESHOOTING

### Resetting the Earbuds

If the left and right earbuds are not pairing automatically or if the earbud status indicators are flashing red and green alternatively on both earbuds, you can manually enter TWS pairing mode:

- Tap either earbud 2 times simultaneously to reset and re-enter pairing mode.




Image: Resetting instructions for the earbuds.

## Common Issues

- **No Sound:** Ensure earbuds are charged, connected to your device, and volume is up.
- **Poor Call Quality:** Check for obstructions around the microphones. Ensure you are in an environment with minimal background noise.
- **Connection Drops:** Ensure your device is within the 10-meter Bluetooth range. Avoid strong electromagnetic interference.

## SPECIFICATIONS

| Feature                  | Detail                                     |
|--------------------------|--------------------------------------------|
| Brand Name               | Oraimo                                     |
| Model Name               | FreePods 3                                 |
| Model Number             | OEB-E104DC                                 |
| Color                    | White                                      |
| Connectivity Technology  | Wireless (Bluetooth)                       |
| Bluetooth Version        | 5.3                                        |
| Bluetooth Range          | 10 Meters                                  |
| Ear Placement            | In Ear                                     |
| Headphones Form Factor   | In Ear                                     |
| Audio Driver Size        | 13mm Dynamic Driver                        |
| Frequency Range          | 20 Hz - 20000 Hz                           |
| Impedance                | 140 Ohm                                    |
| Sensitivity              | 100 dB                                     |
| Noise Control            | Passive Noise Cancellation (ENC for calls) |
| Control Method           | Touch                                      |
| Control Type             | Google Assistant                           |
| Battery Life (Earbuds)   | 8 Hours                                    |
| Battery Life (with Case) | 36 Hours                                   |
| Fast Charge              | 10 min charge for 140 min playtime         |
| Water Resistance Level   | IPX5 (Waterproof)                          |
| Material                 | Plastic                                    |
| Item Weight              | 150 Grams                                  |
| Compatible Devices       | Smartphones                                |

Your browser does not support the video tag.

Video: Animated overview of Oraimo FreePods 3C features including dual modes, ENC, powerful bass, and battery life.

## WARRANTY AND SUPPORT

Oraimo offers a 365-day warranty for the FreePods 3. We provide 24/7 customer service and will resolve any issues within 24 hours. For further assistance, please refer to the contact information provided in the product packaging or visit the official Oraimo website.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0C8Z7YM23>

More documents and user manuals: <https://manuals.plus/>