



Manuals.plus /

- › Epson /
- › Epson BrightLink 760Wi Ultra Short Throw 3LCD Projector User Manual

## Epson 760Wi

# Epson BrightLink 760Wi Ultra Short Throw 3LCD Projector User Manual

Model: 760Wi

## 1. INTRODUCTION

---

The Epson BrightLink 760Wi is an advanced Ultra Short Throw 3LCD Interactive Laser Display designed for collaborative environments such as classrooms. This lamp-free projector delivers bright, clear images with WXGA resolution and offers interactive features for enhanced engagement. This manual provides essential information for the safe and effective use of your projector.

## 2. SAFETY INFORMATION

---

Please read all safety instructions before using the projector to prevent injury or damage to the unit. Keep this manual for future reference.

- Do not look directly into the projector lens when the lamp is on, as it can cause eye damage.
- Ensure proper ventilation around the projector to prevent overheating. Do not block ventilation openings.
- Use only the power cord supplied with the projector.
- Do not attempt to disassemble or modify the projector. Refer all servicing to qualified personnel.
- Keep the projector away from water or other liquids.

## 3. PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- BrightLink 760Wi Ultra Short Throw Interactive Display
- User Manual
- 6' Power Cable
- 16' USB A/B Cable

- Projector Remote Control
- 2x Interactive Pens
- 4x Soft Pen Tips
- 2x Hard Pen Tips
- Pen Tray
- 2x AA Batteries (For Interactive Pens)
- 2x AA Batteries (For Remote)
- Projector Feet
- Corner Markers
- Magnets For Corner Markers
- 1-year License Key For BrightLink GoBoard Software

## 4. SETUP

---

### 4.1 Mounting the Projector

The BrightLink 760Wi is designed for flexible installation, including wall-mountable and tabletop configurations. For wall mounting, ensure you use a compatible ultra-short throw wall mount (sold separately) and follow the mount's instructions carefully. The projector can replace older BrightLink models (595Wi/695Wi/725Wi) using existing mounts and touch modules.



Figure 4.1: Epson BrightLink 760Wi mounted on a wall bracket, showcasing its ultra-short throw design.



Figure 4.2: Another view of the Epson BrightLink 760Wi mounted, highlighting its compact installation.

## 4.2 Connecting Devices

The projector offers various connectivity options for different devices. Refer to the image below for port identification.



Figure 4.3: Rear panel connections of the BrightLink 760Wi.

- **HDMI:** Connect up to three HDMI devices (e.g., laptops, Blu-ray players) using the HDMI 1, HDMI 2, and HDMI 3 ports.
- **USB:** Use the USB-A port (5V/2.0A) for direct image projection from a PC or MacBook, or for powering compatible devices. USB-B 1 and USB-B 2 ports are also available.
- **Computer (VGA):** Connect computers using the Computer 1 and Computer 2 (Monitor Out) VGA ports.
- **Audio:** Audio 1 and Audio 2 inputs, along with Audio Out and Sync In/Out ports, are available for sound connections. A Mic input is also provided.

- **LAN:** Connect to a network using the LAN port for network control and content sharing.
- **RS-232C:** For serial control of the projector.
- **Wi-Fi:** The projector supports wireless connectivity for casting from various devices.

## 4.3 Power Connection

Connect the supplied power cable to the projector's power inlet and then to a standard electrical outlet. Ensure the power source meets the projector's requirements.

# 5. OPERATING INSTRUCTIONS

---

## 5.1 Powering On/Off

- To power on, press the power button on the projector or the remote control.
- To power off, press the power button again. The projector will go through a shutdown sequence.

## 5.2 Input Selection

Use the "Source Search" button on the remote control or the projector's control panel to cycle through available input sources (HDMI, USB, Computer, etc.).

## 5.3 Interactive Features

The BrightLink 760Wi supports multi-user interactivity. Use the included interactive pens for dual-pen functionality. An optional slim-design touch module (sold separately) allows up to eight users to collaborate simultaneously.

## 5.4 Wireless Casting with Epson iProjection

Download the free Epson iProjection software to cast content wirelessly from up to 50 devices, including Chromebooks, iOS and Android devices, Mac computers, and PCs. The moderator feature allows teachers to control displayed content.

## 5.5 PC-Free Digital Whiteboard

Utilize the built-in digital whiteboard functionality to draw, save, print, and email content without needing a connected PC. Whiteboard content can also be shared with other networked BrightLink projectors.

# 6. MAINTENANCE

---

The BrightLink 760Wi features a virtually maintenance-free laser light source with an operating life of up to 20,000 hours, eliminating the need to purchase or replace lamps.

- Regularly clean the projector's exterior with a soft, dry cloth.
- Ensure ventilation openings are clear of dust and debris.
- For optimal performance, keep the projection window clean.

# 7. TROUBLESHOOTING

---

If you encounter issues with your projector, try the following basic troubleshooting steps:

- **No Image:** Check all cable connections, ensure the correct input source is selected, and verify the projector is powered on.
- **Image Blurry:** Adjust the focus using the projector's controls. Ensure the projection surface is flat and the

projector is positioned correctly.

- **No Sound:** Check audio cable connections, ensure the projector's volume is up, and verify the audio output on your source device.
- **Remote Control Not Working:** Replace batteries in the remote control. Ensure there are no obstructions between the remote and the projector's sensor.

For more detailed troubleshooting, refer to the comprehensive user manual available on the Epson support website.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Epson
Model Name	BrightLink
Model Number	760Wi
Display Type	3LCD
Native Resolution	1280 x 800 (WXGA)
Brightness	4100 Lumens (Color & White)
Contrast Ratio	2,500,000:1
Light Source	Laser
Light Source Operating Life	20,000 Hours
Maximum Image Size	100 Inches
Throw Distance (Min/Max)	1.28 Feet / 1.97 Feet
Connectivity Technology	HDMI, USB, Wi-Fi
Hardware Connectivity	HDMI (x3), USB (x3), VGA (x2), Audio (x3), Mic, LAN, RS-232C
Form Factor	Wall Mountable
Item Dimensions (L x W x H)	15.6"L x 14.1"W x 5.3"H
Wattage	277 watts
Recommended Uses	Classroom, Education

## 9. WARRANTY AND SUPPORT

The Epson BrightLink 760Wi is covered by a **3-year Manufacturer Warranty**. For technical support, warranty claims, or additional product information, please visit the official Epson support website or contact their customer service.

You can find more information and support resources on theEpson Store on Amazon.