

## it luggage 15-288108-UOL20-S935

# it Luggage Spontaneous 22-inch Hardside Carry-On Spinner User Manual

Model: 15-288108-UOL20-S935

## 1. INTRODUCTION

---

Thank you for choosing the it Luggage Spontaneous 22-inch Hardside Carry-On Spinner. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new luggage. Designed for durability and convenience, this carry-on features a virtually unbreakable polypropylene shell, superior 8-wheel control, and a central expansion system for additional packing space.

## 2. SETUP

---

### 2.1 Unpacking

Carefully remove the luggage from its packaging. Inspect for any signs of damage during transit. Retain packaging materials for future storage or return if necessary.

### 2.2 Handle Extension

To extend the telescopic handle, locate the button on the top of the handle grip. Press and hold the button while pulling the handle upwards until it locks into your desired height. To retract, press the button and push the handle downwards until it is fully recessed.



Image: Rear view of the luggage showing the telescopic handle in its extended position, ready for transport.

### 2.3 Setting the TSA Combination Lock

Your luggage is equipped with a recessed combination TSA lock. Follow these steps to set your personal combination:

1. The lock is preset to 0-0-0.
2. Locate the small reset button (often a small hole) next to the dials. Use a pen or pointed object to press and hold this button until you hear a click.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set.
5. Test your new combination by scrambling the dials and then entering your combination to open the lock.

*Note: Remember your combination. There is no master key for personal combinations.*





Image: Top-down view highlighting the integrated TSA combination lock mechanism.

### **3. OPERATING**

---

#### **3.1 Using the 8-Wheel Spinner System**

Your luggage features an 8-wheel spinner system designed for superior control and effortless maneuverability. The wheels rotate 360 degrees, allowing you to push, pull, or roll the luggage alongside you in any direction. Ensure all wheels are free from obstructions for smooth movement.



Image: Detailed view of a single spinner wheel, illustrating its design for multi-directional movement.

### 3.2 Expanding the Luggage

For up to 25% extra packing space, your carry-on includes a central expansion zipper. To expand, locate the zipper running along the middle perimeter of the luggage, separate from the main compartment zippers. Unzip this expansion zipper completely. To return to its original size, zip it back up.





Image: Side profile of the luggage, highlighting the central zipper that allows for expansion.

### **3.3 Packing the Main Compartment**

The luggage features a central opening and clamshell design, which helps separate belongings and provides an ideal flat packing surface. Open the luggage completely to lay it flat. Utilize the interior straps to secure your items and the internal pockets for organized storage of smaller essentials.



Image: Interior view of the luggage, demonstrating the spacious compartments, securing straps, and zippered mesh pockets for organized packing.

## 4. MAINTENANCE

---

### 4.1 Cleaning

- **Exterior:** Wipe the hardside shell with a damp cloth and mild soap. Avoid abrasive cleaners that may scratch the surface.
- **Interior:** Spot clean the interior lining with a damp cloth and mild detergent. Allow to air dry completely before closing.
- **Wheels:** Periodically check wheels for debris (hair, lint, dirt) and remove them to ensure smooth rolling.

### 4.2 Storage

Store your luggage in a cool, dry place away from direct sunlight when not in use. Ensure it is clean and

completely dry before storing to prevent mold or mildew.

## 5. TROUBLESHOOTING

---

- **Stuck Handle:** If the telescopic handle is difficult to extend or retract, ensure the release button is fully depressed. Check for any obstructions in the handle mechanism. Do not force the handle.
- **Stiff Wheels:** If wheels are not rolling smoothly, check for tangled hair, lint, or dirt. Clean the wheel axles as described in the Maintenance section.
- **Zipper Issues:** If a zipper snags, gently pull the fabric away from the zipper teeth and slowly move the slider. Avoid forcing the zipper. Lubrication with a zipper wax or silicone spray can help.
- **Lock Not Opening:** Ensure you are entering the correct 3-digit combination. If you have forgotten your combination, there is no override. You may need to contact a locksmith or the manufacturer for assistance.

## 6. SPECIFICATIONS

---

<b>Product Dimensions</b>	15.9 x 10.6 x 22.8 inches
<b>Item Weight</b>	6.5 pounds
<b>Material</b>	Polypropylene (Hardside)
<b>Wheels</b>	8-Wheel Spinner System
<b>Expansion</b>	Central space expander (up to 25% extra space)
<b>Lock Type</b>	Recessed Combination TSA Lock
<b>Model Number</b>	15-288108-UOL20-S935
<b>ASIN</b>	B0C9274YDS

## 7. WARRANTY

---

This it Luggage Spontaneous carry-on comes with a **10-Year Warranty**, assuring quality in every case. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, neglect, accidents, abrasion, extreme temperatures, solvents, acids, normal wear and tear, or transport damage (e.g., by airlines). For warranty claims, please retain your proof of purchase and contact it luggage customer support.

## 8. SUPPORT

---

For further assistance, product inquiries, or warranty claims, please contact it luggage customer support through their official website or the retailer where the product was purchased.

**Website:** [www.itluggage.com](http://www.itluggage.com)

Please have your model number (15-288108-UOL20-S935) and proof of purchase available when contacting support.

