Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM 15.8"D x 31.3"W x 48"H (5 Drawers) Antique White

T4TREAM 5-Drawer Dresser User Manual

Model: 15.8"D x 31.3"W x 48"H (5 Drawers) Antique White
Brand: T4TREAM

Introduction

This user manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM 5-Drawer Dresser. Please read this manual thoroughly before beginning assembly or use to ensure safe and proper functionality of your new furniture.

Safety Information

- Always follow assembly instructions carefully.
- Do not overload drawers or shelves.
- Ensure the dresser is placed on a flat, stable surface.
- For safety, it is recommended to secure the dresser to a wall using anti-tip hardware (if included) to prevent tipping.
- Keep small parts away from children during assembly.

Parts List

Before assembly, verify that all parts listed below are present and undamaged. Refer to the included hardware pack for specific fasteners.

Part	Description	Quantity
Top Panel	Wooden top surface	1
Side Panels	Left and Right side frames	2
Back Panel	Rear support panel	1
Drawers	Complete drawer units	5
Sliding Barn Door	Door with barn-style design	1

Part	Description	Quantity
Adjustable Shelves	Interior shelves for customization	2
Hardware Pack	Screws, cam locks, dowels, etc.	1
Sliding Track & Hardware	Components for barn door mechanism	1 set

Setup & Assembly

Assembly typically requires two people and a Phillips head screwdriver. Follow the numbered steps in the included instruction manual for detailed diagrams. Below are general guidelines and key features.

Step 1: Unpacking and Preparation

Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided parts list.



Image: The fully assembled T4TREAM 5-Drawer Dresser in Antique White.

Step 2: Assembling the Frame

Connect the side panels to the base and top frame using the provided hardware. Ensure all connections are secure before proceeding.



Image: Detailed dimensions of the dresser (31.25"W x 15.75"D x 48"H) and individual drawer dimensions (11.2"W x 12"D x 5.7"H).

Step 3: Installing Drawers and Sliding Door

Assemble the five drawers and install their respective slides into the dresser frame. Attach the sliding barn door to the top track, ensuring smooth operation. The door can slide to reveal either the drawers or the adjustable shelves.



Image: The dresser showcasing its versatile storage options, including five drawers and two adjustable/removable shelves behind the sliding barn door.




Image: Close-up view highlighting the smooth operation of the sliding barn doors, the three-height adjustable shelves, and the smooth-gliding drawers.

Operating Instructions

Using the Sliding Barn Door

The barn door slides smoothly along the top track. Gently push or pull the door handle to move it left or right. This allows you to conceal either the five drawers or the two adjustable shelves, providing flexible display and storage options.

Adjusting Shelves

The two shelves behind the sliding door are adjustable to three different heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and then place the shelf back onto the pins. The shelves are also fully removable for larger items.

Drawer Usage

The five drawers are designed for smooth operation. Pull the black square handles to open and push to close. Avoid forcing drawers if they feel stuck; ensure nothing is obstructing the slides.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the finish.

Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned slides or obstructions.	Check that drawer slides are correctly installed and aligned. Remove any obstructions from the tracks.
Sliding barn door sticks or is difficult to move.	Track obstruction or misaligned rollers.	Inspect the track for debris. Ensure rollers are properly seated on the track. Verify that no drawer handles or items inside are blocking the door's path.
Dresser feels wobbly.	Loose fasteners or uneven floor.	Tighten all assembly screws. Place shims under the legs if the floor is uneven. Ensure anti-tip hardware is installed.

Specifications

Brand: T4TREAM

Model: 15.8"D x 31.3"W x 48"H (5 Drawers) Antique White

Product Dimensions: 15.75"D x 31.25"W x 48"H

Color: Antique White

Material: Engineered Wood

Number of Drawers: 5

Number of Adjustable Shelves: 2

Drawer Weight Capacity: Up to 25 lbs per drawer

Top Surface Weight Capacity: Up to 100 lbs

Assembly Required: Yes

Mounting Type: Freestanding (wall anchor recommended)

Warranty & Support

T4TREAM products are designed for quality and durability. For any questions regarding assembly, missing parts, or product issues, please contact T4TREAM customer service directly. Refer to your purchase documentation for specific warranty details.

Contact Information: Please refer to the contact details provided with your product packaging or visit the official T4TREAM website for support.

We are committed to providing a satisfactory experience with our products.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C974G2HJ

More documents and user manuals: **https://manuals.plus/**