

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SUPPLYZ](#) /

› [SUPPLYZ W11195669 Refrigerator Ice Door Assembly Instruction Manual](#)

SUPPLYZ SZ-W11195669

SUPPLYZ W11195669 Refrigerator Ice Door Assembly Instruction Manual

Model: SZ-W11195669

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of the SUPPLYZ W11195669 Refrigerator Ice Door Assembly. This component is designed as a direct replacement for specific Whirlpool refrigerator models, ensuring proper function of your appliance's ice dispenser system. Please read this manual thoroughly before proceeding with installation or use.

2. SAFETY INFORMATION

- **Disconnect Power:** Always unplug the refrigerator from the power outlet before attempting any installation, repair, or maintenance to prevent electric shock.
- **Wear Protective Gear:** Use gloves to protect hands from sharp edges and safety glasses to protect eyes.
- **Professional Assistance:** If you are unsure about any step, consult a qualified appliance technician.
- **Original Parts:** Use only genuine replacement parts or approved equivalents to ensure proper fit and function.

3. COMPATIBILITY

The SUPPLYZ W11195669 Ice Door Assembly is a direct replacement for Whirlpool part numbers W10616140, 3023321, PS8768838, W10397481, and W10563936.

This part is compatible with various Whirlpool refrigerator models, including but not limited to:

- ASD2275BRB00, ASD2275BRB01, ASD2275BRS00, ASD2275BRS01, ASD2275BRW00, ASD2275BRW01
- ASD2575BRB00, ASD2575BRB01, ASD2575BRS00, ASD2575BRS01, ASD2575BRW00, ASD2575BRW01
- ASI2575FRB00, ASI2575FRS00, ASI2575FRW00
- MSF22D4XAB00, MSF22D4XAB01, MSF22D4XAM00, MSF22D4XAM01, MSF22D4XAW00, MSF22D4XAW01
- MSF25D4XAB00, MSF25D4XAM00, MSF25D4XAW00
- 7WRS22FDBF02, 7WRS22FDBW00, 7WRS22FDBW02
- WRS322FDAB00, WRS322FDAB01, WRS322FDAB02, WRS322FDAB03, WRS322FDAB04

- WRS322FDAD01, WRS322FDAD01
- WRS322FDAM00, WRS322FDAM01, WRS322FDAM02, WRS322FDAM03, WRS322FDAM04
- WRS322FDAT00, WRS322FDAT01, WRS322FDAT02, WRS322FDAT03, WRS322FDAT04
- WRS322FDAW00, WRS322FDAW01, WRS322FDAW02, WRS322FDAW03, WRS322FDAW04
- WRS325FDAB01, WRS325FDAB02, WRS325FDAB04
- WRS325FDAM01, WRS325FDAM02, WRS325FDAM04
- WRS325FDAT02, WRS325FDAT04
- WRS325FDAW01, WRS325FDAW02, WRS325FDAW04
- WRS331FDDB00, WRS331FDDB01
- WRS331FDDM00, WRS331FDDM01
- WRS331FDDW00, WRS331FDDW01
- WRS335FDDB00, WRS335FDDB01
- WRS335FDDM00, WRS335FDDM01
- WRS335FDDW00, WRS335FDDW01

Always verify your appliance's model number to ensure compatibility before purchasing and installing this part. The model number is typically located on a label inside the refrigerator compartment.

4. PACKAGE CONTENTS

Your package should contain the following item:

- 1 x SUPPLYZ W11195669 Refrigerator Ice Door Assembly



Image: The SUPPLYZ W11195669 Refrigerator Ice Door Assembly, showing its main components and design.

5. INSTALLATION INSTRUCTIONS

Follow these steps carefully to replace the ice door assembly. It is recommended to have a helper for certain steps.

1. Prepare the Refrigerator:

- Unplug the refrigerator from the electrical outlet to ensure safety.
- Empty the ice bin and remove it from the freezer compartment.

2. Access the Ice Door Assembly:

- Locate the ice dispenser chute inside the freezer door. The ice door assembly is typically located at the bottom of this chute.
- Depending on your specific model, you may need to remove a trim piece or a few screws to access the assembly. Refer to your refrigerator's specific service manual if needed.

3. Remove the Old Ice Door:

- Carefully disconnect any wiring harnesses attached to the old ice door assembly. Note the orientation of the wires for reinstallation.
- Unscrew or unclip the old ice door assembly from its mounting points. It may be held in place by clips, tabs, or screws.
- Gently pull the old assembly out of the freezer door.

4. Install the New Ice Door:

- Align the new SUPPLYZ W11195669 ice door assembly with the opening in the freezer door.
- Secure the new assembly using the screws or clips that held the old one in place. Ensure it is seated firmly and correctly.
- Reconnect any wiring harnesses to the new assembly. Make sure connections are secure and correctly oriented.

5. Reassemble and Test:

- Replace any trim pieces or covers that were removed.
- Reinsert the ice bin into the freezer compartment.
- Plug the refrigerator back into the electrical outlet.
- Test the ice dispenser function to ensure the new ice door opens and closes properly and that ice dispenses without obstruction.

6. OPERATION

The ice door assembly functions automatically as part of your refrigerator's ice dispensing system. When the dispenser lever is pressed, the ice door opens to allow ice to pass through the chute into your glass or container. Upon release of the lever, the door closes to maintain the freezer's temperature and prevent warm air from entering.

- **Ice Dispensing:** Press the dispenser lever firmly with your glass. The ice door will open, and ice will be dispensed.
- **Door Closure:** Release the dispenser lever. The ice door should close completely and seal the chute.

7. MAINTENANCE

Regular maintenance helps ensure the longevity and proper function of your ice door assembly.

- **Cleaning:** Periodically inspect the ice chute and door for any ice buildup or debris. Clean with a damp cloth and mild detergent if necessary. Ensure the area is dry before re-engaging power.

- **Inspection:** Check the ice door for any signs of wear, cracks, or damage. Ensure the door's seal is intact and free of tears to prevent air leaks.
- **Avoid Force:** Do not force the ice door open or closed manually, as this can damage the mechanism.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice door does not open.	Power issue, dispenser lever malfunction, motor failure.	<ul style="list-style-type: none">◦ Check if the refrigerator is plugged in and receiving power.◦ Ensure the dispenser lever is not jammed.◦ If the issue persists, the dispenser motor or wiring may need inspection by a technician.
Ice door does not close completely.	Ice buildup, debris in chute, damaged seal, faulty spring/mechanism.	<ul style="list-style-type: none">◦ Disconnect power and clear any ice or debris from the chute and around the door.◦ Inspect the door seal for damage and replace if necessary.◦ If the mechanism is visibly damaged, replacement of the assembly may be required.
Water leaks from dispenser.	Damaged ice door seal, cracked ice chute.	<ul style="list-style-type: none">◦ Inspect the ice door seal for tears or improper seating.◦ Check the ice chute for any cracks.◦ Ensure the ice door closes fully to prevent condensation and drips.

For issues not covered here, or if troubleshooting steps do not resolve the problem, contact a qualified appliance repair professional.

9. SPECIFICATIONS

- **Part Number:** SUPPLYZ SZ-W11195669
- **Replaces Part Numbers:** W11195669, W10616140, 3023321, PS8768838, W10397481, W10563936
- **Manufacturer:** SUPPLYZ
- **Compatibility:** Direct replacement for various Whirlpool refrigerator models.

10. WARRANTY AND SUPPORT

For warranty information or technical support regarding your SUPPLYZ W11195669 Refrigerator Ice Door Assembly, please refer to the documentation provided with your purchase or contact SUPPLYZ customer service directly. Keep your proof of purchase for warranty claims.

