Xgody XGODY J706F

XGODY GPS Navigation System User Manual

Brand: Xgody | Model: XGODY J706F

Introduction

Welcome to the user manual for your new XGODY GPS Navigation System. This device is designed to provide reliable and intelligent navigation for various vehicle types, ensuring a smooth and safe journey. Featuring a 2.5D curved screen for enhanced visibility and pre-installed 2023 North America maps with free lifetime updates, your XGODY GPS is a powerful tool for all your travel needs.



Figure 1: XGODY GPS Navigation System in use, displaying a map and navigation details.

Product Overview

Key Features:

- **2.5D Curved Screen:** Offers a wider viewing angle, improved visibility, and better light transmission for clear mapping even in sunlight.
- **Lifetime Map Updates:** Pre-installed with the latest 2023 North America maps (US, Canada, Mexico) with free lifetime updates. Additional maps for Europe, South America, Australia, etc., are available for download.
- **Customized Navigation Routes:** Intelligent GPS can tailor routes based on vehicle type (truck, car, bus, pedestrian, taxi, bicycle, emergency), avoiding height/weight restrictions and traffic congestion.
- **Intelligent Navigation System:** Provides speed warnings, identifies nearby Points of Interest (POIs) like gas stations and rest areas, and displays speed information, remaining distance, and arrival time.
- **Voice Guidance:** Offers clear voice prompts for turn-by-turn directions.




Figure 2: The 2.5D curved screen design of the XGODY GPS.

What's in the Box

Upon opening your XGODY GPS Navigation System package, you will find the following components:

- XGODY GPS Navigation Device (Model J706F)
- Car Charger
- Dashboard Mount (Suction Cup Mount)
- USB Cable
- User Manual (this document)
- Sun Protection Visor (optional, if included in your specific package)




Figure 3: All components included in the XGODY GPS package.

Unboxing Video:

Your browser does not support the video tag.

Video 1: A visual guide to the items included in the XGODY GPS Navigation System box.

Setup

1. **Charge the Device:** Before first use, fully charge the GPS unit using the provided car charger or a compatible USB power source. Charging time is approximately 2-3 hours.
2. **Install the Mount:** Attach the suction cup mount to a clean, smooth surface on your dashboard or windshield. Ensure it is securely fastened and does not obstruct your view of the road.
3. **Attach the GPS Unit:** Slide the GPS unit onto the dashboard mount until it clicks securely into place.
4. **Power On:** Press and hold the power button until the XGODY logo appears.
5. **Initial Setup:** Follow the on-screen prompts to select your language, time zone, and other initial settings.
6. **Map Updates:** Your device comes with the latest 2023 North America maps. For future updates, please refer to the "Maintenance" section or contact XGODY customer support.

Operating Instructions

Main Menu Navigation:

The main menu provides access to all functions. Tap the "Navigation" icon to begin route planning. Other icons include System Info, Movie, Music, Games, Photo, Tools, FM, and Multimedia.




Figure 4: The user-friendly main interface of the XGODY GPS.

Route Planning and Navigation:

1. From the main menu, tap **Navigation**.
2. Enter your destination using the on-screen keyboard. You can search by address, point of interest, or coordinates.
3. Select your preferred route type (e.g., fastest, shortest, avoid highways).

4. Confirm the route, and the device will begin providing turn-by-turn voice guidance and visual directions.

Intelligent Voice Guidance:


The system provides clear voice prompts for turns, speed limits, and upcoming points of interest. This feature helps you stay focused on the road.



Figure 5: Intelligent voice guidance provides timely alerts and information.

Customized Routes for Various Vehicles:

The XGODY GPS allows you to select your vehicle type to optimize routes, avoiding restrictions such as height or weight limits for trucks, or finding pedestrian-friendly paths.



XGODY Navigator offers navigation customization services

Applicable models: small cars, trucks, commercial vehicles, RVs,semi-cranes and more than 20 models

Figure 6: Customization options for different vehicle types.



Figure 7: Seven practical scenarios for tailored navigation.

Multimedia Functions:

Beyond navigation, the device supports various multimedia formats:

- **Video:** ASF, AVI, WMV, MPG, DAT, MPEG, 3GP
- **Audio:** WMA9, MP3, WAV
- **Photo:** JPG, GIF, BMP, PNG
- **E-book:** TXT

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screen and device body. Avoid abrasive cleaners or solvents.
- **Temperature:** Operate the device within the specified temperature range (-10 °C to 60 °C). Store it between 0 °C to 60 °C. Extreme temperatures can damage the battery and internal components.

- **Map Updates:** To ensure the most accurate navigation, it is recommended to periodically update your maps. Contact XGODY customer support for instructions on how to download and install the latest map versions.
- **Software Updates:** Check the XGODY official website or contact support for any available firmware or software updates to improve performance and add new features.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery; power button not pressed correctly.	Charge the device for at least 30 minutes. Press and hold the power button for 5-10 seconds.
No GPS signal or inaccurate location.	Device is indoors; obstructed view of sky; outdated maps.	Move to an open area with clear view of the sky. Ensure maps are updated. Restart the device.
Screen is unresponsive or frozen.	Software glitch; temporary system error.	Perform a soft reset (refer to the device's specific reset procedure, usually a small reset button or holding power).
Maps are outdated or missing roads.	Maps require updating.	Contact XGODY customer support for the latest map updates.
Voice guidance is unclear or too low.	Volume settings; FM transmitter interference.	Adjust volume settings in the device menu. Check FM transmitter frequency if used.

Specifications

Feature	Detail
Model	XGODY J706F
GPS Module	High Sensitive GPS Receiver
Memory Size	256MB RAM – 8GB Internal Memory
Display Screen	7" Capacitive screen (2.5D curved)
SD Slot	Micro SD socket, MAX Micro SD card up to 32GB
FM Transmitter	76.0MHz -108MHz (Transfers GPS sound to Car, not FM Radio)
Bluetooth & AV-IN	NO
Working Time	About 1 hour
Charging Time	2-3 hours
Car Charger	8-36V/2A
Operation Temperature	-10 °C to 60 °C
Saving Temperature	0 °C to 60 °C
Navigation Storage	More than 49 countries maps (North America pre-installed)
Video Formats	ASF, AVI, WMV, MPG, DAT, MPEG, 3GP

Feature	Detail
Audio Formats	WMA9, MP3, WAV
Photo Formats	JPG, GIF, BMP, PNG
E-book Format	TXT
Item Weight	2.03 pounds
Package Dimensions	8.66 x 5.87 x 3.19 inches
Batteries	1 Lithium Ion battery required (included)

Warranty and Support

XGODY offers a **1-year warranty** and a **30-day money-back guarantee** for your GPS Navigation System.
For any questions regarding product operation, troubleshooting, map updates, or warranty claims, please contact XGODY customer support via Amazon message. We aim to reply within 24 hours.
For more information, you may also visit the official Xgody Store on Amazon:Xgody Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question