

[Manuals.plus](#) /

› [ASHUAQI](#) /

› ASHUAQI 12-Light Gold Wagon Wheel Chandelier Instruction Manual

ASHUAQI ZJD00044

ASHUAQI 12-Light Gold Wagon Wheel Chandelier Instruction Manual

Model: ZJD00044

1. INTRODUCTION

Thank you for choosing the ASHUAQI 12-Light Gold Wagon Wheel Chandelier. This manual provides essential information for safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image 1: The ASHUAQI 12-Light Gold Wagon Wheel Chandelier, featuring a gold finish and a handwoven twine-wrapped frame.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these safety precautions:

- **Turn off power** at the circuit breaker or fuse box before installation, servicing, or changing bulbs.
- Consult a qualified electrician if you are not familiar with electrical installation.
- Ensure all electrical connections comply with local codes and ordinances.
- Use only the specified bulb type and wattage to avoid overheating.
- Do not connect this fixture to an ungrounded electrical system.
- Handle the fixture with care to prevent damage to components.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or broken, contact customer support.



Image 2: Overview of the chandelier components, including the main frame, canopy, chain, wiring, and mounting hardware.

The package typically includes:

- Chandelier Frame (with handwoven twine wrap)
- Ceiling Canopy
- Adjustable Hanging Chain (59 inches)
- Mounting Hardware (screws, wire nuts, ground wire)
- Instruction Manual

Note: Light bulbs are not included and must be purchased separately.

4. SPECIFICATIONS



Image 3: Detailed dimensions and electrical requirements for the chandelier.

Feature	Specification
Model Number	ZJD00044
Dimensions (Wheel Diameter)	26.77 inches (68 cm)
Fixture Height	17.72 inches (45 cm)
Adjustable Chain Length	Up to 59 inches (150 cm)
Bulb Base	E12 (Candelabra)
Number of Lights	12
Max Wattage per Bulb	60W

Feature	Specification
Voltage	110-120V (AC)
Material	Metal, Hemp Rope
Finish	Gold (Brushed)
Installation Type	Ceiling Mount
Dimmable	Yes (with dimmable bulbs and compatible dimmer switch, not included)

5. SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is OFF at the circuit breaker before starting.

5.1 Pre-Installation

- Unpack:** Carefully remove all components from the packaging.
- Inspect:** Check for any damage or missing parts.
- Tools Required (not included):** Screwdriver, wire strippers, electrical tape, ladder, safety glasses.

5.2 Mounting the Fixture



Image 4: The chandelier's adjustable chain allows for customization of hanging height to suit various ceiling types and room dimensions.

1. **Turn off power:** Locate the circuit breaker controlling the light fixture and turn it off.
2. **Attach Mounting Bracket:** Secure the mounting bracket to the junction box in the ceiling using the provided screws.
3. **Adjust Chain Length:** Determine the desired hanging height. The 59-inch chain can be adjusted using the two detachable buckles. Shorten the chain by removing links as needed.



Image 5: Details of the ceiling canopy, adjustable chain mechanism, and the decorative twine-wrapped frame.

4. **Wire Connections:** Connect the fixture's wires to the house wires according to standard electrical practices (black to black, white to white, ground to ground). Use wire nuts to secure connections.
5. **Secure Canopy:** Tuck the wires into the junction box and secure the ceiling canopy to the mounting bracket.
6. **Install Bulbs:** Screw E12 base bulbs (not included) into each of the 12 sockets. Do not exceed 60W per bulb.

6. OPERATING INSTRUCTIONS

Once installed, restore power at the circuit breaker. The chandelier is now ready for use.

- **Bulb Type:** This fixture requires 12 E12 base bulbs. Compatible bulb types include LED, Edison, CFL, halogen, or incandescent.
- **Wattage:** Do not exceed 60 watts per bulb.
- **Dimmability:** The chandelier is fully dimmable when used with dimmable E12 bulbs and a compatible dimmer switch (both sold separately).




Image 6: The chandelier with lights off (left) and illuminated (right), demonstrating its functionality.

7. MAINTENANCE

Regular maintenance ensures the longevity and appearance of your chandelier.

- **Cleaning:** Turn off power before cleaning. Use a soft, dry cloth to wipe the metal and twine surfaces. Avoid abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely before touching.

8. TROUBLESHOOTING

If you encounter issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power, loose wiring, faulty bulb	Check circuit breaker, ensure connections are secure, replace bulb.
Lights flicker	Loose bulb, incompatible dimmer, unstable power supply	Tighten bulbs, ensure dimmer is compatible with bulbs, consult electrician.
Fixture is unstable	Improper mounting	Ensure mounting bracket is securely fastened to the junction box.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact ASHUAQI customer service. Keep your purchase receipt as proof of purchase.

You can visit the ASHUAQI store for more products and support:[ASHUAQI Store](#)

© 2025 ASHUAQI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question