

TOPTRO X7

TOPTRO X7 Android TV Projector User Manual

Model: X7

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your TOPTRO X7 Android TV Projector. Please read it thoroughly before use and retain it for future reference.

2. WHAT'S IN THE BOX

- TOPTRO X7 Android TV Projector
- Power Cable
- User Manual
- HDMI Cable
- Remote Control



Image: The TOPTRO X7 projector with its included accessories, such as the power cable, HDMI cable, and remote control, laid out on a surface.

3. PRODUCT FEATURES

The TOPTRO X7 projector is designed for versatile home entertainment, offering advanced features for an immersive viewing experience.

- **Auto Focus & Keystone Correction:** Automatically adjusts image clarity and shape for optimal viewing.
- **Android TV System:** Integrated smart system with access to Netflix, YouTube, and over 8000+ applications.
- **High Brightness & Resolution:** Features 600 ANSI Lumens, Native 1080P resolution, and 4K support for clear, vibrant images.
- **Advanced Connectivity:** Equipped with WiFi 6 and Bluetooth 5.2 for fast, stable wireless connections.
- **Dust-proof Design:** IP5X protection level helps prevent dust accumulation, maintaining image quality over time.
- **Flexible Projection:** Supports 50% zoom and a 1.33:1 projection ratio, allowing for large screen sizes even in smaller spaces.
- **AI Color Optimization:** Enhances clarity, revivifies colors, and reduces image noise for a superior visual experience.

- **Smart Eye Protection:** Certified for low blue light emission to reduce eye strain.



Image: A split image demonstrating the "Remarkable Picture Effect" of the TOPTRO X7, showing a blurred image on the left and a sharp, colorful parrot on the right.




Image: The projector displaying its built-in smart system interface, featuring icons for popular streaming services and apps.



Image: A visual representation of WiFi 6 technology, emphasizing faster, smoother, and lower latency performance for streaming content.




Image: The projector demonstrating its auto focus and keystone correction features, projecting a clear image of an elephant onto a wall.

4. SETUP

4.1 Placement

Position the projector on a stable, flat surface. Ensure there is adequate ventilation around the unit. The ideal projection distance will vary based on desired screen size.

4.2 Power Connection

1. Connect the power cable to the projector's power input.
2. Plug the other end of the power cable into a suitable electrical outlet.

4.3 Initial Power On

Press the power button on the projector or the remote control to turn on the device. The projector will perform an initial boot-up sequence.

4.4 Focus and Keystone Adjustment

The TOPTRO X7 features automatic focus and keystone correction. Upon startup or movement, the projector will automatically adjust the image for clarity and rectangular shape. Manual adjustments can also be made via the settings menu if needed.

5. OPERATING INSTRUCTIONS

5.1 Navigation

Use the provided remote control to navigate the Android TV interface. The directional buttons allow movement through menus, and the OK button confirms selections.

5.2 Connecting Devices

- **HDMI:** Connect external devices like laptops, gaming consoles, or Blu-ray players using an HDMI cable to the HDMI 1 or HDMI 2 ports.
- **USB:** Insert USB drives into the USB ports to access media files.
- **Bluetooth:** Pair Bluetooth speakers, headphones, or other compatible devices via the Bluetooth settings menu for enhanced audio.
- **Wi-Fi:** Connect to your wireless network through the Network settings to access online content and apps. The projector supports WiFi 6 for stable streaming.
- **Ethernet:** For a wired internet connection, plug an Ethernet cable into the RJ45 port.

Upgraded Bluetooth 5.2, More Stable



Image: The TOPTRO X7 projector surrounded by various Bluetooth-enabled audio devices, illustrating its connectivity options.

5.3 Using Built-in Apps

The TOPTRO X7 comes with pre-installed streaming applications like Netflix and YouTube. Access these and thousands more via the Google Play Store on the projector's home screen.

5.4 Projection Settings

Adjust projection settings such as zoom (50% reduction) and projection method (front, rear, ceiling) through the system settings menu to optimize your viewing experience.

6. MAINTENANCE

6.1 Dust-proof Design

The TOPTRO X7 features an advanced IP5X dust-proof design, which significantly reduces the accumulation of dust within the optical engine. This minimizes the occurrence of black spots and maintains consistent image quality over time, reducing the need for frequent internal cleaning.



Image: An internal diagram of the TOPTRO X7 projector, highlighting its advanced dust-proof design and cooling system.

6.2 Cleaning

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid abrasive materials or harsh chemicals.
- **Exterior:** Wipe the exterior casing with a soft, dry cloth. Do not use liquid cleaners directly on the projector.
- **Ventilation:** Ensure the ventilation grilles are free from dust and obstructions to prevent overheating.

6.3 Storage

When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Use the original packaging or a protective case to prevent damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image displayed	Power not connected; Input source incorrect; Lens cap on.	Check power connection; Select correct input source; Remove lens cap.
Blurred image	Out of focus; Incorrect projection distance.	Allow auto-focus to adjust or manually adjust focus; Adjust projection distance.
Image is trapezoidal	Incorrect keystone setting; Projector not perpendicular to screen.	Allow auto-keystone to adjust or manually adjust keystone; Reposition projector.

Problem	Possible Cause	Solution
No sound	Volume too low; Muted; External audio device not connected properly.	Increase volume; Unmute; Check external audio connections or Bluetooth pairing.
Wi-Fi connection issues	Incorrect password; Out of range; Router issues.	Verify Wi-Fi password; Move projector closer to router; Restart router.

8. SPECIFICATIONS

Feature	Detail
Brand	TOPTRO
Model	X7
Product Dimensions	8.3 x 7.2 x 6.2 inches
Item Weight	7.19 pounds
Display Resolution	2160p (4K Supported, Native 1080P)
Brightness	600 ANSI Lumens
Connectivity Technology	Bluetooth 5.2, USB, Wi-Fi 6, HDMI, RJ45
Special Features	Built-In Wi-Fi, Portable, Wireless, Auto Focus, Auto Keystone Correction, 50% Zoom, Dust-proof
Recommended Uses	Home entertainment, outdoor movie nights, business presentations, educational purposes
Date First Available	June 25, 2023

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided in your product packaging or visit the official TOPTRO website. Keep your purchase receipt for warranty claims.

© 2023 TOPTRO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question