

Smart Steps WK07F10B

Smart Steps® Trend Plus 2-in-1 Walker with Deluxe Toys

Model: WK07F10B

Brand: Smart Steps

- [Introduction](#)
- [Safety Information](#)
- [Features](#)
- [Assembly](#)
- [Operation](#)
- [Maintenance](#)
- [Storage](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Support](#)

1. INTRODUCTION

The Smart Steps® Trend Plus 2-in-1 Walker with Deluxe Toys is designed to support your child's development as they prepare for their first steps. This versatile product functions as both a traditional walker and a walk-behind aid, adapting to your child's growing needs. It features a sturdy design, multi-directional wheels for easy movement, and an extra-wide base for enhanced stability. The integrated activity tray includes removable STEM-based toys to engage and entertain your child, fostering early learning and coordination.



Figure 1.1: The Smart Steps Trend Plus 2-in-1 Walker in Orbits Pink, fully assembled.

2. IMPORTANT SAFETY INFORMATION

WARNING: NEVER LEAVE CHILD UNATTENDED. ALWAYS KEEP CHILD IN VIEW WHILE IN WALKER. PREVENT ACCESS TO STAIRS, STEPS, AND UNEVEN SURFACES.

- Always ensure the walker is used on flat, level surfaces free from obstacles.
- Do not use the walker near stairs, steps, swimming pools, or any other hazardous areas.
- Regularly inspect the walker for loose parts, damage, or wear. Discontinue use if any damage is found.
- Ensure all locking mechanisms are securely engaged before placing your child in the walker.
- The maximum weight recommendation for this walker is 30 pounds. Do not exceed this limit.
- This product is intended for children who can sit up unassisted but cannot yet walk independently.
- Keep all packaging materials away from children to prevent suffocation.

3. PRODUCT FEATURES

The Smart Steps® Trend Plus 2-in-1 Walker is equipped with several features designed for your child's comfort, safety, and entertainment:

- **Removable STEM Toys:** The activity toys can be easily detached from the tray, allowing for on-the-go play.
- **Large Surround Tray:** Provides ample space for snacks and includes a convenient cup holder.
- **3-Position Height Adjustment:** The walker's height can be adjusted to three different positions to accommodate your growing child.
- **Folds Flat:** Designed for easy transport and compact storage.
- **Extra Wide Base:** Ensures superior support and stability during use.
- **Multi-directional Wheels:** Allows for freedom of movement across various floor types.

4. ASSEMBLY AND SETUP

Assembly of the Smart Steps® Trend Plus 2-in-1 Walker is straightforward. Please follow these general steps. Refer to the detailed PDF instructions for specific diagrams and steps if available (see Support section).

1. Unpack all components and verify against the parts list in your instruction manual.
2. Attach the base frame components, ensuring they click securely into place.
3. Insert the support legs into the designated slots on the base and main tray assembly.
4. Secure the seat fabric onto the seat frame and attach it to the main walker structure.
5. Place the activity tray with toys onto the main tray, ensuring it is properly seated.
6. Confirm all connections are firm and secure before first use.



Figure 4.1: The walker transitions from a compact folded state to its upright, ready-to-use position.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

The walker features a 3-position height adjustment to grow with your child. To adjust the height:

1. Ensure your child is not in the walker.
2. Locate the height adjustment buttons or levers, typically found on the walker's legs or frame.
3. Press the buttons/levers and simultaneously raise or lower the walker to the desired height.
4. Ensure both sides are adjusted to the same height and that the locking mechanisms are fully engaged before placing your child back in the walker.

5.2 Using the Activity Tray and Toys

The large activity tray provides a stable surface for play and snacks. The included STEM-based toys are designed to be engaging and can be removed for play outside the walker.

- To remove toys: Gently pull the toys upwards from their base on the tray.
- To reattach toys: Align the toy's base with the corresponding slot on the tray and press down firmly until it clicks into place.



Figure 5.1: Detailed view of the activity tray, showing the interactive STEM toys and snack space.



Figure 5.2: The removable STEM toys, designed for play both on and off the walker.

5.3 2-in-1 Functionality (Walker to Walk-Behind)

This product can transition from a traditional seated walker to a walk-behind aid. To convert:

1. Ensure your child is not in the walker.
2. Locate the conversion mechanism, typically a latch or button that allows the seat assembly to be folded or removed, and the rear handle to be extended or rotated into position.
3. Follow the specific instructions in your detailed manual to safely convert the unit.
4. Once converted, ensure all parts are securely locked for walk-behind use.

6. MAINTENANCE AND CARE

Regular cleaning and maintenance will ensure the longevity and hygiene of your Smart Steps® Trend Plus 2-in-1 Walker.

- **Seat Pad:** The high-back padded seat is easy to clean. Remove the seat pad from the frame. Hand wash with mild soap and cold water, or machine wash on a gentle cycle. Air dry completely before

reattaching.

- **Plastic Parts:** Wipe down all plastic surfaces, including the tray and base, with a damp cloth and mild soap. Rinse thoroughly with a clean damp cloth and dry completely.
- **Wheels:** Periodically check the wheels for debris (hair, lint, etc.) and clean as necessary to ensure smooth movement.
- **Metal Components:** Wipe metal parts with a dry cloth. Avoid abrasive cleaners.
- **General Inspection:** Regularly check all screws, bolts, and fasteners to ensure they are tight. Do not overtighten.

7. STORAGE

The Smart Steps® Trend Plus 2-in-1 Walker is designed to fold flat for convenient storage and transport.

1. Ensure the walker is clean and dry before folding.
2. Locate the folding mechanism (refer to your detailed manual for specific instructions).
3. Engage the mechanism to collapse the walker into its flat position.
4. Store in a cool, dry place away from direct sunlight and extreme temperatures.



Figure 7.1: The walker folded flat, demonstrating its compact design for easy storage or transport.

8. TROUBLESHOOTING

If you encounter any issues with your Smart Steps® Trend Plus 2-in-1 Walker, please refer to the following common solutions:

Problem	Possible Cause	Solution
Walker is difficult to move.	Used on carpeted surfaces; wheels are obstructed or dirty.	Ensure the walker is used on hard, flat surfaces. Clean any debris from the wheels.
Height adjustment is difficult.	Locking mechanisms are stiff or misaligned.	Apply gentle, even pressure when adjusting. Ensure buttons/levers are fully depressed. Do not force.
Toys do not stay on tray.	Toys not fully inserted or aligned.	Ensure toys are aligned with their respective slots and pressed down firmly until they click into place.

9. SPECIFICATIONS

Attribute	Detail
Product Dimensions	27 x 23.5 x 21.5 inches (L x W x H)
Item Model Number	WK07F10B
Maximum Weight Recommendation	30 Pounds
Material Type	Metal, Plastic, Polyester
Material Composition	70% Plastic, 20% Metal, 10% Polyester
Additional Product Features	Height adjustable, Removable Toys, STEM toys, Slim fold
Style	Activity Walker
Batteries Required	No
Item Weight	7.15 pounds
Color	Orbits Pink
Age Range (Description)	Infant



Figure 9.1: Key dimensions of the Smart Steps Trend Plus 2-in-1 Walker.





10. SUPPORT AND CONTACT INFORMATION


For further assistance, product registration, or warranty information, please contact Smart Steps customer support. You may also refer to the official Instructions for Use (IFU) PDF document for detailed diagrams and specific assembly steps.

- **Official PDF Manual:** A comprehensive PDF instruction manual is available for download.[Download Instructions for Use \(IFU\)](#)
- **Online Support:** Visit the Smart Steps official website for FAQs and support resources.
- **Customer Service:** Refer to the product packaging or the official website for direct contact information (phone, email).

© 2024 Smart Steps. All rights reserved. Product specifications are subject to change without notice.


Related Documents - WK07F10B

	<p>Baby Trend Buddy Bot 2-in-1 Push Walker: Assembly and Safety Guide</p> <p>Comprehensive guide for the Baby Trend Buddy Bot 2-in-1 Push Walker, including safety warnings, battery information, FCC compliance, care instructions, and assembly steps.</p>
	<p>Kolcraft Tiny Steps Roadster 2-in-1 Activity Walker: Assembly, Safety, and Use Guide</p> <p>This guide provides comprehensive instructions for the Kolcraft Tiny Steps Roadster 2-in-1 Activity Walker. It covers important safety information, assembly steps, parts list, care and maintenance, seat height adjustment, and conversion to a walk-behind walker.</p>
	<p>Cisco Unified Contact Center Express Editor Step Reference Guide, Release 11.0(1)</p> <p>A comprehensive guide detailing the steps available within the Cisco Unified Contact Center Express Editor for developing interactive scripts. This volume covers individual steps, their functionalities, and usage within various palettes, including General, Trigger, Session, Contact, Call, eMail, HTTP, Media, User, Prompt, Grammar, Document, Database, and ACD steps.</p>
	<p>Baby Trend Bounce N' Play 3-in-1 Activity Center AC01XXXXA Instruction Manual</p> <p>Instruction manual for the Baby Trend Bounce N' Play 3-in-1 Activity Center (Model AC01XXXXA). Provides detailed guidance on assembly, safety precautions, parts identification, usage, and maintenance. Includes warnings for strangulation and fall hazards, FCC compliance information, and customer service contact details.</p>



Fruyyzl RV Steps with Handrail Installation Instructions

Step-by-step installation guide for Fruyyzl RV Steps with Handrail, a 2-step outdoor RV stair with anti-slip pedals and a handrail, suitable for campers, porches, and spas.



Installation Instructions for 5-Step Stool with Handle

Step-by-step guide for assembling a 5-step stool with a handle, including a list of parts and detailed visual instructions.