



Manuals.plus /

› WANAI /

› WANAI Compact Refrigerator 3.2 Cu.Ft Retro Mini Fridge with Freezer - Instruction Manual

**WANAI BCD72-BLACK**

# WANAI Compact Refrigerator 3.2 Cu.Ft Retro Mini Fridge with Freezer

Model: BCD72-BLACK - Instruction Manual

## 1. INTRODUCTION AND OVERVIEW

---

Thank you for choosing the WANAI Compact Refrigerator. This 3.2 cubic feet retro-style mini fridge with a separate freezer compartment is designed for convenience and efficiency in various settings such as apartments, campers, dorms, and offices. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting.



Figure 1: Front view of the WANAI Compact Refrigerator.

# Suitable for Anywhere



KITCHEN



BAR



OFFICE



DORM

Figure 2: The WANAI Compact Refrigerator is suitable for kitchens, bars, offices, and dorms.

## 2. SAFETY INFORMATION

---

Before operating the appliance, please read all safety instructions carefully to reduce the risk of fire, electric shock, or injury.

- Ensure the refrigerator is placed on a stable, level surface.
- Allow the refrigerator to stand upright for at least 24 hours before plugging it in to allow the refrigerant to settle.
- Do not use mechanical devices or other means to accelerate the defrosting process.
- Do not damage the refrigerant tubing.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is intended for household use only.

## 3. UNBOXING AND SETUP

---

Carefully remove the refrigerator from its packaging. It is recommended to have two people for safe unboxing and placement.

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing process and initial setup of the WANAI Compact Refrigerator, including how to remove packaging and stabilize the unit.

### 3.1 Placement

Place the refrigerator on a firm, level floor. Ensure there is adequate space around the unit for proper ventilation (at least 4 inches on the sides and back, and 8 inches on top).

### 3.2 Leveling the Refrigerator

The refrigerator is equipped with adjustable leveling legs at the front. Turn the legs clockwise to raise the unit or counter-clockwise to lower it. Ensure the refrigerator is level to prevent vibrations and ensure proper door sealing.





Figure 3: Close-up view of the adjustable legs and thermostat dial inside the refrigerator.

## 4. FEATURES

- **2-Door Design:** Separate freezer and refrigerator compartments for optimal food storage.
- **Super Quiet Operation:** Equipped with a powerful and efficient R600a compressor for low noise levels.
- **Crisper Drawer:** Dedicated drawer for fruits and vegetables to maintain freshness.
- **Energy Saving:** Designed with R600a high-efficiency compressor for lower energy consumption.
- **Adjustable Shelves:** Removable glass shelves allow for flexible storage configurations.
- **7 Temperature Modes:** A thermostat dial provides 7 settings for precise temperature control.

- **LED Lighting:** Interior LED light illuminates the refrigerator compartment when the door is open.

# Hanaí

## 2-DOOR REFRIGERATOR

SMALL SIZE BUT BIG CAPACITY



Figure 4: Interior layout with separate freezer and cooler sections.

# LOW NOISE

Have a comfortable resting or working environment




Figure 5: Illustration of the refrigerator's low noise operation, ensuring a comfortable environment.

## FREEZER

Fast freezer ice-cream, seafood etc.



Figure 6: Examples of frozen items that can be stored in the freezer compartment.

## COOLER

Keep food cold and fresh



Figure 7: Examples of fresh food and beverages that can be stored in the cooler compartment.

## 5. OPERATING INSTRUCTIONS

### 5.1 Temperature Control

The refrigerator features a 7-level thermostat control dial located inside the fresh food compartment. Turn the dial to adjust the temperature. Setting '1' is the warmest, and '7' is the coldest. '0' is used for defrosting. It is recommended to start at setting '4' and adjust as needed based on your cooling requirements and ambient temperature.

### 5.2 Adjustable Shelves

The glass shelves inside the fresh food compartment are removable and can be adjusted to different heights to accommodate items of various sizes. To adjust, carefully lift the shelf and slide it out. Reinsert into desired slots.

### 5.3 Crisper Drawer

The crisper drawer is located at the bottom of the fresh food compartment and is ideal for storing fruits and vegetables to help them stay fresh longer.

### 5.4 Door Storage

The refrigerator door includes multiple shelves and compartments for storing bottles, cans, and smaller items, maximizing storage efficiency.

## 6. MAINTENANCE

---

### 6.1 Defrosting

This refrigerator features manual defrost. When frost accumulates to a thickness of 0.2 inches (5mm) or more, it should be defrosted. To defrost, turn the thermostat dial to '0' (OFF) and unplug the unit. Remove all food items and allow the frost to melt naturally. Use a soft cloth to wipe away melted water. Do not use sharp objects to remove frost.

### 6.2 Cleaning

Regularly clean the interior and exterior of the refrigerator. Unplug the unit before cleaning. Use a mild detergent and warm water to wipe down surfaces. Avoid abrasive cleaners or solvents. Ensure all parts are dry before plugging the unit back in.

## 7. TROUBLESHOOTING

---

If you experience issues with your refrigerator, please check the following common problems before contacting customer service:

- **Refrigerator does not operate:** Check if the power cord is properly plugged in and if the circuit breaker is tripped. Ensure the thermostat is not set to '0' (OFF).
- **Temperature is not cold enough:** Adjust the thermostat to a colder setting. Ensure the door is closed properly and not opened too frequently. Check for proper ventilation around the unit.
- **Unusual noises:** Ensure the refrigerator is level. Check if any objects are vibrating against the unit.
- **Excessive frost buildup:** This is normal for manual defrost units. Defrost the unit as described in the maintenance section.

## 8. SPECIFICATIONS

---

<b>Brand Name</b>	WANAI
<b>Model Info</b>	BCD72-BLACK
<b>Item Weight</b>	36 pounds
<b>Product Dimensions</b>	17.7 x 18.8 x 35.4 inches
<b>Capacity</b>	3.2 Cubic Feet (Overall)
<b>Installation Type</b>	Freestanding
<b>Special Features</b>	Adjustable Shelves, Crisper Drawer
<b>Color</b>	Black
<b>Voltage</b>	110 Volts
<b>Number Of Doors</b>	2
<b>Defrost System</b>	Manual Defrost
<b>Certification</b>	Energy Star

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your product or contact WANAI customer service directly. Our customer service is available 24 hours a day to assist with any after-sales questions or concerns.

Contact information can typically be found on the manufacturer's website or on the product packaging.