MIRROTOWEL XG-H4

MIRROTOWEL Shoe Cabinet (Model XG-H4) Instruction Manual

Model: XG-H4 | Brand: MIRROTOWEL

1. Introduction

Thank you for choosing the MIRROTOWEL Shoe Cabinet, Model XG-H4. This slim, narrow shoe rack cabinet is designed to help organize your footwear efficiently in various spaces such as entryways, foyers, hallways, and bedrooms. Featuring four drawers, it offers a practical and aesthetically pleasing storage solution. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new shoe cabinet.



Image 1.1: The MIRROTOWEL Shoe Cabinet, Model XG-H4, shown in a modern home setting.

2. Safety Information

WARNING: Always secure the back of the cabinet to the wall using the anti-tipping device to prevent accidental

tipping and ensure the safety of children and pets. Failure to do so can result in serious injury.



Image 2.1: Illustration of the anti-tipping device, crucial for securing the cabinet to a wall.

3. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included assembly diagram for specific part identification.

- Cabinet Panels (Top, Bottom, Sides, Back)
- Drawer Fronts (4 units)
- Internal Shelves/Partitions (for drawers)
- Drawer Mechanisms and Hardware
- Handles (4 units)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tipping Device Kit
- Assembly Instructions Manual

4. Setup and Assembly Instructions

Assembly is required for this shoe cabinet. Please follow the detailed instructions provided in the separate assembly manual included in your package. Below are general guidelines and key considerations:

1. **Preparation:** Clear a spacious area for assembly. Lay out all components and hardware. It is recommended to have a soft surface (e.g., a blanket) to prevent scratches during assembly.
2. **Frame Assembly:** Begin by assembling the main cabinet frame according to the step-by-step diagrams. Ensure all connections are secure.
3. **Drawer Mechanism Installation:** Install the flip-up drawer mechanisms. These allow each compartment to store shoes on two levels.
4. **Movable Partitions:** The internal partitions within each drawer are adjustable. Install them at the desired height based on your shoe sizes. They can also be removed for larger items.
5. **Attach Handles:** Securely attach the metal handles to each drawer front.
6. **Back Panel:** Install the back panel to enhance stability and enclose the cabinet.

7. **Anti-Tipping Device: Crucially,** install the anti-tipping device to a sturdy wall stud or appropriate anchor point. This prevents the cabinet from falling forward, especially important in households with children or pets.



Image 4.1: Product dimensions for planning placement and assembly.



Image 4.2: Detail of the flip-up drawer design, showing how shoes are stored on two levels.



Image 4.3: Movable partitions allow flexible adjustment for different shoe types and sizes.

5. Operating Instructions

The MIRROTOWEL Shoe Cabinet is designed for simple and efficient shoe storage.

- **Opening Drawers:** Gently pull the metal handle on each drawer front. The drawer will tilt forward, revealing two levels of shoe storage.
- **Storing Shoes:** Place shoes on the internal shelves. The movable partitions can be adjusted to accommodate various shoe heights. For optimal space utilization, place shoes with toes pointing inwards.
- **Closing Drawers:** Push the drawer back into the cabinet until it is fully closed and flush with the cabinet front.
- **Top Surface:** The top surface of the cabinet can be used for decorative items or small essentials.



Image 5.1: Multi-functional storage in action, keeping living spaces tidy.




Image 5.2: Shoe capacity guidelines for different sizes and partition configurations.

Video 5.1: Official product video demonstrating the features and usage of the MIRROTOWEL Shoe Cabinet.

6. Maintenance

To keep your MIRROTOWEL Shoe Cabinet in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or water damage, as the material is engineered wood.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Overloading:** Do not overload the drawers or place excessively heavy items on the top surface to prevent structural damage.



Image 6.1: The cabinet is constructed from high-quality, engineered wood designed to be waterproof and stain-resistant.

7. Troubleshooting

If you encounter any issues with your shoe cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Shoes do not fit in drawers.	Partitions set too high/low; shoes are too large (e.g., men's size 11+).	Adjust the movable partitions to create more space. For very large shoes, consider removing partitions or placing shoes diagonally. Refer to Image 5.2 for capacity guidelines.
Cabinet feels unstable or wobbly.	Not properly secured to the wall; loose assembly hardware.	Ensure the anti-tipping device is correctly installed and anchored to a sturdy wall. Check and tighten all assembly screws.
Drawers do not close smoothly.	Obstruction inside the drawer; misaligned drawer mechanism.	Check for shoes or other items blocking the drawer's path. Inspect the drawer mechanism for proper alignment and ensure all hardware is tight.
Surface scratches or blemishes.	Impact during assembly or use.	Minor scratches can sometimes be touched up with furniture repair pens. Prevent future damage by using soft pads under items placed on top.

8. Product Specifications

Feature	Detail
Brand	MIRROTOWEL
Model Number	XG-H4
Color	Grey
Material	Engineered Wood
Product Dimensions (D x W x H)	9.4" x 30.9" x 40.3"
Number of Drawers	4
Number of Shelves (internal)	3 (adjustable per drawer)
Handle Material	Metal
Mounting Type	Floor Mount (with wall anchor for safety)
Assembly Required	Yes
Care Instructions	Wipe with Damp Cloth
UPC	733506868026

9. Warranty Information

MIRROTOWEL products are manufactured with quality and care. For specific warranty details regarding your shoe cabinet, please refer to the warranty card included in your package or contact MIRROTOWEL customer support. Typically, warranties cover manufacturing defects under normal use conditions.

10. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact MIRROTOWEL customer support. You can usually find contact information (email, phone, or website) on the product packaging or the brand's official Amazon store page.
For online support, visit the MIRROTOWEL Store on Amazon.

© 2026 MIRROTOWEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question