

[Manuals.plus](#) /

› [ZIYOU LANG](#) /

› ZIYOU LANG V600 Gaming Keyboard User Manual

ZIYOU LANG V600

ZIYOU LANG V600 Gaming Keyboard User Manual

Model: V600

INTRODUCTION

Thank you for choosing the ZIYOU LANG V600 Gaming Keyboard. This manual provides essential information for setting up, operating, and maintaining your keyboard. Please read these instructions carefully to ensure proper use and to maximize your gaming and typing experience.

SETUP

Connecting the Keyboard

1. Unpack the ZIYOU LANG V600 Gaming Keyboard from its packaging.
2. Locate an available USB port on your computer.
3. Plug the USB connector of the keyboard into the USB port.
4. Your computer should automatically detect and install the necessary drivers. No additional software installation is typically required for basic functionality.

OPERATING INSTRUCTIONS

Key Features

- **Floating Keycaps:** The keyboard features floating keycaps, which provide a distinct tactile feel and facilitate easier cleaning.
- **96-Key RGB Lighting:** Enjoy dynamic RGB backlighting with various effects to enhance your gaming setup.
- **Full-Key Conflict-Free Design (Anti-Ghosting):** All 96 keys are designed to be conflict-free, ensuring that every keystroke is registered accurately, even during rapid, simultaneous presses. This model supports 26-key anti-ghosting.

FLOATING KEYCAPS



Image: The ZIYOU LANG V600 keyboard showcasing its floating keycap design, which allows for easier cleaning and a distinct typing feel.

96-KEY RGB LIGHTING GAMING KEYBOARD



Image: The ZIYOU LANG V600 keyboard illuminated with its 96-key RGB lighting, highlighting the customizable backlighting effects.

FULL-KEY CONFLICT-FREE DESIGN

All 96 keys are conflict-free ,
which can achieve ultimate gaming performance;
Let the game flow unimpeded.



Image: A user interacting with the ZIYOU LANG V600 keyboard, illustrating the full-key conflict-free design for accurate keystroke registration during intense use.

Multimedia FN Shortcuts

The keyboard includes a range of multimedia function (FN) shortcuts to enhance productivity and control media playback. Press and hold the **FN** key, then press the corresponding function key:

- **FN + F1:** Open Multimedia Player
- **FN + F2:** Decrease Volume
- **FN + F3:** Increase Volume
- **FN + F4:** Mute Audio
- **FN + F5:** Previous Track
- **FN + F6:** Next Track
- **FN + F7:** Play/Pause Media
- **FN + F8:** Stop Media Playback
- **FN + F9:** Open Home Page

- **FN + F10:** Open Mail Application
- **FN + F11:** Open My Computer
- **FN + F12:** Open Favorites
- **FN + W:** Toggle W/A/S/D keys with Arrow keys (Default: W/A/S/D active)

COMPOUND FUNCTION KEY SWITCH

The FN group of multi-function shortcut keys allows you to do whatever you want in the office/game.




Image: A detailed view of the ZIYOU LANG V600 keyboard, illustrating the various FN key combinations for multimedia and system functions.

12 MULTIMEDIA FN SHORTCUTS

Save Time, Make Using Easier



Image: The ZIYOU LANG V600 keyboard highlighting the FN+W function, which allows users to swap the functionality of the W/A/S/D keys with the arrow keys.

Backlight Control

The keyboard features customizable RGB backlighting. While specific modes are not detailed, the keyboard typically allows for cycling through various lighting effects and adjusting brightness. Look for a dedicated backlight key or an FN combination (often with Scroll Lock or a specific F-key) to control the lighting.

MAINTENANCE

Cleaning the Keyboard

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, dry cloth to wipe down the keycaps and keyboard surface.
- For stubborn dirt, a slightly damp cloth with a mild cleaning solution can be used, ensuring no liquid enters the keyboard.

- Use compressed air to remove dust and debris from between the keys. The floating keycap design makes this process easier.
- Avoid using harsh chemicals or abrasive materials, as these can damage the keyboard's finish.

TROUBLESHOOTING

Keyboard Not Responding

- Ensure the USB cable is securely plugged into both the keyboard and the computer.
- Try plugging the keyboard into a different USB port on your computer.
- Restart your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or your system.

Specific Keys Not Working

- Check for any physical obstructions or debris under the affected keycap.
- Gently remove the keycap (if removable) and clean the switch area with compressed air.
- If the issue persists, it may indicate a hardware malfunction.

Backlight Issues


- Ensure the backlight is not turned off using the dedicated backlight key or FN combination.
- Try cycling through different lighting modes to see if the issue is with a specific mode.
- If only certain keys are not lighting up, it might indicate a localized LED failure.

SPECIFICATIONS

Model	V600
Key Count	96 Keys
Anti-Ghosting	26-Key Anti-Ghosting
Cable Length	1.8 meters
Dimensions (L x W x H)	388.5mm x 138mm x 38mm
Design Features	Floating Keycaps, RGB Backlighting, Anti-Slip Design



Image: The ZIYOU LANG V600 keyboard, illustrating its 1.8-meter cable length for flexible connectivity.



Anti Slip Design^{ti}

Image: The underside of the ZIYOU LANG V600 keyboard, showcasing its anti-slip design for stability during use, along with the product label indicating the V600 model.



Image: A diagram illustrating the physical dimensions of the ZIYOU LANG V600 keyboard: 388.5mm length, 138mm width, and 38mm height.

WARRANTY AND SUPPORT

Specific warranty information for the ZIYOU LANG V600 Gaming Keyboard is not provided in this manual. Please refer to the retailer or manufacturer's official website for details regarding warranty coverage and customer support. For technical assistance, contact ZIYOU LANG customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question