

AUSDOM ABE7

AUSDOM ABE7 Bluetooth Noise Cancelling Headphones User Manual

Model: ABE7

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your AUSDOM ABE7 Bluetooth Noise Cancelling Headphones. Please read this manual thoroughly before using the product to ensure proper function and longevity. These headphones are designed to deliver high-fidelity audio with advanced Active Noise Cancellation (ANC) technology, extended playtime, and comfortable wear for various environments.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x AUSDOM ABE7 Bluetooth Noise Cancelling Headphones
- 1 x Type-C Charging Cable
- 1 x Carry Bag
- 1 x 3.5mm Audio Cable
- 1 x User Manual (this document)

PRODUCT OVERVIEW

The AUSDOM ABE7 headphones feature an over-ear design with soft ear cushions and an adjustable headband for comfort. Key controls are located on the earcups for easy access.



Figure 1: AUSDOM ABE7 Bluetooth Noise Cancelling Headphones, Silver and Black. The image displays the headphones with their adjustable headband, comfortable earcups, and a small carry bag in the background.

The headphones are equipped with 40mm large-aperture drivers for superior sound quality and a built-in microphone for clear communication.




Figure 2: Internal components of the AUDDOM ABE7 headphones, highlighting the 40mm dynamic drivers responsible for audio output.

SETUP

1. Charging the Headphones

Before initial use, fully charge the headphones. A full charge takes approximately 2.5 hours and provides up to 50 hours of playtime in standard mode or 35 hours with Active Noise Cancellation enabled. A quick 5-minute charge can provide 2 hours of listening time.

1. Connect the supplied Type-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will show charging status (refer to the LED indicator section for details, if available on the device).
4. Once fully charged, disconnect the charging cable.



Figure 3: Illustration of the AUDDOM ABE7 headphones connected for charging using the Type-C cable.

2. Bluetooth Pairing

To connect your headphones to a device:

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, laptop, tablet), enable Bluetooth and search for available devices.
4. Select "AUDDOM E7" from the list of found devices.
5. Once connected, the LED indicator will flash blue periodically.

3. Multipoint Connectivity

The AUDDOM ABE7 headphones support connecting to two Bluetooth devices simultaneously, allowing seamless switching between audio sources (e.g., phone and laptop).

1. Pair the headphones with the first device following the steps above.
2. Disable Bluetooth on the first device.
3. Put the headphones back into pairing mode and pair with the second device.
4. Re-enable Bluetooth on the first device. The headphones should automatically connect to both devices.
5. Audio will play from the device that is actively transmitting.

IMPRESSIVE SOUND

Dual 40mm high-range drivers deliver heart-pounding bass and audio.




Figure 4: The AUSDOM ABE7 headphones demonstrating simultaneous Bluetooth connection to both a smartphone and a laptop, enabling multipoint functionality.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes blue.
- **Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes red and then turns off.

2. Active Noise Cancellation (ANC)

The ANC feature reduces up to 92% of low-frequency ambient noise, such as engine hums from aircraft or vehicles.

- **Activate ANC:** Press the dedicated ANC button (usually located on one earcup). The ANC indicator light will illuminate.
- **Deactivate ANC:** Press the ANC button again. The ANC indicator light will turn off.

ACTIVE NOISE CANCELLATION

Enhanced Active NC technology reduces 92% of unwanted low-frequency ambient noise.



Figure 5: A visual representation of how Active Noise Cancellation technology in the AUSDOM ABE7 headphones reduces ambient noise, showing a significant reduction compared to other headphones.

3. Music Playback Controls

Use the buttons on the earcup to control your music:

- **Play/Pause:** Press the Multi-function button once.
- **Volume Up:** Press the Volume Up button.
- **Volume Down:** Press the Volume Down button.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.

4. Call Management

The built-in microphone allows for hands-free calling:

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

5. Wired Mode

You can use the headphones in wired mode with the supplied 3.5mm audio cable, even if the battery is depleted. Connect one end of the 3.5mm audio cable to the headphone's audio jack and the other end to your audio source.

MAINTENANCE

Proper care ensures the longevity of your headphones:

- **Cleaning:** Use a soft, dry cloth to clean the earcups and headband. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in the provided carry bag to protect them from dust and scratches. Avoid storing in extreme temperatures.
- **Water Exposure:** These headphones are not waterproof. Avoid exposure to liquids and high humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth disabled on device; too far from device.	Ensure headphones are in pairing mode (flashing red/blue). Enable Bluetooth on your device. Move headphones closer to the device (within 33 feet/10 meters).
No sound or low volume.	Volume too low on headphones or device; incorrect audio output selected; headphones not connected.	Increase volume on both headphones and device. Check device's audio output settings. Reconnect headphones.
ANC not working effectively.	ANC feature not activated; type of noise not suitable for ANC.	Ensure ANC is activated (indicator light on). ANC is most effective against low-frequency, constant hums, not sudden or high-frequency sounds.

SPECIFICATIONS

Feature	Detail
Model Name	ABE7S
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Noise Control	Active Noise Cancellation
Headphones Jack	3.5 mm Jack
Audio Driver Size	40 Millimeters
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohm

Feature	Detail
Battery Life	Up to 50 Hours (Standard Mode), 35 Hours (ANC Mode)
Charging Time	2.5 Hours
Bluetooth Range	33 Feet (10 meters)
Item Weight	9.6 ounces
Material	Leather, Plastic, Stainless Steel
Compatible Devices	Cellphones, Laptops, Tablets, PC




WARRANTY AND SUPPORT




AUSDOM products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included in your package or visit the official AUSDOM website. Please retain your proof of purchase for any warranty claims.

For further assistance, you may contact AUSDOM customer service through their official channels.

© 2023 AUSDOM. All rights reserved.

Related Documents - ABE7

	<p>AUSDOM ANC1 Wireless Headphones User Manual</p> <p>Comprehensive user manual for the AUSDOM ANC1 wireless headphones, covering setup, pairing, features, troubleshooting, and specifications. Learn how to use your ANC1 headphones effectively.</p>
	<p>AUSDOM Voipfocus Connect Mono Wireless Headset User Manual - Features, Specs, and Pairing Guide</p> <p>Comprehensive user manual for the AUSDOM Voipfocus Connect mono wireless headset. Learn about setup, charging, Bluetooth pairing, controls, specifications, and warranty information for this on-ear headset.</p>
	<p>AUSDOM ANC10 Wireless Noise Cancelling Headphones User Manual</p> <p>Comprehensive user manual for the AUSDOM ANC10 Wireless Active Noise Cancelling Headphones, covering introduction, package contents, product overview, charging, Bluetooth pairing, active noise cancelling features, call handling, care instructions, control functions, troubleshooting, specifications, and warranty information.</p>

	<p>AUDOM Hola 98 Pro Wireless Mechanical Keyboard User Manual</p> <p>User manual for the AUDOM Hola 98 Pro Wireless Mechanical Keyboard, providing setup, usage, and technical information.</p>
	<p>AUDOM AW651S FHD 2K Webcam User Manual</p> <p>User's manual for the AUDOM AW651S FHD 2K Webcam. Learn about package contents, system requirements, product overview, mounting, connecting, usage on Windows and Mac, and specifications.</p>
	<p>AUDOM AF640 4K Webcam User Manual</p> <p>This user manual guides you through the setup and operation of the AUDOM AF640 4K UHD Webcam. Learn about its features, system requirements, and how to achieve high-quality video for calls and streaming.</p>