

Vicco Eliza 40425

Vicco Eliza Nightstand Instruction Manual

Model: Eliza 40425

1. IMPORTANT SAFETY INFORMATION

WARNING: TIPPING HAZARD! Unanchored furniture can tip over. To prevent this furniture from tipping, it must be securely anchored to the wall. Appropriate fastening accessories suitable for your home's walls should be used. If you have any questions, please consult your local specialized retailer. Please follow each step of the instructions carefully. Keep these instructions for future reference. Read them carefully before assembly and use.

2. PRODUCT OVERVIEW

The Vicco Eliza Nightstand is a modern bedside table designed for bedrooms and children's rooms. It features two drawers, offering practical storage. Its dimensions are 66 cm (width) x 36 cm (depth) x 60 cm (height). The nightstand is constructed from 16 mm particle board with a melamine resin coating.



Figure 2.1: The Vicco Eliza Nightstand (Grey) in a bedroom environment, showcasing its modern design and two drawers.




Figure 2.2: Detailed dimensions of the Eliza Nightstand: 66 cm width, 36 cm depth, and 60 cm height. Drawer internal width is approximately 61.8 cm and height 21.7 cm.

3. SETUP AND ASSEMBLY

The Vicco Eliza Nightstand requires assembly. It is recommended that one person performs the assembly.

3.1 Required Tools

- Screwdriver (not included)

3.2 Assembly Steps

Please refer to the detailed assembly instructions provided in the packaging. The instructions are in German. Follow these general guidelines for a smooth assembly:

1. **Unpack all components:** Carefully remove all parts from the packaging and verify against the parts list in the manual. Ensure no parts are missing or damaged.
2. **Identify parts:** Although parts may not be numbered, identify each component by comparing it with the diagrams in the assembly manual.
3. **Assemble the frame:** Begin by connecting the main structural panels according to the diagrams. Ensure all connections are secure.
4. **Install drawer runners:** Attach the drawer runners to the side panels of the nightstand and the drawer boxes. Pay close attention to the orientation of the runners to ensure smooth operation.
5. **Assemble drawers:** Construct the drawer boxes. Insert the bottom panel into the grooves and secure the back panel.
6. **Attach drawer fronts:** Secure the drawer fronts to the assembled drawer boxes. Ensure they are aligned correctly.
7. **Insert drawers:** Carefully slide the assembled drawers into the nightstand frame. Test for smooth operation.
8. **Attach handles:** Secure the handles to the drawer fronts.

9. **Install feet:** Attach the legs/feet to the base of the nightstand.
10. **Wall anchoring:** For safety, anchor the nightstand to the wall using appropriate hardware (not always included, check your package contents). This prevents tipping.



Figure 3.1: An overview of the nightstand, showing its closed state and an exploded view of the drawers, indicating the assembly process.



Figure 3.2: Close-up view of the open drawers, illustrating the drawer runners and internal construction, crucial for correct assembly.

4. OPERATING INSTRUCTIONS

The Vicco Eliza Nightstand is designed for personal use in a bedroom.

4.1 Using the Drawers

- Gently pull the handles to open the drawers.
- Push the drawers firmly but smoothly to close them completely.
- Avoid overloading the drawers to ensure smooth operation and prevent damage to the runners.

4.2 Placement

- Place the nightstand on a flat, stable surface to prevent wobbling.
- Ensure it is not exposed to direct sunlight or excessive moisture, which can damage the material.



Figure 4.1: The nightstand with both drawers partially open, demonstrating its storage capacity and accessibility.

5. MAINTENANCE

To ensure the longevity and appearance of your Vicco Eliza Nightstand, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the melamine coating.
- **Spills:** Immediately wipe up any spills to prevent staining or moisture damage.
- **Hardware:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary to maintain stability.
- **Avoid excessive weight:** Do not place items heavier than the recommended maximum weight (21.8 kg) on the nightstand.

6. TROUBLESHOOTING

If you encounter any issues with your Vicco Eliza Nightstand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Nightstand is wobbly.	Uneven floor or loose fittings.	◦ Ensure the nightstand is on a flat surface. ◦ Check and tighten all assembly screws. ◦ If the floor is uneven, use furniture pads or shims under the legs to level it.
Drawers do not slide smoothly or open/close by themselves.	Incorrectly installed drawer runners, misaligned drawer boxes, or overloaded drawers.	◦ Recheck the installation of the drawer runners on both the nightstand frame and the drawer boxes. Ensure they are level and correctly oriented. ◦ Verify that the drawer boxes are assembled squarely and not warped. ◦ Reduce the weight in the drawers if they are overloaded. ◦ Ensure the nightstand itself is level (see "Nightstand is wobbly" solution).
Missing parts during assembly.	Packaging error or parts overlooked.	◦ Carefully re-check all packaging materials. ◦ Contact the retailer or manufacturer's customer support with your purchase details and a list of missing parts.

7. SPECIFICATIONS

Feature	Detail
Brand	Vicco
Model Name	Eliza
Model Number	40425
Color	Grey
Product Dimensions (D x W x H)	36 cm x 66 cm x 60 cm
Item Weight	19.8 Kilograms
Maximum Recommended Weight	21.8 Kilograms
Frame Material	Engineered Wood (16 mm particle board)
Finish Type	Melamine Resin Coating (Laminated)
Number of Drawers	2
Assembly Required	Yes
Recommended Assembly Persons	1
Recommended Tools	Screwdriver

Feature	Detail
Intended Use	Indoor, personal use in a bedroom

8. WARRANTY AND SUPPORT

Specific warranty details for the Vicco Eliza Nightstand are not provided in this manual. Please refer to your purchase documentation or contact the retailer for warranty information.

For customer support, assembly assistance, or to report missing/damaged parts, please contact the seller "ok-living" directly through the platform where you made your purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question