Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WANAI 100A-Sliver

WANAI Compact Refrigerator

User Manual

Model: 100A-Sliver

1. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance must be properly installed and located in accordance with the Installation Instructions before it is used.
- Unplug the refrigerator before cleaning or making any repairs.
- Ensure proper ventilation around the appliance for efficient operation and safety.
- Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

2. Product Overview

Key Features

- **Large Capacity:** Dimension: 17.7 x 18.8 x 35.4 inches, this compact fridge can fit it anywhere you want, perfect size for to fit in your apartment, kitchen, living room and dorm. It requires little space of storage room, perfect for apartment, dorm, office, bedroom and RV, also an ideal choice for saving space.
- **Two Door Design:** This Mini fridge with two door deign allows to store various of foods, like steak, seafood, ice cream, vegetable, etc, which has large capacity of 3.5 cu.ft Adjustable level feet provide convenience for placing the refrigerator.
- **Adjustable Temperatures & Freezer:** The compact refrigerator has 5 temperature control mode, Ranges from 24.8° F to 50° F, which offer a great variety of temperature condition to make ice cubes, keep your food fresh and drinks chilled. Meet your different requirements of different foods.
- **Super Quiet Design:** Operates at a low noise of 39 dB, this fridge brings the peace and refreshing cold. At the same time, it provides comfortable and quiet environment for sleeping, working, reading. Free of any disturbance while it’s keeping all your food nice and fresh, ideal for environment like bedroom, office and study.

- **ENERGY SAVING:** Lower energy consumption design with R600a high-efficiency compressor.This not only means WANAI Mini fridge are more environmentally friendly, but also allow you to save on your next energy bill.

Components



Front view of the WANAI 3.5 Cu.ft Compact Refrigerator in silver, showcasing its two-door design.



Diagram highlighting key features of the refrigerator: energy saving, low noise operation, efficiency, and dual-temperature storage capabilities.



Illustration emphasizing the low noise operation of the refrigerator, less than 39dB.



Visual representation of the refrigerator's versatility, suitable for apartment, kitchen, office, and dorm environments.

3. Setup and Installation

Unpacking

Carefully remove all packaging materials from the refrigerator. Ensure no parts are left inside the unit. Dispose of packaging responsibly.

Placement

Place the refrigerator on a flat, stable surface. Allow adequate space around the unit for proper ventilation (at least 4 inches on sides and back, 8 inches on top). Avoid direct sunlight or heat sources.



Image showing the compact refrigerator with its dimensions: 17.7 inches depth, 18.1 inches width, and 36 inches height.

Leveling

The refrigerator is equipped with adjustable leveling legs. Adjust these legs to ensure the unit is perfectly level, which is crucial for optimal performance and door alignment.



Close-up view of the refrigerator's interior showing removable glass shelves and an illustration of the adjustable leveling leg at the bottom.

Initial Power-On

After placement and leveling, wait at least 2-4 hours before plugging the refrigerator into a power outlet. This allows the refrigerant to settle. Once plugged in, allow the unit to cool for several hours before loading with food.

4. Operating Instructions

Temperature Control

The refrigerator features a 7-mode temperature control knob located inside the fresh food compartment. Turn the knob to adjust the temperature setting. Setting '1' is the warmest, and '7' is the coldest. The recommended setting for general use is '4'.



Internal view of the refrigerator showing distinct temperature zones: the freezer compartment suitable for seafood, ice cream, and meat (-0.3°F to -13°F), and the refrigerator compartment for fruits, vegetables, eggs, and drinks (32°F to 50°F).

Food Storage Guidelines

The two-door design provides separate compartments for freezing and refrigeration. The top freezer compartment has a capacity of 1.2 cubic feet, ideal for frozen goods like ice cream, meat, and seafood. The bottom fresh food compartment has a capacity of 2.3 cubic feet, suitable for fruits, vegetables, beverages, and other refrigerated items. The removable glass shelves allow for flexible storage arrangements.



Interior view of the 2-door refrigerator, detailing the freezer capacity of 1.2 cubic feet and refrigerator fresh food capacity of 2.3 cubic feet, along with the adjustable 7-temperature thermostat knob.

Product Demonstration Video

Official product video demonstrating the interior layout, storage capacity, and features of the WANAI Compact Refrigerator, including the separate freezer and refrigerator compartments.

5. Care and Maintenance

Cleaning

Regularly clean the interior and exterior of the refrigerator. Unplug the unit before cleaning. Use a soft cloth with a mild detergent and warm water. Avoid abrasive cleaners or sharp objects that could damage surfaces. Dry thoroughly after cleaning.

Defrosting

The freezer compartment may accumulate frost. When the frost layer is about 0.2 inches (5mm) thick, defrost the unit. Unplug the refrigerator, remove all food, and leave the freezer door open to allow frost to melt naturally. Place a towel at the bottom to collect water. Do not use sharp objects to remove frost.

6. Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Refrigerator does not operate	Not plugged in; Circuit breaker tripped/blown fuse; Temperature control set to OFF.	Ensure plug is secure; Reset circuit breaker/replace fuse; Adjust temperature control.
Temperature is too warm	Door opened too frequently; Large amount of warm food added; Poor ventilation; Gasket not sealing properly.	Reduce door openings; Allow food to cool before storing; Ensure proper clearance; Check and clean door gasket.
Excessive noise	Refrigerator not level; Parts vibrating; Compressor cycling.	Adjust leveling legs; Ensure nothing is touching the back or sides; This is normal operation.
Water on floor	Drain tube clogged; High humidity.	Clear drain tube; This is normal in humid conditions.

7. Product Specifications

Specification	Detail
Brand Name	WANAI
Model Info	100A-Sliver
Product Dimensions	17.7 x 18.8 x 35.4 inches
Item model number	100A-Sliver
Capacity	3.5 Cubic Feet
Installation Type	Freestanding
Part Number	BCD-100A-Silver
Form Factor	Compact
Special Features	Compact
Color	Silver
Voltage	110 Volts
Crispers/Drawers	1
Defrost	Electric defrost or Hot gas defrost
Door Hinges	Right

Specification	Detail
Door Material Type	Stainless Steel
Shelves	2
Number Of Doors	2
ASIN	B0C9HV9RBZ
Date First Available	June 27, 2023
Refrigerant	R-600A

8. Warranty and Customer Support

WANAI products are manufactured to the highest quality standards. For warranty information or technical assistance, please refer to the warranty card included with your product or contact WANAI customer support directly. Please have your model number (100A-Sliver) and ASIN (B0C9HV9RBZ) ready when contacting support.
For further assistance, please visit the official WANAI store on Amazon:WANAI Store

© 2024 WANAI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C9HV9RBZ

More documents and user manuals: **https://manuals.plus/**