

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Air Choice](#) /

› [Air Choice 1500W Infrared Electric Space Heater \(Model GD9315BCW-4JA\) Instruction Manual](#)

Air Choice GD9315BCW-4JA

Air Choice 1500W Infrared Electric Space Heater

MODEL: GD9315BCW-4JA

Instruction Manual

Introduction

This manual provides essential information for the safe and efficient operation of your Air Choice 1500W Infrared Electric Space Heater. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, read and understand all instructions before using this heater.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug into a properly grounded outlet.
- This heater includes a Tip-over Cut-off and Overheating Protection feature for enhanced safety.

Package Contents

- Air Choice 1500W Infrared Electric Space Heater (Model GD9315BCW-4JA)
- Remote Control
- User Manual

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for storage.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 m) of clear space around the heater from any combustible materials.
3. **Power Connection:** Plug the heater directly into a 120V AC, 60Hz grounded wall outlet. Do not use extension cords or power strips.
4. **Initial Power On:** Locate the main power switch on the back of the unit and flip it to the 'ON' position. The unit will emit an audible beep, and the LED display on the front panel will illuminate.

Rear View of Heater with Cord Management and Main Power Switch:



24 hours

Quick reply within 24 hours



12 Months

Replacement available within 12 months



Lifetime

Lifetime after-sales service and technical support

This image displays the rear of the heater, highlighting the convenient cord management system and the main on/off power switch.

The air intake filter is also visible.

Operating Instructions

Your Air Choice heater can be operated using the touch-sensitive control panel on the front or the included remote control.

Control Panel / Remote Control Functions:

- **ON/OFF Button:** Press to turn the heater on or off.
- **Mode Button:** Cycles through the three heating modes: 750W (Low), 1500W (High), and ECO mode.
- **Temperature Up/Down Arrows:** Adjusts the desired temperature between 59°F and 86°F in 1°F increments.
- **Timer Button:** Sets the auto-off timer from 0 to 12 hours.
- **°C/°F Button (Remote Only):** Toggles the temperature display between Celsius and Fahrenheit.
- **Child Lock (Remote Only):** Prevents accidental operation by children.

Heating Modes:

- **High (1500W):** Provides maximum heat output, suitable for heating larger areas (86-161 sq.ft).
- **Low (750W):** Provides reduced heat output, suitable for smaller areas (64-107 sq.ft) or maintaining warmth.
- **ECO Mode:** Automatically adjusts power consumption to maintain a constant, energy-efficient temperature.

Heater with 3 Heating Modes:

ONLY 3 SECONDS TO HEAT UP QUICKLY



This image illustrates the three available heating modes (High, Low, Eco) and the heater's compact dimensions.

Quick Heating Function:

A GOOD HEATER, A GREAT WINTER



12 Hours Timer
Setting Power-on/off




Low Noise



The heater features a 2-second preheat function for rapid warmth, as depicted with warm air flowing towards a family.

Timer Function and Low Noise Operation:

TIP-OVER SAFETY



OVERHEAT SHUT OFF



This image highlights the 12-hour timer and quiet operation (34 dB), ensuring a peaceful environment.

Remote Control Operation:

TIMER FUNCTION



The remote control allows convenient adjustment of settings from a distance, enhancing user comfort.

Official Product Video: Stay Warm for Winter with Portable Electric Space Heater

This video, provided by Air Choice US, demonstrates the heater's features and benefits, showcasing its ability to provide warmth and comfort during winter.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

- Cleaning:** Use a soft, dry cloth to wipe the exterior of the heater. Do not use abrasive cleaners or solvents.
- Air Intake Filter:** Periodically check and clean the air intake filter located at the rear of the unit. This can be done by vacuuming or gently washing the filter. Ensure the filter is completely dry before re-installing.
- Storage:** When not in use, store the heater in a cool, dry place. Wrap the power cord neatly around the integrated cord management hooks.

Troubleshooting

If your heater is not operating correctly, please refer to the following common issues:

- Heater does not turn on:** Ensure the power cord is securely plugged into a grounded outlet and the main power switch on the back is in the 'ON' position. Check if the circuit breaker has tripped.
- No heat output:** Verify that the desired temperature setting is higher than the current room temperature. Check the selected heating mode (High, Low, ECO).
- Heater shuts off unexpectedly:** This may be due to the overheating protection or tip-over safety features. Ensure the heater is on a stable surface and not covered or obstructed. Allow the unit to cool down before restarting.
- Remote control not working:** Check the batteries in the remote control. Ensure there are no obstructions between the remote and the heater's sensor.

If problems persist, contact customer support for assistance.

Specifications

Brand	Air Choice
Model Number	GD9315BCW-4JA
Power Output	1500W (High), 750W (Low)
Heating Technology	Infrared (6 Quartz Tubes) & PTC
Voltage	120 Volts
Amperage	12.5 Amps
Temperature Range	59°F ~ 86°F
Timer	1-12 Hours
Noise Level	34 dB
Dimensions (D x W x H)	11.96" x 10.77" x 14.3"
Item Weight	13.89 pounds
Heating Coverage	Up to 200 sq.ft
Safety Features	Tip-over Cut-off, Overheating Protection

Warranty and Support

The Air Choice 1500W Infrared Electric Space Heater comes with a 12-month default warranty from the manufacturer. For warranty claims or technical support, please refer to the contact information provided in your product packaging or visit the official Air Choice website.

© 2023 Air Choice. All rights reserved.