

[Manuals.plus](#) /

› [EUREKA ERGONOMIC](#) /

› EUREKA ERGONOMIC Smart Coffee Table (Model ERK-90Ma2-US) User Manual

EUREKA ERGONOMIC ERK-90Ma2-US

EUREKA ERGONOMIC Smart Coffee Table User Manual

Model: ERK-90Ma2-US

1. SAFETY INFORMATION

CAUTION: This product requires assembly. Always follow the assembly instructions carefully to avoid injury. The power socket is equipped with a safety switch to prevent electrical hazards. Ensure the table is stable and properly anchored to prevent tipping or collapse, especially when using the refrigerator or freezer drawers. Always unplug the table when not in use or when performing maintenance. Keep the table away from heat sources and do not place heavy objects on the table that could cause it to tip over. Always supervise children when they are near the table.

2. SETUP

2.1. Assembly

This product requires assembly. Refer to the separate assembly guide for detailed instructions. Ensure all components are present before beginning. A screwdriver is recommended for assembly, and two people are recommended for safe handling and assembly.

2.2. Placement

Place the coffee table on a stable, level surface. Ensure adequate clearance around the table for proper ventilation of the refrigeration unit. Avoid placing the table near direct heat sources or in direct sunlight. Do not place heavy objects on the table that could compromise its stability.

2.3. Initial Power-up

After assembly and placement, plug the power cord into a grounded electrical outlet. Ensure the safety switch for the power socket is in the 'OFF' position before plugging in. Once plugged in, you can switch the power socket to 'ON' to activate the table's features.



Figure 1: Product dimensions and basic electrical specifications.

3. OPERATING INSTRUCTIONS

3.1. Refrigerator and Freezer Drawers

The smart coffee table features two refrigerated drawers. The large refrigerator drawer has a capacity of 65 liters and maintains a temperature range of 3°C to 12°C. The smaller freezer drawer has a capacity of 28 liters and maintains a temperature range of -16°C to -25°C. Temperature control is mechanical. Use the temperature dial located inside the unit to adjust the cooling settings.



Figure 2: Refrigerator and freezer drawers with contents.



Figure 3: Mechanical temperature control dial.

3.2. Wireless Charging

A 10W wireless charging pad is integrated into the tabletop. Place your compatible smartphone directly on the designated charging area to initiate charging.



Figure 4: Wireless charging pad in use.

3.3. USB Interface and Power Socket

The table includes a dual USB interface and a 110V power socket located on the back. These ports can be used to charge electronic devices or power small appliances. The power socket is equipped with a safety switch. In case of excessive power draw, the safety switch will automatically cut off power to prevent hazards. Reset the switch if this occurs.



Figure 5: USB ports and power socket.

Your browser does not support the video tag.

Video 1: This video demonstrates the key features of the EUREKA ERGONOMIC Smart Coffee Table, including the accessible refrigerator and freezer drawers for cold beverages and snacks, and the integrated wireless charging functionality.

4. MAINTENANCE

4.1. Cleaning

To clean the table, wipe surfaces with a damp cloth. Avoid abrasive cleaners or harsh chemicals. For the refrigerator and freezer compartments, periodically defrost and clean with a mild detergent and water. Ensure the table is unplugged before cleaning.

4.2. General Care

Regularly check power cords for damage. Ensure ventilation areas for the refrigeration unit are not obstructed. Avoid placing hot items directly on the tempered glass top without protection.

5. TROUBLESHOOTING

- **No Power:** Check if the power cord is securely plugged into a working outlet. Verify the power socket's safety switch is in the 'ON' position. If the safety switch has tripped, reduce the load on the power socket and reset it.
- **Cooling Issues:** Ensure the refrigerator and freezer drawers are properly closed. Check the mechanical temperature control dial to ensure it is set to the desired cooling level. Ensure adequate ventilation around the unit.
- **Charging Issues:** For wireless charging, ensure your device is compatible and correctly placed on the charging pad. For USB and power sockets, ensure devices are properly connected and the table's power is on.
- **Unusual Noise:** The refrigeration unit operates with a low noise level (34dB). If unusual or loud noises occur, ensure the table is level and not vibrating against other objects. If the noise persists, contact customer support.

6. SPECIFICATIONS

Brand	EUREKA ERGONOMIC
Model Number	ERK-90Ma2-US
Product Dimensions (D x W x H)	23.03" x 41.54" x 18.11"
Item Weight	94.8 pounds
Frame Material	Glass
Color	White
Refrigerator Capacity	65L (3°C to 12°C)
Freezer Capacity	28L (-16°C to -25°C)
Wireless Charging	10W
USB Interface	Dual USB
Power Socket	110V with Safety Switch
Refrigeration Method	Compressor/Direct Cooling
Noise Level	34dB
Electricity Consumption	0.35 KWH/24H
Operation Mode	Mechanical Temperature Control
Top Material Type	Tempered Glass
Recommended Assembly	2 people, Screwdriver
Product Care	Wipe with Damp Cloth

7. WARRANTY

This product comes with a limited warranty. For details regarding warranty coverage and claims, please refer to the warranty card included with your product or contact EUREKA ERGONOMIC customer support.

8. CUSTOMER SUPPORT

For further assistance, technical support, or to report issues, please contact EUREKA ERGONOMIC customer service. Visit the official [EUREKA ERGONOMIC website](#) for contact information and additional resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question