

FEZIBO B0C9JGVG61

FEZIBO Height Adjustable Electric Desk User Manual

Model: B0C9JGVG61

1. INTRODUCTION

The FEZIBO Height Adjustable Electric Desk is designed to enhance your working environment by allowing seamless transitions between sitting and standing positions. This electric desk features a motorized lifting mechanism for smooth height adjustment, memory control for personalized settings, and anti-collision technology for safety. It is a practical and multifunctional solution for both office and home environments.

Key features include:

- Electric lifting system with smooth and quiet operation.
- Four memory preset buttons for quick height adjustments.
- Anti-collision technology to prevent accidents.
- Durable industrial-grade steel frame with a 70 kg load capacity.
- Tabletop made from stained oak veneer.




Figure 1: FEZIBO Height Adjustable Electric Desk

2. SAFETY INFORMATION

Please read and understand all safety instructions before operating the desk. Failure to follow these instructions may result in injury or damage to the product.

- Be cautious when adjusting the desk's height to avoid injury.
- Ensure the desk is properly assembled and stable before use.
- Keep the desk area clear of obstructions to prevent the anti-collision sensors from activating unexpectedly.
- This product is only for indoor use.
- Serious or fatal crushing injuries can occur from furniture tip-over.
- ALWAYS secure this furniture to the wall using tip-over restraints.
- To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, desks, or shelves.



English

WARNING

Keep away from fire.

This product is only for indoor use.

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, desks, or shelves.

Deutsch

ACHTUNG

Von Zündquellen fernhalten.

Dieses Produkt ist nur für den Innenbereich geeignet.

Umfallende Möbelstücke können lebensgefährlich sein.

Um diesem Risiko zu entgehen, muss das Möbel UNBEDINGT mit dem beige-packten Kippschutz an der Wand befestigt werden.

Um das Risiko schwerer oder gar tödlicher Verletzungen durch umkippende Möbelstück weiter zu mindern, bitte Folgendes beachten:

- schwere Gegenstände immer in Bodennähe aufbewahren.
- Fernsehgeräte oder andere schwere Geräte niemals auf das Produkt stellen.
- Kindern niemals erlauben, auf Schubladen, Türen, Tischen und Regalen zu klettern oder sich daranzuhängen.

Français

ATTENTION

Tenir à l'écart des sources d'incendie.

Ce produit ne peut être utilisé qu'à l'intérieur.

Risque de blessures graves ou mortelles en cas de basculement du meuble.

TOUJOURS fixer ce meuble au mur à l'aide des fixations antibasculement.

Pour encore réduire les risques de blessures graves ou mortelles dus au basculement du meuble:

- Placer les objets les plus lourds dans le tiroir du bas.
- Ne placez pas de téléviseur ou d'autres objets lourds sur ce produit.
- Ne jamais laisser les enfants grimper ou s'accrocher aux tiroirs, portes, tables, ou tablettes.

Español

ADVERTENCIA

Mantener alejado del fuego.

Este producto es sólo para uso en interiores.

Si el mueble vuelca, puede provocar lesiones muy graves e incluso mortales.

Fija SIEMPRE este mueble a la pared utilizando los accesorios antivuelco.

Para reducir aún más el riesgo de lesiones graves o incluso mortales causadas por el vuelco del mueble:

- Guarda los objetos más pesados en el cajón inferior.
- No pongas un TV u otros objetos pesados encima de este producto.
- Evite que los niños se suban a los muebles o se cuelguen de cajones, puertas, mesas o estanterías.

Italiano

AVVERTENZA

Tenere lontano da fonti di accensione.

Questo prodotto è solo per uso interno.

Se il mobile si ribalta può causare lesioni da schiacciamento gravi o mortali.

Fissa SEMPRE questo mobile alla parete usando i componenti di sicurezza.

Per ridurre ulteriormente il rischio di lesioni gravi o mortali causate dal ribaltamento:

- Metti gli oggetti più pesanti nel cassetto inferiore.
- Non collocare la TV o altri oggetti pesanti sopra questo prodotto.
- Evita che i bambini si appendano o si arrampichino sui cassetti, ante, tavoli o sui ripiani.

日本語

警告

発火源に近づけないでください。

本製品は屋内専用です。

家具の転倒により、家具の下敷きになって大ケガ、あるいは生命にかかわるような傷害を負う危険があります。

本製品は、転倒防止用固定具を使用して、必ず壁に固定してください。

家具の転倒による大ケガや死亡事故のリスクを減らすために以下のことを守ってください。

- 重い物は下の引き出しに入れる。
- 本製品の上にテレビやほかの重い物を置かない。
- 絶対に子どもに引き出しや扉、テーブル、棚板によじ登ったりぶら下がったりさせない。

Figure 2: Important Safety Warnings

3. SETUP AND ASSEMBLY

The FEZIBO Electric Desk is designed for quick and straightforward assembly. The tabletop is divided into two parts, which can be assembled with precise screws and accessories. A simple tool is included to assist with the process.

3.1. Unpacking

Carefully remove all components from the packaging. Verify that all parts listed in the assembly guide (not provided in this manual) are present and undamaged. Keep packaging materials until assembly is complete in case of missing parts or returns.

3.2. Assembly Steps

1. Assemble the desk frame according to the provided instructions. Ensure all screws are tightened securely.
2. Attach the two tabletop sections together using the designated connectors and screws.
3. Mount the assembled tabletop onto the desk frame, aligning it with the pre-drilled holes.
4. Secure the tabletop to the frame using the appropriate fasteners.
5. Install the control panel and connect all necessary cables as indicated in the assembly guide.



Figure 3: Desk components ready for assembly

4. OPERATING INSTRUCTIONS

The FEZIBO Electric Desk features an intuitive control panel for easy height adjustment and memory functions.

4.1. Control Panel Overview




Figure 4: Smart Keypad

- **Up/Down Arrows (▲ / ▼):** Press and hold to manually adjust the desk height. The desk moves at a speed of 2 cm/second (approximately 1 inch per second) with soft start and stop.
- **Memory Buttons (1, 2, 3, 4):** These buttons allow you to save and recall preferred height settings.

4.2. Adjusting Height

To adjust the desk height, simply press and hold the up (▲) or down (▼) arrow button until the desired height is reached. The current height will be displayed on the digital screen.

Standing and Sitting

Height Adjustment Range

28.3"–45"



Figure 5: Standing and Sitting Height Range

4.3. Setting Memory Presets

1. Adjust the desk to your desired height using the up/down arrows.
2. Press the