

[Manuals.plus](#) /

› [Feit Electric](#) /

› Feit Electric 40W LED Outdoor Wall Pack Light Instruction Manual (Model S8WPK/850/DD/BZ/4)

Feit Electric S8WPK/850/DD/BZ/4

Feit Electric 40W LED Outdoor Wall Pack Light Instruction Manual

MODEL: S8WPK/850/DD/BZ/4

1. Safety Information

Please read and understand all safety instructions before installation and use. Failure to do so may result in electric shock, fire, or other hazards.

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installing or servicing.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Ensure the supply voltage is 120V AC.
- Do not attempt to modify the fixture.
- This fixture is UL Listed, ensuring it meets safety standards.
- Suitable for wet locations.

2. Product Overview

The Feit Electric 40W LED Outdoor Wall Pack Light is designed for outdoor security and area illumination. It features integrated LED technology, a durable aluminum housing, and a built-in photocell for dusk-to-dawn operation.



Image: Feit Electric 40W LED Outdoor Wall Pack Lights, showing multiple units.

Key Features:

- **Dusk-to-Dawn Photocell:** Automatically turns the light on at night and off during the day.
- **Durable Construction:** Made with corrosion-resistant, die-cast aluminum housing and impact-resistant glass.
- **Weather Resistant:** IP65 wet location rated, designed to withstand harsh outdoor conditions.
- **Energy Efficient:** Integrated LED technology provides 3700 lumens using only 40 watts.
- **Long Lifespan:** Rated for up to 50,000 hours of operation.

Premium Durability



Sunproof



Weather Resistant



Windproof



Durable

Image: Illustrates the durability features including sunproof, weather resistant, windproof, and overall durable construction.

3. Specifications

Detailed specifications for the Feit Electric 40W LED Outdoor Wall Pack Light:

Wall Pack Specifications



 CCT: 5000k Daylight

 Wattage: 40W

CRI: 80

 Brightness: 3,700 Lumens

 Life Hours: 50,000

 Dusk To Dawn Sensor

 IP65 Wet Rated

Voltage 120

Image: Diagram showing key specifications and dimensions of the wall pack light.

Specification	Value
Model Number	S8WPK/850/DD/BZ/4
Wattage	40W
Brightness	3700 Lumens
Color Temperature (CCT)	5000K Daylight
Color Rendering Index (CRI)	80
Voltage	120V
Dimensions (L x W x H)	3.5" x 5.5" x 8.3"
Material	Aluminum, Glass

IP Rating	IP65 (Wet Location Rated)
Lifespan	50,000 Hours
Installation Type	Surface Mounted
Special Features	Dusk to Dawn, Energy Efficient, Waterproof

4. Setup and Installation

The Feit Electric Wall Pack Light offers two primary installation methods: Junction Box Mount and Direct Wall Mount. Always ensure power is disconnected before beginning installation.

Tools Required (Not Included):

- Screwdriver
- Wire Strippers
- Drill (if direct wall mounting)
- Safety Glasses

Installation Steps:

1. **Disconnect Power:** Turn off power at the circuit breaker or fuse box to avoid electrical shock.
2. **Prepare Mounting Surface:** The fixture comes with a hands-free wiring mounting back plate. This detachable plate fits most standard junction boxes or can be used for direct wall mounting.
3. **Mount Back Plate:** Secure the mounting back plate to the junction box or directly to the wall using appropriate hardware. Ensure it is level and securely fastened.
4. **Wire Connections:** Connect the fixture's wires to the supply wires according to local electrical codes. Typically, this involves connecting live to live, neutral to neutral, and ground to ground. Use approved wire connectors.
5. **Attach Fixture:** Carefully align the fixture with the mounted back plate and secure it using the provided screws. Ensure a tight seal to prevent water intrusion.
6. **Restore Power:** Once the fixture is securely installed and wired, restore power at the circuit breaker.



✓ Built-in photocell sensor	✗ No Sensor
✓ High quality aluminum housing	✗ Standard quality metal
✓ Shatter resistant	✗ Easy to break glass cover
✓ Anti-Rust	✗ Rusty
✓ Weather resistant	✗ Deteriorate overtime
✓ Energy efficient	✗ Uneconomical
✓ Longlasting 50,000 hours Lifespan	✗ Approx. 4,000 hours Lifespan

Image: Depicts two installation methods: Junction Box Mount and Direct Wall Mount.



Image: Example of the wall pack light installed on a textured exterior wall.

5. Operating Instructions

The Feit Electric Wall Pack Light is equipped with a built-in photocell sensor for automatic operation.

Dusk-to-Dawn Functionality:

- The integrated photocell sensor detects ambient light levels.
- When natural light diminishes at dusk, the sensor will activate the light fixture.
- When natural light returns at dawn, the sensor will deactivate the light fixture, saving energy.
- No manual intervention is required for daily operation once installed.

Photocell Sensor



Image: Close-up view of the photocell sensor located on the top of the fixture.




Image: Illustrates the difference between daytime (light off) and nighttime (light on) operation due to the dusk-to-dawn sensor.

6. Maintenance

The Feit Electric LED Wall Pack Light requires minimal maintenance due to its durable construction and integrated LED design.

- **Cleaning:** Periodically clean the exterior of the fixture with a soft, damp cloth to remove dirt and debris. Do not use abrasive cleaners or solvents. Ensure the photocell sensor is clear of obstructions for proper operation.
- **No Bulb Replacement:** This fixture uses integrated LEDs, meaning there are no bulbs to replace. The LEDs are designed to last for the entire lifespan of the fixture.
- **Inspection:** Occasionally inspect the fixture and wiring for any signs of damage or wear. If damage is found, disconnect power and consult a qualified electrician.

7. Troubleshooting

If your Feit Electric Wall Pack Light is not functioning as expected, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Light does not turn on at night.	No power to the fixture. Photocell obstructed or faulty. Wiring issue.	Check circuit breaker/fuse. Ensure photocell is clean and not blocked by objects or light sources. Verify wiring connections are secure (consult electrician if unsure).
Light stays on during the day.	Photocell obstructed or receiving insufficient light. Photocell faulty.	Ensure photocell is clean and exposed to direct daylight. Relocate fixture if it's in a shaded area. If issue persists, contact customer support.
Light flickers or dims.	Loose wiring connection. Voltage fluctuations.	Check all wiring connections. Consult an electrician to check voltage supply.

8. Warranty Information

This Feit Electric product is covered by a**5-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For warranty claims or further details, please contact Feit Electric customer support.

9. Customer Support

For 24/7 customer support and additional assistance, please visit the Feit Electric help center:

[Visit Feit Electric Help Center](#)



For 24/7 customer support,
visit **feit.com/help**



Image: Information on 24/7 customer support, directing users to feit.com/help.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C9JWWND5>

More documents and user manuals: <https://manuals.plus/>